

DVP-S330/S530D/S550D/S705D

RMT-D108A/D109A/D111A/D111E

SERVICE MANUAL

Self Diagnosis
Supported model



Photo: DVP-S330

US Model

DVP-S330/S530D/S550D

Canadian Model

DVP-S330/S530D/S550D

E Model

DVP-S530D

Hong Kong Model

DVP-S705D

Singapore Model

DVP-S705D

SPECIFICATIONS

CD/DVD player

Laser Semiconductor laser
Signal format system NTSC

Audio characteristics

Frequency response DVD (PCM 96 kHz): 2 Hz to 44 kHz (± 1 dB)*
DVD (PCM 48 kHz): 2 Hz to 22 kHz (± 0.5 dB)
CD: 2 Hz to 20 kHz (± 0.5 dB)
Signal-to-noise ratio More than 110 dB (LINE OUT (AUDIO 1, 2) connectors only)
Harmonic distortion Less than 0.0025%
Dynamic range More than 100 dB (DVD)
More than 97 dB (CD)
Wow and flutter Less than detected value ($\pm 0.001\%$ W PEAK)

Outputs and inputs

	Jack type	Output level	Load impedance
LINE OUT (AUDIO 1, 2)	Phono jacks	2 Vrms (at 50 kilohms)	Over 10 kilohms
DIGITAL OUT (OPTICAL)	Optical output connector	-18 dBm	Wave length: 660 nm
DIGITAL OUT (COAXIAL)	Phono jack	0.5 Vp-p	75 ohms terminated
LINE OUT (VIDEO 1, 2)	Phono jacks	1.0 Vp-p	75 ohms, sync negative
S VIDEO OUT (1, 2)	4-pin mini DIN	Y: 1.0 Vp-p C: 0.286 Vp-p	75 ohms, sync negative 75 ohms terminated
COMPONENT VIDEO OUT (Y, Pb/B-Y, Pr/R-Y) (EXCEPT S330)	phono jacks	Y: 1.0 Vp-p Pb/B-Y, Pr/R-Y: 0.7 Vp-p	75 ohms, sync negative 75 ohms
PHONES (EXCEPT S330)	Phone jack	12 mW	32 ohms
5.1CH OUTPUT (EXCEPT S330)	Phono jacks	2 Vrms (at 50 kilohms)	Over 10 kilohms

General

Power requirements 120 V AC, 60 Hz
Power consumption 14 W (S330)
16 W (EXCEPT S330)
Dimensions (approx.) 430 \times 95 \times 305 mm (17 \times 3 $\frac{3}{4}$ \times 12 in.) (w/h/d) incl. projecting parts
Mass (approx.) 3.3 kg (7 lb 4 oz) (S330)
3.4 kg (7 lb 8 oz) (EXCEPT S330)
Operating temperature 41°F to 95°F (5°C to 35°C)
Operating humidity 5% to 90%

Supplied accessories

- Audio/Video/S-link connecting cord (1) (US, Canadian)
- Audio/Video connecting cord (1) (E, Hong Kong, Singapore)
- S video cable (1)
- Remote commander (remote) RMT-D108A (1) (S530D)
- Remote commander (remote) RMT-D109A (1) (S330)
- Remote commander (remote) RMT-D111A (1) (S550D)
- Remote commander (remote) RMT-D111E (1) (S705D)
- Size AA (R6) batteries (2)

* The signals from LINE OUT (AUDIO 1, 2) connectors and 5.1 ch L, R connectors (except S330) are measured. When you play the PCM sound tracks with 96 kHz sampling frequency, the output signals from the DIGITAL OUT (OPTICAL, COAXIAL) are converted to 48 kHz (sampling frequency).

Design and specifications are subject to change without notice.




CD/DVD PLAYER

SONY®

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer:

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are “pinched” or contact high-wattage resistors.
3. Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement.
4. Look for parts which, though functioning, show obvious signs of deterioration. Point them out to the customer and recommend their replacement.
5. Check the line cord for cracks and abrasion. Recommend the replacement of any such line cord to the customer.
6. Check the B+ voltage to see it is at the values specified.
7. Check the antenna terminals, metal trim, “metallized” knobs, screws, and all other exposed metal parts for AC leakage. Check leakage as described below.



LEAKAGE TEST

The AC leakage from any exposed metal part to earth ground and from all exposed metal parts to any exposed metal part having a return to chassis, must not exceed 0.5 mA (500 microamperes). Leakage current can be measured by any one of three methods.

1. A commercial leakage tester, such as the Simpson 229 or RCA WT-540A. Follow the manufacturers' instructions to use these instruments.
2. A battery-operated AC milliammeter. The Data Precision 245 digital multimeter is suitable for this job.
3. Measuring the voltage drop across a resistor by means of a VOM or battery-operated AC voltmeter. The “limit” indication is 0.75V, so analog meters must have an accurate low-voltage scale. The Simpson 250 and Sanwa SH-63Trd are examples of a passive VOM that is suitable. Nearly all battery operated digital multimeters that have a 2V AC range are suitable. (See Fig. A)

WARNING!!

WHEN SERVICING, DO NOT APPROACH THE LASER EXIT WITH THE EYE TOO CLOSELY. IN CASE IT IS NECESSARY TO CONFIRM LASER BEAM EMISSION, BE SURE TO OBSERVE FROM A DISTANCE OF MORE THAN 25 cm FROM THE SURFACE OF THE OBJECTIVE LENS ON THE OPTICAL PICK-UP BLOCK.

CAUTION:

The use of optical instrument with this product will increase eye hazard.

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK \triangle OR DOTTED LINE WITH MARK \triangle ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE \triangle SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.


TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>	<u>Section</u>	<u>Title</u>	<u>Page</u>
Service Note 4			AU-212 (AUDIO, VIDEO BUFFER)		
1.	GENERAL		Printed Wiring Board 4-53		
	This Player Can Play the Following Discs 1-1		AU-212 (AUDIO) Schematic Diagram 4-55		
	Getting Started 1-1		AU-212 (VIDEO BUFFER) Schematic Diagram 4-57		
	Playing Discs 1-3		FL-97/101 (FUNCTION SWITCH, IF CON)		
	Using Various Functions with the Control Menu 1-5		Printed Wiring Board 4-59		
	Settings and Adjustments 1-11		FL-99 (FUNCTION SWITCH, IF CON)		
	Additional Information 1-15		Printed Wiring Board 4-61		
2.	DISASSEMBLY		FL-97/99/101 (FUNCTION SWITCH)		
2-1.	Case Removal 2-1		Schematic Diagram 4-65		
2-2.	MB-82/85 Board Removal 2-1		FL-97/99/101 (IF CON) Schematic Diagram 4-67		
2-3.	AU-208/212 Board Removal		SW-315/317 (SURROUND SWITCH), FR-146/148/150		
	(S330/S530D/S550D) 2-1		(IR/POWER SWITCH) Printed Wiring Boards 4-69		
2-4.	AU-210 Board Removal (S705D) 2-1		SW-315/317 (SURROUND SWITCH), FR-146/148/150		
2-5.	Power Block Removal 2-2		(IR/POWER SWITCH) Schematic Diagram 4-71		
2-6.	Tray Cover Removal 2-2		HP-109/111 (HEADPHONE) Printed Wiring Boards		
2-7.	Front Panel Removal 2-2		and Schematic Diagram 4-73		
2-8.	Mechanism Deck Removal 2-2		RY-12 (RELAY) Printed Wiring Board and		
2-9.	Tray Removal 2-3		Schematic Diagram 4-75		
2-10.	Optical Pick-up Removal 2-3		HS-030SF/030SH (SWITCHING REGULATOR)		
2-11.	Belt, Loading Motor (M001),		Printed Wiring Board 4-77		
	MS-29/TK-51 Board Removal 2-3		HS-030SF/030SH (SWITCHING REGULATOR)		
2-12.	Internal View 2-4		Schematic Diagram 4-79		
2-13.	Circuit Boards Location 2-5		SRV902UC (SWITCHING REGULATOR)		
3.	BLOCK DIAGRAMS		Printed Wiring Board 4-81		
3-1.	Overall Block Diagram 3-1		SRV902UC (SWITCHING REGULATOR)		
3-2.	RF/Servo Block Diagram 3-3		Schematic Diagram 4-83		
3-3.	Signal Process/Video Block Diagram 3-5		5.		
3-4.	System Control Block Diagram 3-7		IC PIN FUNCTION DESCRIPTION		
3-5.	Audio (1) Block Diagram 3-9		5-1.		
3-6.	Audio (2) Block Diagram 3-11		System Control Pin Function		
3-7.	Audio (3) Block Diagram 3-13		(MB-82/85 Board IC202) 5-1		
3-8.	Interface Control Block Diagram 3-15		6.		
3-9.	Power Block Diagram 3-17		TEST MODE		
4.	PRINTED WIRING BOARDS AND SCHEMATIC		6-1.		
	DIAGRAMS		General Description 6-1		
4-1.	Frame Schematic Diagram 4-3		6-2.		
4-2.	Printed Wiring Boards and Schematic Diagrams 4-9		Starting Test Mode 6-1		
	TK-51 (RF/SERVO) Printed Wiring Board 4-9		6-3.		
	TK-51 (RF/SERVO) Schematic Diagram 4-13		Syscon Diagnosis 6-1		
	MS-29 (LOADING) Printed Wiring Board and		6-4.		
	Schematic Diagram 4-15		Drive Auto Adjustment 6-5		
	MB-82/85 (SIGNAL PROCESS)		6-5.		
	Printed Wiring Board 4-17		Drive Manual Operation 6-7		
	MB-82/85 (AV DECODER) Schematic Diagram 4-21		6-6.		
	MB-82/85 (SDRAM) Schematic Diagram 4-23		Mecha Aging 6-9		
	MB-82/85 (SERVO DSP) Schematic Diagram 4-25		6-7.		
	MB-82/85 (DRIVE) Schematic Diagram 4-27		Emergency History 6-9		
	MB-82/85 (ARP) Schematic Diagram 4-29		6-8.		
	MB-82/85 (SYSTEM CONTROL)		Version Information 6-10		
	Schematic Diagram 4-31		6-9.		
	MB-82/85 (HGA) Schematic Diagram 4-33		Video Level Adjustment 6-10		
	MB-82/85 (CLOCK GENERATOR, AUDIO DSP,		7.		
	V EQ/NR) Schematic Diagram 4-35		ELECTRICAL ADJUSTMENTS		
	MB-82/85 (DAC) Schematic Diagram 4-37		7-1.		
	MB-82/85 (BIAS) Schematic Diagram 4-39		Power Supply Adjustment 7-1		
	AU-208 (AUDIO, VIDEO BUFFER)		1.		
	Printed Wiring Board 4-41		Power Supply Check		
	AU-208 (AUDIO, VIDEO BUFFER)		(HS-030SF/030SH BOARD, SRV902UC BOARD) 7-1		
	Schematic Diagram 4-43		2.		
	AU-210 (AUDIO, VIDEO BUFFER)		+3.3 V Adjustment (SRV902UC BOARD) 7-1		
	Printed Wiring Board 4-45		7-2.		
	AU-210 (AUDIO) Schematic Diagram 4-49		Adjustment of Video System 7-2		
	AU-210 (VIDEO BUFFER) Schematic Diagram 4-51		1.		
			Video Level Adjustment (MB-82/85 BOARD) 7-2		
			2.		
			S-terminal Output Check (MB-82/85 BOARD) 7-2		
			3.		
			Checking Component Video Output B-Y		
			(MB-82/85 BOARD) 7-2		
			4.		
			Checking Component Video Output R-Y		
			(MB-82/85 BOARD) 7-2		
			5.		
			Checking Component Video Output Y		
			(MB-82/85 BOARD) 7-3		
			6.		
			Checking S Video Output S-C (MB-82/85 BOARD) 7-3		
			7-3.		
			Adjustment Related Parts Arrangement 7-4		
			8.		
			REPAIR PARTS LIST		
			8-1.		
			Exploded Views 8-1		
			8-1-1.		
			Case Assembly (S330/S530D/S550D) 8-1		
			8-1-2.		
			Case Assembly (S705D) 8-2		
			8-1-3.		
			Front Panel Assembly 8-3		
			8-1-4.		
			Chassis Assembly 8-5		
			8-1-5.		
			Mechanism Deck Assembly 8-6		
			8-2.		
			Electrical Parts List 8-7		

SERVICE NOTE

1. DISASSEMBLY

- This set can be disassembled in the order shown below.



2. NOTE ON REMOVE THE CASE

- 1) Remove seven screws. (See Fig. 1)
- 2) Open the side of case. (See Fig. 1)
- 3) Remove the case as lift straight. (See Fig. 1)




Fig. 1

4. HOW TO SERVICE MB-82/85 BOARD

- 1) Remove the case from the set. (Refer to 2-1)
- 2) Remove the MB-82/85 board. (Refer to 2-2)
- 3) Set the MB-82/85 board as shown in Fig. 3.

Note: Do not disconnect wiring, except FMA-7/8/9.




Fig. 3

3. DISC REMOVAL PROCEDURE (at POWER OFF)

- 1) Insert a tapering driver into the aperture of the unit bottom, and move the lever of chuck cam in the direction of the arrow (A). (See Fig. 2)
- 2) Draw out the tray in the direction of the arrow (B), and remove a disc. (See Fig. 2)




Fig. 2

SECTION 1 GENERAL

This section is extracted from DVP-S550D instruction manual (3-865-641-11).

About This Manual

Conventions

- Instructions in this manual describe the controls on the player. You can also use the controls on the remote if they have the same or similar names as those on the player.
- The icons on the right are used in this manual:

Icon	Meaning
	Indicates that you can use only the remote to do the task.
	Indicates tips and hints for making the task easier.
	Indicates the functions for DVD VIDEOS.
	Indicates the functions for VIDEO CDs.
	Indicates the functions for Audio CDs.

This Player Can Play the Following Discs

	DVD VIDEOS		VIDEO CDs		Audio CDs	
Disc logo						
Contents	Audio + Video		Audio + Video		Audio	
Disc size	12 cm	8 cm	12 cm	8 cm	12 cm	8 cm (CD single)
Play time	About 4 h (for single-sided DVD)/ about 8 h (for double-sided DVD)	About 80 min. (for single-sided DVD)/ about 160 min. (for double-sided DVD)	74 min.	20 min.	74 min.	20 min.

DVD VIDEO logo is a trademark.

This player conforms to the NTSC color system. You cannot play discs recorded in other color systems such as PAL or SECAM.

Region code of DVDs you can play on this unit

Your DVD player has a region code printed on the back of the unit and will only play DVDs that are labeled with identical region codes.

DVDs labeled will be also played on this unit.

If you try to play any other DVD, the message "Playing this disc prohibited by area limits." will appear on the TV screen.

Depending on the DVD, no region code indication may be labeled even though playing the DVD is prohibited by the area limits.




Note on playback operations of DVDs and VIDEO CDs

Some playback operations of DVDs and VIDEO CDs may be intentionally fixed by software producers. Since this player plays DVDs and VIDEO CDs according to the disc contents the software producers designed, some playback features may not be available. Also refer to the instructions supplied with the DVDs or VIDEO CDs.

4

Terms for discs

- Title**
The longest sections of a picture or a music piece on a DVD; a movie, etc. for a picture piece on a video software or an album, etc., for a music piece on an audio software. Each title is assigned a title number enabling you to locate the title you want.
- Chapter**
Sections of a picture or a music piece that are smaller than titles. A title is composed of several chapters. Each chapter is assigned a chapter number enabling you to locate the chapter you want. Depending on the disc, no chapters may be recorded.
- Track**
Sections of a picture or a music piece on a VIDEO CD or a CD. Each track is assigned a track number enabling you to locate the track you want.



- Index (CD) / Video Index (VIDEO CD)**
A number that divides a track into sections to easily locate the point you want on a VIDEO CD or a CD. Depending on the disc, no indexes may be recorded.

- Scene**
On a VIDEO CD with PBC functions, the menu screens, moving pictures and still pictures are divided into sections called "scenes." Each scene is assigned a scene number enabling you to locate the scene you want.

Note on PBC (Playback Control) (VIDEO CDs)

This player conforms to Ver. 1.1 and Ver. 2.0 of VIDEO CD standards. You can enjoy two kinds of playback according to the disc type.

Disc type	You can
VIDEO CDs without PBC functions (Ver. 1.1 discs)	Enjoy video playback (moving pictures) as well as music.
VIDEO CDs with PBC functions (Ver. 2.0 discs)	Play interactive software using menu screens displayed on the TV screen (PBC Playback), in addition to the video playback functions of Ver. 1.1 discs. Moreover, you can play high-resolution still pictures, if they are included on the disc.

Discs that the player cannot play

The player cannot play discs other than the ones listed in the table on page 4. CD-R, CD-ROMs including PHOTO CDs, data sections in CD-EXTRAS, DVD-ROMs etc., cannot be played.

When playing DTS*-encoded CDs, excessive noise will be heard from the analog stereo outputs. To avoid possible damage to the audio system, the consumer should take proper precautions when the analog stereo outputs of the DVD player are connected to an amplification system. To enjoy DTS Digital Surround™ playback, an external 5.1-channel DTS Digital Surround™ decoder system must be connected to the digital output of the DVD player.

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

* "DTS" is a trademark of Digital Theater Systems, Inc.

5

Precautions

On safety

- Caution - The use of optical instruments with this product will increase eye hazard.
- Should any solid object or liquid fall into the cabinet, unplug the player and have it checked by qualified personnel before operating it any further.

On power sources

- The player is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the player itself has been turned off.
- If you are not going to use the player for a long time, be sure to disconnect the player from the wall outlet. To disconnect the AC power cord (mains lead), grasp the plug itself; never pull the cord.
- Should the AC power cord (mains lead) need to be changed, have it done at a qualified service shop only.

On placement

- Place the player in a location with adequate ventilation to prevent heat build-up in the player.
- Do not place the player on a soft surface such as a rug that might block the ventilation holes on the bottom.
- Do not place the player in a location near heat sources, or in a place subject to direct sunlight, excessive dust or mechanical shock.

On operation

- If the player is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lenses inside the player. Should this occur, the player may not operate properly. In this case, remove the disc and leave the player turned on for about half an hour until the moisture evaporates.

On adjusting volume

- Do not turn up the volume while listening to a portion with very low level inputs or no audio signals. If you do, the speakers may be damaged when a peak level portion is played.

On cleaning

- Clean the cabinet, panel and controls with a soft cloth slightly moistened with a mild detergent solution. Do not use any type of abrasive pad, scouring powder or solvent such as alcohol or benzene.

If you have any questions or problems concerning your player, please consult your nearest Sony dealer.

IMPORTANT NOTICE

Caution: The enclosed DVD player is capable of holding a still video image or On screen display image on your television screen indefinitely. If you leave the still video image or On screen display image on your TV for an extended period of time you risk permanent damage to your television screen. Projection televisions are very susceptible.

Notes on Discs

On handling discs

- To keep the disc clean, handle the disc by its edge. Do not touch the surface.
- Do not stick paper or tape on the disc.
- If there is glue (or a similar substance) on the disc, remove the glue completely before using the disc.



- Do not expose the disc to direct sunlight or heat sources such as hot air ducts, or leave it in a car parked in direct sunlight as there can be considerable rise in temperature inside the car.
- After playing, store the disc in its case.

On cleaning

- Before playing, clean the disc with a cleaning cloth. Wipe the disc from the center out.



- Do not use solvents such as benzene, thinner, commercially available cleaners or anti-static spray intended for vinyl LPs.

6

Getting Started


This section describes how to hook up the CD/DVD player to a TV (with audio/video input jacks) and/or an AV receiver (amplifier). You cannot connect this player to a TV which does not have a video input connector. Be sure to turn off the power of each component before making the connections.

Unpacking

- Check that you have the following items:
 - Audio/video/S-link connecting cord (1)
 - S video cord (1)
 - Remote commander (remote) RMT-D111A (1)
 - Size AA (R6) batteries (2)

Inserting batteries into the remote

You can control the player using the supplied remote. Insert two Size AA (R6) batteries by matching the + and - on the batteries. When using the remote, point it at the remote sensor on the player.



You can control TVs and AV receivers using the supplied remote. See page 60.

Notes

- Do not leave the remote in an extremely hot or humid place.
- Do not drop any foreign object into the remote casing, particularly when replacing the batteries.
- Do not expose the remote sensor to direct sunlight or lighting apparatuses. Doing so may cause a malfunction.
- If you will not use the remote for an extended period of time, remove the batteries to avoid possible damage from battery leakage and corrosion.

Getting started



7

TV Hookups

This connection is for listening to the sound through TV speakers (2ch - L,R). Refer to the instructions supplied with the component to be connected.

Required cords


Audio/video/S-link connecting cord (supplied) (1)
S video cord (supplied) (1)
When connecting the cords, be sure to match the color-coded cord to the appropriate jacks on the components. Yellow (video) to Yellow, Red (right) to Red and White (left) to White. Be sure to make connections firmly to avoid hum and noise.
If your TV has an S-link connector, you can control the CD/DVD player from the TV. Connect the TV via the S-LINK connector. If your TV has an S-video input connector, connect the component via the S VIDEO OUT connector using the S video cord. You will get a better picture.
Refer to the instructions supplied with the TV to be connected.



8


If you connect the player to a monitor or projector having component video input connectors that conform to output signals from the COMPONENT VIDEO OUT (Y, PB/B-Y, PR/R-Y) connectors on the player

Connect the component via the COMPONENT VIDEO OUT connectors using three video connecting cords (not supplied) of the same kind. You will get a better picture.



Notes

- Refer to the instructions supplied with the component to be connected.
- Do not connect this player to a video deck. If you view the pictures on your TV after making the connections shown below, a picture noise may appear.



- Depending on the TV or receiver (amplifier), sound distortion may occur because the audio output level is high. In this case, set "AUDIO ATT" in "AUDIO SETUP" to "ON" in the setup display. For details, see page 55.

Setups for the player

Some setups are necessary for the player depending on the TV or other components to be connected. Use the setup display to change the various settings. For details on using the setup display, see page 47.

- To connect the player to a normal TV
In the setup display, set "TV TYPE" in "SCREEN SETUP" to "4:3 LETTER BOX" (default setting) or "4:3 PAN SCAN." For details, see page 51.
- To connect the player to a TV having the WIDE MODE function
In the setup display, set "TV TYPE" in "SCREEN SETUP" to "16:9/4:3 WIDE MODE." For details, see page 51.
- To connect the player to a wide-screen TV
In the setup display, set "TV TYPE" in "SCREEN SETUP" to "16:9/4:3 WIDE MODE." For details, see page 51.

Getting Started

9



Receiver (Amplifier) Hookups

This connection is for listening to the sound through speakers connected to a receiver (amplifier such as an integrated stereo amplifier, a receiver having a built-in Dolby Pro Logic decoder, etc.). Refer to the instructions supplied with the component to be connected.
You can enjoy 5.1 channel surround sound by connecting a receiver (amplifier) with 5.1 channel inputs. See page 34.

You can enjoy surround when connecting front speakers only. You can use 3D sound imaging to create virtual rear speakers from the sound of the front speakers (L, R) without using actual rear speakers (VES: Virtual Enhanced Surround). For details, see page 34.

Required cords

Audio connecting cord (not supplied) (1)
S video cord (supplied) (1)
When connecting the cords, be sure to match the color-coded cord to the appropriate jacks on the components. Red (right) to Red and White (left) to White. Be sure to make connections firmly to avoid hum and noise.




Signal flow

10


If you have a digital component such as a receiver (amplifier) with a digital connector, DAT or MD

Connect the component via the DIGITAL OUT OPTICAL or COAXIAL connector using an optical or coaxial digital connecting cord (not supplied).
When you play a DVD, set "DIGITAL OUT" in "AUDIO SETUP" to "ON" and then set "DOLBY DIGITAL" to "D-PCM" and "DTS" to "OFF" in the setup display. (page 56)



When using an optical digital connecting cord



Take off the cap and plug in the optical digital connecting cord.



When using a coaxial digital connecting cord



Notes


- Refer to the instructions supplied with the component to be connected.
- You cannot make digital audio recordings of discs recorded in multi-channel surround format directly using an MD deck or DAT deck.

When you make the connections above, do not set "DOLBY DIGITAL" to "DOLBY DIGITAL" and "DTS" to "ON." If you do, a loud noise will suddenly come out from the speakers, affecting your ears or causing the speakers to be damaged.

If you have an audio component with a built-in DTS decoder or Dolby Digital decoder

Connect the component via the DIGITAL OUT OPTICAL or COAXIAL connector using an optical or coaxial digital connecting cord (not supplied).

- When you play a DVD or CD that are recorded in DTS format
Set "DIGITAL OUT" in "AUDIO SETUP" to "ON" and then set "DTS" to "ON" in the setup display. (page 56)
- When you play a DVD that is recorded in Dolby Digital format
Set "DIGITAL OUT" in "AUDIO SETUP" to "ON" and then set "DOLBY DIGITAL" to "DOLBY DIGITAL" in the setup display. (page 56)



Notes

- Refer to the instructions supplied with the component to be connected.
- When you do not connect an audio component with a built-in DTS decoder, do not set "DTS" to "ON."
- When you do not connect an audio component with a built-in DOLBY DIGITAL decoder, do not set "DOLBY DIGITAL" to "DOLBY DIGITAL."

Setups for the player

Some setups are necessary for the player depending on the components to be connected. Use the setup display to change the various settings. For details on using the setup display, see page 47.

- To listen to the sound through speakers connected to a receiver (amplifier) having a digital connector or to output the sound to a digital component such as a DAT or MD deck
When you play a DVD, set "DIGITAL OUT" in "AUDIO SETUP" to "ON" and then set "DOLBY DIGITAL" to "D-PCM" and "DTS" to "OFF" in the setup display. (page 56). These are the default settings.

Getting Started

11

5.1 Channel Surround Hookups

Getting Started

Some DVDs have a sound track with up to 5.1 channels recorded in Dolby® Digital (AC-3) format. Using a receiver (amplifier) having 5.1 channel inputs and the 5 (+1) speakers, you can enjoy more real audio presence in the comfort of your own home.

"5 channel" stands for the 2 front speakers (Left and Right), 2 rear speakers (Left and Right) and 1 center speaker. The "0.1 channel" (+1) stands for the subwoofer which outputs the bass.

Even if you have fewer than 5 (+1) speakers, the player distributes the output signal to the speakers appropriately. This player has VIRTUAL3D SURROUND mode.

You can use the 3D sound imaging to shift the sound of the rear speakers away from the actual speaker position (VIRTUAL REAR SHIFT) or to create 3 sets of virtual rear speakers from 1 set of actual rear speakers (VIRTUAL MULTI REAR). For details on the VIRTUAL 3D SURROUND mode, see page 34.

Speaker placement

For the best possible surround sound, we recommend the following conditions.

- Use higher performance speakers.
- Use rear and center speakers that match your front speakers in size and performance.
- All speakers should be the same distance from the listening position.
- Place the subwoofer between the front (L, R) speakers if possible.

Note

Do not place the center or rear speakers farther away from the listening position than the front speakers.

Required cords

Audio cords (not supplied)

Two for the 5.1CH OUTPUT FRONT and REAR jacks

White (L) ——— White (L)
Red (R) ——— Black

Monaural audio cords (not supplied)

Two for the 5.1CH OUTPUT CENTER and WOOFER jacks

Black ——— Red (R)

5 video cord (supplied)

One for the S VIDEO OUT jacks

———

Notes


- Do not connect the power cord to an AC outlet or press the POWER switch before completing all connections.
- The cord connectors should be fully inserted into the jacks. Loose connection may cause hum and noise.
- Jacks and plugs of the connecting cords are color-coded as follows:
Red jacks and plugs: Right audio channel
White jacks and plugs: Left audio channel
You can use either red or white cables to connect the center speaker and subwoofer.
- When you connect the component via the DIGITAL OUT OPTICAL or COAXIAL connector using an optical or coaxial digital connecting cord (not supplied), see page 11.

Setups for the player

Some setups are necessary for the player depending on the components to be connected. Use the setup display or the Control Menu display to change the various settings. For details on using the setup display, see page 47. For details on enjoying Digital Cinema Sound, see page 34.

- To enjoy Dolby Digital surround sound by connecting the player to a receiver (amplifier) with 5.1 ch inputs
Set each speaker position or distance, etc. See page 58.

Manufactured under license from Dolby Laboratories. "Dolby", "AC-3", "Pro Logic" and the double-D symbol (DD) are trademarks of Dolby Laboratories. Confidential Unpublished Works. ©1992-1997 Dolby Laboratories, Inc. All rights reserved.



Getting Started


12

13


Selecting the Language for On-Screen Display

Getting Started


You can select the language for the setup display, the Control Menu display or the messages displayed on the screen. Default setting is "ENGLISH."



- 1 Press SET UP and select "LANGUAGE SETUP" using F, and then press ENTER.



- 2 Select "OSD" using F, then press → or ENTER.



- 3 Select "FRENCH" using F, then press ENTER.



To cancel using the setup display on the way Press SET UP.

Note


The languages you can select are the ones displayed in step 2. For details, see page 50.

Playing Discs


This chapter describes how to play a DVD/CD/VIDEO CD.

Playing Discs DVD VIDEO CD

Depending on the DVD or VIDEO CD, some operations may be different or restricted. Refer to the instructions supplied with your disc.



- 1 Make settings on your TV.
Turn on the TV and select the video input so that you can view the pictures from this player.
- When using a receiver (amplifier)
Turn on the receiver (amplifier) and select the appropriate position so that you can listen to the sound from this player.
- 2 Press I/II (POWER) to turn on the player.
The indicator (red) above the I/II (POWER) button changes to green and the front panel display lights up.
- 3 Press Δ, and place the disc on the disc tray.



- 4 Press ▶.
- The disc tray closes, and the player starts playback (continuous play). Adjust the volume on the TV or the receiver (amplifier).

After following Step 4

- When playing a DVD
A DVD menu or title menu may appear on the TV screen (see page 19).
- When playing a VIDEO CD
The menu screen may appear on the TV screen depending on the VIDEO CD. You can play the disc interactively, following the instructions on the menu screen. (PBC Playback, see page 20)

Playing Discs

14



15

Playing Discs

You can turn on the player using the remote. Press I/⏻ (POWER) when the indicator above the I/⏻ (POWER) button on the front panel is lit in red.

Notes

- If you leave the player or the remote in pause or stop mode for 15 minutes, the screen saver image appears automatically. To make the screen saver image go away, press ▷. (If you want to set the screen saver function to off, see page 51.)
- The indicator above the I/⏻ (POWER) button lights up in red when the power is turned off.




To	Operation
Stop	Press ■.
Pause	Press II.
Resume play after pause	Press II or ▷.
Go to the next chapter, track or scene in continuous play mode	On the player: Turn I/⏻ / ▷ clockwise to select the chapter and then press I/⏻ / ▷. On the remote: Press I/⏻.
Go back to the preceding chapter, track or scene in continuous play mode	On the player: Turn I/⏻ / ▷ counterclockwise to select the chapter and then press I/⏻ / ▷. On the remote: Press I/⏻.
Stop play and remove the disc	Press ▲.


You can play discs in various modes such as Program Play using the on-screen menu (Control Menu). For operations of Control Menu, see page 23.

Playing at Various Speeds/Frame by Frame DVD VIDEO CD

Using the click shuttle and the JOG button/indicator, you can play back a DVD/CD/VIDEO CD at various speeds or frame by frame. Each time you press JOG, it changes between shuttle mode and jog mode.



When you play back a CD/VIDEO CD



* VIDEO CD Only

If you turn the click shuttle quickly, the playback speed goes to FF2/FR2 at once.


To return to continuous play Press ▷.

To search for the picture using the button on the remote Keep pressing ⏻ or ⏻. The playback speed is same as FR1 or FF1 when using the click shuttle.

Note Depending on the DVD/VIDEO CD, you may not be able to do some of the operations described.

To change the playback speed (Shuttle mode)

Turn the click shuttle. The playback speed changes depending on the turning direction and angle as follows:



If you turn the click shuttle quickly, the playback speed goes to FF2/FR2 at once.

16

17

Playing at Various Speeds/Frame by Frame

To play the disc frame by frame changing the playback speed (Jog mode)

- Press JOG. JOG lights up during jog mode. When you press JOG on the player, it pauses.
- Turn the click shuttle. Depending on the turning speed, the playback goes to frame-by-frame in the direction that the click shuttle is turned. If you turn the click shuttle with constant speed for a while, the playback speed goes to slow or normal.


To return to continuous play Press ▷.

Notes

- The JOG indicator shows the mode of the corresponding click shuttle. For example, when the JOG indicator on the remote is not lit, the remote click shuttle will remain in the shuttle mode even if the indicator on the player is lit.
- If you don't operate the click shuttle for about 20 seconds after pressing JOG, it returns to shuttle mode on the remote. On the player, it stays in jog mode.

Resuming Playback from the Point Where You Stopped the Disc (Resume Play) DVD VIDEO CD

The player stores the point where you stopped the disc and if "RESUME" appears on the front panel display. You can resume playback from that point. As long as you do not open the disc tray, Resume Play is available even if you turn the power off.




- While playing a disc, press ■ to stop playback. "RESUME" appears in the front panel display and "When playing next time, disc restarts from point you stopped." appears on the TV screen. If "RESUME" does not appear, Resume Play is not available.
- Press ▷. The player starts playback from the point where you stopped the disc in Step 1.

To play from the beginning of the disc When the playing time appears on the front panel display before you start playing, press ■ to reset the playing time, then press ▷.

Using the Menu for Each DVD VIDEO

Using the title menu

A DVD is divided into long sections of a picture or a music piece called "titles." When you play a DVD which contains several titles, you can select the title you want using the title menu.



- Press TITLE. The title menu appears on the TV screen. The contents of the menu vary from disc to disc.
- Press ◀/▶/⏮/⏭ to select the title you want to play. Depending on the disc, you can use the number buttons to select the title.
- Press ENTER. The player starts playing the selected title.

Notes

- Depending on the DVD, you may not be able to select the title.
- Depending on the DVD, a "title menu" may simply be called a "menu" or "title" in the instructions supplied with the disc. "Press ENTER" may also be expressed as "Press SELECT."

18

19

Using the Menu for Each DVD

Using the DVD menu

Some DVDs allow you to select the disc contents using the menu. When you play these DVDs, you can select the language for the subtitles, the language for the sound, etc., using the DVD menu.


- 1 Press DVD MENU.
The DVD menu appears on the TV screen. The contents of the menu vary from disc to disc.
- 2 Press \leftarrow/\rightarrow to select the item you want to change.
Depending on the disc, you can use the number buttons to select the item.
- 3 To change other items, repeat Step 2.
- 4 Press ENTER.

If you want to select the language for the DVD menu. Change the setting using "LANGUAGE SETUP" in the setup display. For details, see page 50.

Note
Depending on the DVD, a "DVD menu" may simply be called a "menu" in the instructions supplied with the disc.

Playing VIDEO CDs with PBC Functions (PBC Playback)

When playing VIDEO CDs with PBC functions (Ver. 2.0 discs), you can enjoy simple interactive operations, operations with search functions, etc. PBC Playback allows you to play VIDEO CDs interactively, following the menu screen on the TV screen. On this player, you can use the number buttons, ENTER, \leftarrow/\rightarrow , \uparrow/\downarrow and \square (RETURN) during PBC Playback.



- 1 Start playing a VIDEO CD with PBC functions, following Steps 1 to 4 in "Playing Discs" on page 15.
- 2 Select the item number you want.
On the player
Press \uparrow/\downarrow to select the item number.
On the remote
Press the number button of the item you want.
- 3 Press ENTER.
- 4 Follow the instructions on the menu screen for interactive operations.
Refer to the instructions supplied with the disc, as the operating procedure may differ according to the VIDEO CD.

Going back to the menu screen

Press \leftarrow/\rightarrow , \leftarrow , or \rightarrow .

If you want to return to the menu screen, press \leftarrow/\rightarrow , \leftarrow , or \rightarrow .

To cancel PBC playback of a VIDEO CD with PBC functions and play the disc in continuous play mode


- Before you start playing, select the track you want using \leftarrow/\rightarrow or \uparrow/\downarrow , then press ENTER or \square .
- Before you start playing, select the track number using the number buttons on the remote, then press ENTER or \square . "Play without PBC" appears on the TV screen and the player starts continuous play. You cannot play still pictures such as a menu screen.

Note
Depending on the VIDEO CD, "Press ENTER" in Step 3 may be expressed as "Press SELECT" in the instructions supplied with the disc.

Using the Front Panel Display


DVD VIDEO CD

You can check information about the disc, such as the total number of the titles or the tracks or remaining time, using the front panel display.



When playing back a DVD

Display information while playing the disc



Checking the remaining time

Press TIME/TEXT.


Each time you press TIME/TEXT while playing the disc, the display changes as shown in the following chart.

Using the Front Panel Display


Playing time and number of the current chapter




Press TIME/TEXT



Press TIME/TEXT



Press TIME/TEXT



Press TIME/TEXT




Press TIME/TEXT

Notes
• Depending on the DVD, the chapter number or time may not appear or you may not be able to change the front panel display.
• While you are doing Shuffle Play or Program Play, the playing time of the title and the remaining time of the title are not displayed.

When playing back a CD/VIDEO CD

Display information while playing a disc



When playing VIDEO CDs with PBC functions


The current scene number is displayed instead of the current track number and the current index number. In this case, the front panel display does not change when you press TIME/TEXT. If a TEXT or Disc Memo is recorded on the disc, the front panel display changes to "Text or Disc Memo" display when you press TIME/TEXT.

Checking the remaining time


Press TIME/TEXT.

Each time you press TIME while playing a disc, the display changes as shown in the following chart.


Playing time and number of the current track




Press TIME/TEXT



Press TIME/TEXT



Press TIME/TEXT



Press TIME/TEXT



Press TIME/TEXT

Note
While you are doing Shuffle Play, Program Play, or PBC playback, the playing time of the disc and the remaining time of the disc are not displayed.

Using Various Functions with the Control Menu


This chapter describes how to play discs in various modes and how to use the convenient features of the on-screen menu (Control Menu).

Using the Control Menu Display


DVD VIDEO CD

Using the Control Menu display, you can select the start point, label a disc, change the angles, adjust the picture, set for Digital Cinema Sound, etc.

The items are different depending on the kind of disc. For details on each Control Menu display item, see pages 26 to 46.




- 1 Press DISPLAY to show the Control Menu display on the TV screen.



Using the Control Menu Display

- Select the item you want using \uparrow/\downarrow , then press \rightarrow or ENTER.




Note

Some Control Menu display items require operations other than selecting the setting. For details on these items, see the relevant pages.

To cancel using the Control Menu display on the way
Press \rightarrow RETURN.



To display other items

Each time you press DISPLAY, the Control Menu display changes as follows:



You can display some items using the remote
Some items can be displayed by pressing the button of the remote. In this case, only the item you selected is displayed. For the item and operations using the remote, see the pages of each item.

- Select the item you want using \uparrow/\downarrow , then press ENTER.



24

Control Menu Item List

- TITLE** (DVD only) (page 26)
- CHAPTER** (DVD only) (page 26)
- TRACK** (VIDEO CD/CD only) (page 26)
- INDEX** (VIDEO CD/CD only) (page 26)
- SCENE** (VIDEO CD during PBC playback only) (page 26)

You can search by selecting the title/chapter/track/index/scene.

TIME/TEXT (page 27, 28, 29)

You can check the playing time and remaining time of the current title/chapter/track and the total remaining time of the disc.

You can search by inputting the time code. You can check the DVD TEXT or CD TEXT of the disc on the TV screen and the front panel display. When the disc is a VIDEO CD or the DVD TEXT or CD TEXT is not recorded on the disc, you can label the disc as a Disc Memo and check it.

AUDIO (page 31)

With DVDs recorded with multilingual sounds, you can select the language you want while playing the DVD. With multiplex CDs or VIDEO CDs, you can select the sound of the selected channel through both the right and left speakers.

SUBTITLE (DVD only) (page 32)

With DVDs on which multilingual subtitles are recorded, you can change the subtitle language whenever you want while playing the DVD, and turn it on or off whenever you want.

ANGLE (DVD only) (page 33)

With DVDs on which various angles (multi-angles) are recorded, you can change the angle on the scene for which multi-angles are recorded.

VIRTUAL SURROUND (page 34)

Select the mode to enjoy multi-channel surround sound such as Dolby Digital. Even if you connect only front speakers, Virtual Enhanced Surround (VES) lets you enjoy 3D sound by using 3D sound imaging to create virtual rear speakers from the sound of the front speakers (L, R) without using actual rear speakers.

When you connect 2 front speakers and 2 rear speakers, you can use the 3D sound imaging to shift the sound of the rear speakers away from the actual speaker position (VIRTUAL REAR SHIFT) or to create 3 sets of virtual rear speakers from 1 set of actual rear speakers (VIRTUAL MULTI REAR).

You can feel the more effective 3D sound when you connect a receiver (amplifier) with 5.1 channel inputs, 2 front speakers, 2 rear speakers, 1 center speaker and 1 subwoofer.

PROGRAM (page 36)

You can play the contents of the disc in the order you want by arranging the order of the titles, chapters or tracks on the disc to create your own program.

SHUFFLE (page 38)

You can have the player "shuffle" titles, chapters or tracks and play them in a random order. The playing order may differ from the previous "shuffling."

REPEAT (page 39)

You can play all the titles/tracks on a disc or a single title/chapter/track repeatedly.

SKIP (page 39)

You can play a specific portion of a title, chapter, or track repeatedly.

ADVANCED (page 41)

You can check the play information about the bit rate, bit rate history, the position where the disc is played (layer) or audio level.

DSR (DVD/VIDEO CD only) (page 43)

You can make the picture clearer by reducing the picture noise.

VIDEO IO (DVD/VIDEO CD only) (page 43)

You can adjust the video output of the DVD or VIDEO CD from the player, not from the TV, to obtain the picture quality you want.

SPECIAL FEATURES (DVD only) (page 45)

With DVDs on which various angles (multi-angles) for a scene are recorded, you can display all the angles recorded on the disc on the same screen, and start playback in continuous mode at the chosen angle directly.

Control Menu Item List

TIME/TEXT (DVD/VIDEO CD only) (page 45)

You can display 9 consecutive sections of the disc on the screen. In this case, the sections show still images.

TITLE VIEWER (DVD only) (page 46)

CHAPTER VIEWER (DVD only) (page 46)

You can check the titles, chapters and tracks of the disc on the screen divided in 9 sections, and start playback from the chosen title, chapter or track.

BOOKMARK (page 46)

You can have the player store specific portions of the disc in memory and play them immediately whenever you want without the need to search.


Searching for the Title/Chapter/Track/Index/Scene



You can search by selecting the title/chapter/track/index/scene.


Select "TITLE," "CHAPTER," "TRACK," "INDEX" or "SCENE" after pressing DISPLAY.

When you play back a DVD, "TITLE" and "CHAPTER" are displayed. When you play back a VIDEO CD/CD, "TRACK" and "INDEX" are displayed. When you play back a VIDEO CD with PBC functions, "SCENE" is displayed.




- Select "TITLE," "CHAPTER," "TRACK," "INDEX" or "SCENE" using \uparrow/\downarrow .

"**(*)*" is highlighted. (** means optional number in this manual.) Number in parentheses indicate the total number of titles, chapters, tracks or indexes.



- Press \rightarrow or ENTER.

"**(*)*" is changed to "----(*)*".



- Select the number of the title, chapter, track, index or scene you want to search for using the number buttons, then press ENTER. The player starts searching.

To cancel selecting

Press \rightarrow RETURN.

Notes


- The number of titles, chapters or tracks displayed is that of the titles, chapters or tracks recorded on a disc.
- The index numbers are not displayed during PBC playback of VIDEO CDs.

Checking the Playing Time and Remaining Time



You can check the playing time and remaining time of the current title/chapter/track and the total remaining time of the disc.

Select "TIME/TEXT" or "TIME/MEMO" after pressing DISPLAY. You can also check the DVD TEXT, CD TEXT and Disc Memo, and label the Disc Memo. See page 29.



When playing a DVD

TIME/TEXT or TIME/MEMO

- C-***:***: Remaining time of the current chapter
- T-***:***: Remaining time of the current title
- T-***:***: Remaining time of the current title

When playing a VIDEO CD (during PBC playback)

TIME/MEMO

- *-***:***: Remaining time of the current scene

When playing a VIDEO CD (in continuous play) or CD

TIME/TEXT or TIME/MEMO

- T-***:***: Remaining time of the current track
- T-***:***: Remaining time of the current track
- D-***:***: Remaining time of the current disc
- D-***:***: Remaining time of the current disc

You can display "TIME/TEXT" or "TIME/MEMO" display using the remote.

Press TIME/TEXT on the remote. Each time you press the button, the time information changes.


26

27


Changing the Sounds

The display examples are as follows:


- PCM (stereo)




- Dolby Surround



- Dolby Digital (AC-3) 5.1ch



- DTS




You can find Dolby Surround-encoded software by looking at the packaging. Use discs with the **DOLBY SURROUND** logo. In order to enjoy Dolby Digital (AC-3) playback, you must use discs bearing this logo.

Displaying the Subtitles



With DVDs on which subtitles are recorded, you can turn the subtitles on and off whenever you want while playing the DVD. With DVDs on which multilingual subtitles are recorded, you can change the subtitle language whenever you want while playing the DVD, and turn it on or off whenever you want. For example, you can select the language you want to master and turn the subtitles on for better understanding. Select "SUBTITLE" after pressing DISPLAY.



SUBTITLE

Select the language. The languages you can select are different depending on the DVD. When 4 digits are displayed, they indicate the language code. Select the language code from the list on page 69.

You can display the "SUBTITLE" display by using the remote. Press SUBTITLE on the remote. Each time you press the button, the item changes.


Notes

- When playing a DVD on which no subtitles are recorded, no subtitles appear.
- Depending on the DVD, you may not be able to turn the subtitles on even if they are recorded on it.
- Depending on the DVD, you may not be able to turn the subtitles off.
- If the language is displayed as a 4-digit number, refer to the language code list on page 69.
- The type and number of languages for subtitles vary from disc to disc.
- Depending on the DVD, you may not be able to change the subtitles even if multilingual subtitles are recorded on it.
- While playing the DVD, the subtitle may change when:
 - you open or close the disc tray
 - you change the title


Changing the Angles



With DVDs on which various angles (multi-angles) for a scene are recorded, you can change the angles. For example, while playing a scene of a train in motion, you can display the view from either the front of the train, the left window of the train or from the right window without having the train's movement interrupted. Select "ANGLE" after pressing DISPLAY. When the angles can be changed, the indicator of the "ANGLE" lights in green.




1 Select "ANGLE."




2 Press →.

The number of the angle is highlighted. The number in parentheses indicates the total number of angles.



- 3 Select the number of the angles using the number buttons, then press ENTER. The angle is changed to the selected angle.



Notes

- The number of angles varies from disc to disc or from scene to scene. The number of angles that can be changed on a scene is that of angles recorded for that scene.
- Depending on the DVD, you may not be able to change the angles even if multi-angles are recorded on the DVD.

You can specify the angle beforehand.

Specify the angle when "ANGLE" is not displayed on the front panel display. When a scene on which multi-angles are recorded comes, the angle is automatically selected.

You can select the angle using the remote.

Press ANGLE on the remote. Each time you press the button, the angle changes.

You can display different angles simultaneously (ANGLE VIEWER).

You can display all the angles recorded on the disc on the same screen, and start playback in continuous mode from the chosen angle directly. The angles are displayed on a screen divided in 9 sections. For details, see page 45.

Setting for Digital Cinema Sound



Select the mode to enjoy multi-channel surround sound such as Dolby Digital. Even if you connect only front speakers, Virtual Enhanced Surround lets you enjoy 3D sound by using 3D sound imaging to create virtual rear speakers from the sound of the front speakers (L, R) without using actual rear speakers.

When you connect 2 front speakers and 2 rear speakers, use 3D sound imaging to shift the sound of the rear speakers away from the actual speaker position.


(VIRTUAL REAR SHIFT) or to create 3 sets of virtual rear speakers from 1 set of actual rear speakers (VIRTUAL MULTI REAR).

You can feel the more effective 3D sound when you connect a receiver (amplifier) with 5.1 channel inputs, 2 front speakers, 2 rear speakers, 1 center speaker and 1 subwoofer.

Select "VIRTUAL 3D SURROUND" after pressing DISPLAY. When you select the item except "OFF," the indicator of the "VIRTUAL 3D SURROUND" lights in green.

Note

To enjoy the original Dolby Digital (AC-3) sound through the 5.1 CH OUTPUT connectors, set each speaker position or distance, etc. For details on setting each speaker, see page 58.



VIRTUAL 3D SURROUND

Select the desired item. For details on each item, see "Effects of each item."

- OFF
- VES A*
- VES B*
- NORMAL SURROUND
- ENHANCED SURROUND
- VIRTUAL REAR SHIFT
- VIRTUAL MULTI REAR

* These settings also effect the output from the LINE OUT (AUDIO 1, 2) connectors.

Note

The items displayed are different depending on the settings of "SPEAKER SETUP" (page 58).

- You can select only "OFF," "VES A" or "VES B" when you play back a DVD and set "NONE" in "REAR" in "SIZE" under "SPEAKER SETUP" in the set up display.
- "VIRTUAL 3D SURROUND" is not displayed when you play back a VIDEO CD or CD and set "NONE" in "REAR" in "SIZE" under "SPEAKER SETUP" in the set up display.

Effects of each item

OFF
Outputs all channel signals recorded on the disc. For example, outputs 2-channel signals for stereo sound of the CD or 5-channel signals for Dolby Digital sound of the DVD. When you connect fewer than 5 (+1) speakers, the player distributes the output signal for the missing speaker to other speakers appropriately.

VES (Virtual Enhanced Surround) A

Uses 3D sound imaging to create virtual rear speakers from the sound of the front speakers (L, R) without using actual rear speakers. The virtual speakers are reproduced as shown in the illustration below.



VES (Virtual Enhanced Surround) B

Uses 3D sound imaging to create virtual rear speakers from the sound of the front speakers (L, R) without using actual rear speakers. The virtual speakers are reproduced as shown in the illustration below.



NORMAL SURROUND


Software with 2 channel audio signals, is decoded with Dolby Pro Logic to create surround effects.

ENHANCED SURROUND

Provides a greater sense of presence from Pro Logic source with monaural rear channel sound. Produces a stereo like effect in the rear channels.


VIRTUAL REAR SHIFT

Uses 3D sound imaging to shift the sound of the rear speakers away from the actual speaker position. The virtual speakers are reproduced as shown in the illustration below. The shift position differs according to the setting of the rear speaker position.



VIRTUAL MULTI REAR

Uses 3D sound imaging to create an array of virtual rear speakers from a single pair of actual rear speakers. The virtual speakers are reproduced as shown in the illustration below. The position of the virtual rear speakers differs according to the setting of the rear speaker position.



* See page 58 for details on how to set the rear speaker position.

- L: Front speaker (left)
- R: Front speaker (right)
- SL: Rear speaker (left)
- SR: Rear speaker (right)
- : Virtual speaker

Notes


- Each item of "VIRTUAL 3D SURROUND" (except "NORMAL SURROUND" and "ENHANCED SURROUND") is effective on only discs on which a multi-channel soundtrack is recorded. Some discs do not have rear sound. In this case, you cannot get the 3D surround effect.
- When you select an item, the sound cuts off for a moment.
- When the playing signal does not contain the surround component, the effects may be difficult to hear even if you select "VES A" or "VES B."
- If you connect the front speakers only, "NORMAL SURROUND," "ENHANCED SURROUND," "VIRTUAL REAR SHIFT" and "VIRTUAL MULTI REAR" cannot be selected.
- Set the front speakers to form an equilateral triangle including the listening position, or the effects may be difficult to hear even if you select "VES A" or "VES B."
- When you select "VES A" or "VES B," the player outputs the audio signal from LINE OUT, DIGITAL OUT (OPTICAL, COAXIAL) or 5.1CH OUTPUT FRONT connectors. In case of the signal from DIGITAL OUT (OPTICAL, COAXIAL), however, the surround effect will be heard only when you play DVD or VIDEO CD with "DOLBY DIGITAL" in "AUDIO SETUP" set to "D-PCM."
- When you play sound tracks with 96 kHz sampling frequency, be sure to select "OFF" or the output signals will be converted to 48 kHz (sampling frequency).
- When you connect a center speaker and a subwoofer, you can also hear the sound from the center speaker and the subwoofer. When you select "VES A" or "VES B," the player does not output the sound from the center speaker.

You can select the item of "VIRTUAL 3D SURROUND" using this button. Press VIRTUAL 3D SURROUND on the player. Each time you press the button, the item changes.

Creating Your Own Program (Program Play)



You can play the contents of the disc in the order you want by arranging the order of the titles, chapters or tracks on the disc and create your own program. One program can be restored in the player and contain up to 99 titles, chapters and tracks. Select "PROGRAM" after pressing DISPLAY. When you select "ON", the indicator of the "PROGRAM" lights in green.




PROGRAM

- Q/E: plays normal.
- SET: allows you to create your own program.
- ON: plays Program Play.


Creating the program

- 1 Select "SET" in "PROGRAM". The programming display appears.

"TRACK" is displayed when you play a VIDEO CD or a CD.




- 2 Press →. "01" is highlighted. It is ready to set the first title or track for program.







- 3 Select the title, chapter or track you want to program using 1/4, then press ENTER. For example, select title or track 2. (You can also use the number buttons and ENTER button to select. In this case, the selected number is displayed on the screen.)

When playing a DVD

When both titles and chapters are recorded on the disc, select the title, then the chapter.



- When playing a VIDEO CD or CD. Select the track you want to program.



- 4 To program other titles, chapters or tracks, repeat Step 3. The programmed titles, chapters or tracks are displayed from 2 in order.

- 5 Press → to start Program Play.

To cancel Program Play
Press CLEAR.

To cancel programming
Press PROGRAM.

To change programming

- 1 In Step 2, select the program number of the title, chapter or track you want to change using 1/4.
- 2 Follow Step 3 for new programming.

To cancel the programmed order

To cancel all the titles, chapters or tracks in the programmed order, select "ALL CLEAR" in Step 2. To cancel the selected program, select the program using 1/4 in Step 2 then press CLEAR, or select "-" in Step 3 then press ENTER.

The program remains even after the Program Play ends. When you press →, you can play the same program again.

You can do Repeat Play or Shuffle Play of the programmed titles, chapters or tracks. During Program Play, press REPEAT or SHUFFLE. Or set "REPEAT" or "SHUFFLE" to "ON" in the Control Menu display.

You can display "PROGRAM" display using the remote. Press PROGRAM.


Notes

- The number of titles, chapters or tracks displayed are that of the titles, chapters or tracks recorded on a disc.
- The program is canceled when:
 - you open or close the disc tray
 - you turn the power off
- You may not be able to do Program Play depending on the DVD.
- While you are doing PBC playback, you cannot set a program unless you stop playback once.

Playing in Random Order (Shuffle Play)



You can have the player "shuffle" titles or tracks and play them in a random order. The playing order may differ from the previous "shuffling." Select "SHUFFLE" after pressing DISPLAY. When you select "ON", the indicator of the "SHUFFLE" lights in green.



SHUFFLE

Selects the setting of Shuffle Play.

When playing a DVD and when Program Play is set to OFF

- OFF: does not play a disc in random order.
- TITLE: has the player "shuffle" titles and play in a random order.
- CHAPTER: has the player "shuffle" chapters and play in a random order.

When playing a VIDEO CD, CD or DVD (when Program Play is set to ON)

- OFF: does not play a disc in random order.
- ON: has the player "shuffle" titles or tracks and play in a random order.

When playing a VIDEO CD or CD (when Program Play is set to OFF)

- OFF: does not play a disc in random order.
- TRACK: has the player "shuffle" tracks and play in a random order.

After selecting the item of "SHUFFLE", press →. The player starts Shuffle Play.

To cancel Shuffle Play
Press CLEAR.

You can display the "SHUFFLE" display by pressing the button. Press SHUFFLE.

Notes

- Shuffle Play is canceled when:
 - you open or close the disc tray
 - you turn the power off
- You may not be able to do Shuffle Play depending on the DVD.
- Up to 200 chapters in a disc can be played in a random order when "CHAPTER" is selected.


Playing Repeatedly (Repeat Play)



You can play all the titles/tracks on a disc or a single title/chapter/track.

In Shuffle or Program Play mode, the player repeats the titles or tracks in the shuffled or programmed order. You cannot do Repeat Play during PBC playback of VIDEO CDs (page 20).

You may not be able to do Repeat Play depending on the DVD. Select "REPEAT" after pressing DISPLAY. When you select "ON", the indicator of the "REPEAT" lights in green.



REPEAT

Selects the setting of Repeat Play.

When playing a DVD and when Program Play and Shuffle Play are set to OFF

- OFF: does not play repeatedly.
- DISC: repeats all the titles.
- TITLE: repeats the current title on a disc.
- CHAPTER: repeats the current chapter.

When playing a VIDEO CD/CD and when Program Play and Shuffle Play are set to OFF

- OFF: does not play repeatedly.
- DISC: repeats all the tracks on a disc.
- TRACK: repeats the current track.

When Program Play or Shuffle Play is set to ON

- OFF: does not play repeatedly.
- ON: repeats Program Play or Shuffle Play.

To cancel Repeat Play
Press CLEAR.

You can display the "REPEAT" display by pressing the button. Press REPEAT.

Notes

Repeat play is canceled when you turn the power off.


Repeating a Specific Portion (A→B Repeat)



You can play a specific portion of a title, chapter, track repeatedly. This is useful when you want to memorize lyrics.

During PBC playback of VIDEO CDs (page 20), this function is available only while playing moving pictures. You may not be able to do A→B Repeat Play depending on the DVD.

Select "A-B REPEAT" after pressing DISPLAY. During A→B Repeat Play, the indicator of the "A-B REPEAT" lights in green.



A-B REPEAT



• SET: sets the A and B points.

- OFF: does not play a specific portion of a title/chapter/track repeatedly.


Repeating a Specific Portion (A→B Repeat)

Setting a portion for A→B repeat


- 1 Select "SET→" in "A-B REPEAT."
The A→B REPEAT setting display appears.



- 2 During playback, when you find the starting point (point A) of the portion to be played repeatedly, press ENTER.
The starting point (point A) is set.



- 3 When you reach the ending point (point B), press ENTER again.
The setting points are displayed and the player starts repeating this specific portion.
"A-B" appears on the front panel display during A→B repeat play.



To cancel A→B Repeat Play

Press CLEAR.


Notes

- You can set A→B Repeat on only one specific portion.
- A→B Repeat is canceled when:
 - you open or close the disc tray
 - you turn the power off
- When you set A→B Repeat, the settings for Shuffle Play and Program Play are canceled.
- You may not be able to set A→B Repeat, depending on the scene of the DVD or the VIDEO CD.

Checking the Play Information

You can check the play information on the bit rate, bit rate history, the portion where the disc is played (layer) or audio level.

While playing a disc, the approximate bit rate of the playback picture is always displayed by Mbps (Mega bit per second) and the audio by Kbps (Kilo bit per second). Select "ADVANCED" after pressing DISPLAY.



ADVANCED

When playing a DVD

- BIT RATE: displays bit rate.
- BIT RATE HISTORY: displays bit rate and bit rate history.
- LAYER: displays layer and the point picked up.
- AUDIO LEVEL: displays audio level of each output.
- OFF: turns off ADVANCED display.


When playing a VIDEO CD/CD

- AUDIO LEVEL: displays audio level of each output.
- OFF: turns off ADVANCED display.

You can display the ADVANCED display directly.
Press DISPLAY until the the ADVANCED display appears.


Displays of each item

BIT RATE



Bit rate refers to the amount of video/audio data per second in a disc. The higher the bit rate is, the larger the amount of data. When the bit rate level is high, there is a large amount of data. However, this does not always mean that you can get higher quality pictures or sounds.

BIT RATE HISTORY



Indicates the transition of bit rate of the playback picture for a period up to the present.

Checking the Play Information

LAYER




Indicates where the disc is played. When the DVD has dual-layer, the player indicates which layer is being read. For details on layer, see page 67.

Reducing the Picture Noise (DNR: Digital Noise Reduction)

You can make the picture cleaner by reducing the picture noise of the background.

Select "DNR" after pressing DISPLAY.
When you select "DNR1," "DNR2," or "DNR3," the indicator of the "DNR" lights in green.



DNR

As the value increases, the picture noise will be reduced. However, afterimages may increase.

- OFF: turns off the DNR function
- DNR1
- DNR2
- DNR3

Notes


- Depending on the disc, the effect may be difficult to tell.
- If the afterimages appear on the TV screen, set the noise reduction function to off on your TV. Then set "DNR" to "OFF" on the Control Menu display.

Adjustments for Playback Picture (VIDEO EQ: Video Equalizer)

You can adjust the video output of the DVD or VIDEO CD from the player, not from the TV, to obtain the picture quality you want. Choose one of the video modes whichever best suits the program you are watching.

When you select "MEMORY→" in a menu item, adjust the value.

Select "VIDEO EQ" after pressing DISPLAY.



VIDEO EQ

Selects the setting of video control.

- STANDARD: displays a standard picture
- DYNAMIC: emphasizes the black level and so produces a bolder dynamic picture
- CINEMA: displays a finely detailed picture
- MEMORY→: adjusts the picture items

To adjust the picture items



You can adjust the following picture items individually.

- PICTURE
- BRIGHTNESS
- COLOR
- SHARPNESS


Adjustments for Playback Picture (VIDEO EQ: Video Equalizer)

- 1 Select "MEMORY" in "VIDEO EQ."


The video control display appears.



- 2 Select the picture item you want to adjust using \uparrow/\downarrow , then press ENTER. The adjustment bar of the selected item appears. To cancel adjusting the picture halfway, press \rightarrow RETURN.



- 3 Adjust the selected picture item using \leftarrow/\rightarrow , then press ENTER.



- 4 To adjust other items, repeat Steps 2 and 3.


To cancel adjusting the picture Press \rightarrow RETURN.

To reset the picture items Select "STANDARD" in "MEMORY."

Note Only one setting of the picture items you adjusted in "MEMORY" can be stored. When you adjust the items, new setting erases the setting adjusted before.

Displaying Different Angles Simultaneously

With DVDs on which various angles (multi-angles) for a scene are recorded, you can display all the angles recorded on the disc on the same screen, and start playback in continuous mode at the chosen angle directly. The angles are displayed on a screen divided in 9 sections. Select "ANGLE VIEWER" after pressing DISPLAY. When you can select "ANGLE VIEWER", the indicator of the "ANGLE VIEWER" lights in green.



To select the one angle Select the angle using $\leftarrow/\uparrow/\downarrow/\rightarrow$, then press ENTER. The selected angle only is displayed.


To cancel displaying multi-angles Press \rightarrow RETURN.

You can check the number on the front panel display. The number of the angle you select is displayed on the front panel display.

Notes
• Depending on the DVD, you may not be able to change the angles even if multi-angles are recorded on the DVD.
• When a scene for which various angles (multi-angles) are not recorded comes while displaying different angles simultaneously, the player returns to the normal play.

Dividing a Track into 9 Sections (Strobe Play)

You can display 9 consecutive sections of the disc on the screen. In this case, the sections show still images. Select "STROBE PLAYBACK" after pressing DISPLAY.



To cancel watching the strobe play Press \rightarrow RETURN.

During pause mode, 9 still images around the pause position are displayed. It is convenient to see the still images around the specific portion.


Note Depending on the disc, there are some scenes you may not be able to watch with the strobe play.

Using Various Functions with the Control Menu

Using Various Functions with the Control Menu


Scanning the Title, Chapter and Track

You can check the top picture of titles, chapters and tracks of the disc on a screen divided in 9 sections, and start playback from the chosen title, chapter or track. Select "TITLE VIEWER" (DVD only), "CHAPTER VIEWER" (DVD only) or "TRACK VIEWER" (VIDEO CD only) after pressing DISPLAY.



To start playback from the selected picture Select the picture using $\leftarrow/\uparrow/\downarrow/\rightarrow$, then press ENTER. The playback starts from the selected picture.

When there are over 9 titles or chapters ∇ appears at the right bottom of the screen. Use \downarrow to scroll and display next titles or chapters.




You can check the number on the front panel display. The number of the title, chapter and track you select is displayed on the front panel display.

To cancel scanning the title, chapter and track Press \rightarrow RETURN.

Notes
• Depending on the disc, you may not be able to scan the title, chapter and track.
• You cannot scan the title, chapter and track on a VIDEO CD during PBC playback.

Setting and Selecting Favorite Scene (Bookmark)

You can have the player store specific portions of the disc in memory and play them immediately whenever you want without the need to search (Bookmark). Up to 9 bookmarks per disc for up to 200 discs can be stored in memory. Select "BOOKMARK" after pressing DISPLAY. When you play the disc which has bookmarks, the indicator of the "BOOKMARK" lights in green.



To start playback from the selected picture Select the picture using $\leftarrow/\uparrow/\downarrow/\rightarrow$, then press ENTER. The playback starts from the selected picture.

To cancel scanning the bookmark pictures Press \rightarrow RETURN.

To reset the bookmark Select the point on which you want to reset the bookmark using $\leftarrow/\uparrow/\downarrow/\rightarrow$, then press CLEAR.

To reset the all bookmarks of the player Select "BOOKMARK RESET" under the "CUSTOM SETUP" in the setup display. For details on resetting all the bookmark: of the player, see page 52.

Setting the bookmark

During playback, when you find the scene to be bookmarked, press BOOK MARK on the remote. The bookmark is set.




Settings and Adjustments

This chapter describes how to set and how to adjust using the on-screen SET UP menu. Most settings and adjustments are required to be set when you first use the player. This chapter also describes how to set the remote for controlling the TV or the AV receiver (amplifier).


Using the Setup Display

Using the setup display, you can do the initial setup, adjusting the picture and sound quality, setting the various outputs, etc. You can also set a language for the subtitles and the setup display, limit playback by children, etc. For details on each setup display item, see pages 50 to 61.

Note You can display the setup display only when the player is in stop mode.



- 1 Press SET UP to display the setup display on the TV screen.





To set, press $\leftarrow/\uparrow/\downarrow/\rightarrow$. To quit, press \rightarrow .

Using Various Functions with the Control Menu


Using Various Functions with the Control Menu

Using the Setup Display



- Select the main item you want using \uparrow/\downarrow , and then press ENTER.
The selected main item is highlighted.



- Select the item you want using \uparrow/\downarrow , then press \rightarrow or ENTER.



- Select the setting you want using \leftarrow/\rightarrow , then press ENTER.






- To cancel using the setup display on the way Press SET UP on the remote.

Note
Some setup display items require operations other than selecting the setting. For details on these items, see the relevant pages.

Setup Display Item List


Default settings are underlined.



Setting the Language for Display and Sound (LANGUAGE SETUP)

Select "LANGUAGE SETUP" after pressing SET UP. "LANGUAGE SETUP" allows you to set various languages for on-screen display or sound. Default settings are underlined.

Note
When you select a language that is not recorded on the DVD, one of the recorded languages is automatically selected except for the "OSD".



■ OSD (On-Screen Display)

Switches the language for the on-screen display.

- ENGLISH
- FRENCH
- SPANISH
- PORTUGUESE

■ DVD MENU

Switches the language for the DVD menu.

- ENGLISH
- FRENCH
- SPANISH
- PORTUGUESE
- GERMAN
- ITALIAN
- DUTCH
- CHINESE
- JAPANESE
- DANISH
- SWEDISH
- FINNISH
- NORWEGIAN
- RUSSIAN
- OTHERS

When you select "OTHERS", select and enter the language code from the list using the number buttons (page 69). After you have once selected, the language code (4 digits) is displayed.

■ AUDIO

Switches the language for the sounds.

- ORIGINAL: the language given priority in the disc
- ENGLISH
- FRENCH
- SPANISH
- PORTUGUESE
- GERMAN
- ITALIAN
- DUTCH
- CHINESE
- JAPANESE
- DANISH
- SWEDISH
- FINNISH
- NORWEGIAN
- RUSSIAN
- OTHERS

When you select "OTHERS", select and enter the language code from the list using the number buttons (page 69). After you have once selected, the language code (4 digits) is displayed.

■ SUBTITLE

Switches the language for the subtitles.

- AUDIO FOLLOW
- ENGLISH
- FRENCH
- SPANISH
- PORTUGUESE
- GERMAN
- ITALIAN
- DUTCH
- CHINESE
- JAPANESE
- DANISH
- SWEDISH
- FINNISH
- NORWEGIAN
- RUSSIAN
- OTHERS


When you select "OTHERS", select and enter the language code from the list using the number buttons (page 69). After you have once selected, the language code (4 digits) is displayed.

When you select "AUDIO FOLLOW," the language for the subtitles changes according to the language for the setting you selected in "AUDIO."

Note
The player gives priority to the settings of "SUBTITLE" and "AUDIO" in the Control Menu display when "PLA" BACK MEMORY" is set to "ON." The settings of "SUBTITLE" and "AUDIO" selected in the setup display may not appear in this case. For details on the Playback Memory function, see page 53.

Settings for Display (SCREEN SETUP)


Select "SCREEN SETUP" after pressing SET UP. "SCREEN SETUP" allows you to set the display according to the playback conditions. Default settings are underlined.



■ TV TYPE

Selects the aspect ratio of the TV to be connected.

- 4:3 LETTER BOX: when you connect a normal TV to the player. Displays a wide picture with bands displayed on the upper and lower portions of the screen.
- 4:3 PAN SCAN: when you connect a normal TV to the player. Displays the wide picture on the whole screen with a portion automatically cut off.
- 16:9/4:3 WIDE MODE: when you connect a wide-screen TV to the player or when you connect a TV with WIDE MODE function to the player (displays a wide picture with bands displayed on the upper and lower portions of the screen).



Note
Depending on the DVD, "4:3 LETTER BOX" may be selected automatically instead of "4:3 PAN SCAN" and vice versa.

■ SCREEN SAVER

Turns on and off the screen saver. If you turn on the screen saver, the screen saver image appears when you leave the player or the remote in pause or stop mode for 15 minutes or when you play back a CD for more than 15 minutes. The screen saver is useful to prevent your display from becoming damaged.

- ON: turns on the screen saver.
- OFF: turns off the screen saver.

■ BACKGROUND

Selects the background color or picture of the TV screen in stop mode or while playing a CD.

- JACKET PICTURE: The jacket picture appears in the background, but only when the jacket picture is already recorded on the disc.
- PICTURE MEMORY: Your favorite picture appears in the background when you have the player store in memory your favorite scene recorded on the disc for the background picture. For the way of storing in memory, see "Storing the picture in memory."
- GRAPHICS: The graphic picture stored in memory in the player beforehand appears in the background.
- BLUE: The background color is blue.
- BLACK: The background color is black.

■ STARTUP SCREEN

Selects the startup screen. The startup screen image you selected appears when you turn on the player.


- STANDARD: The standard startup screen memorized in the player beforehand appears.
- PICTURE MEMORY: Your favorite picture appears in the startup screen when you have the player store in memory your favorite scene recorded on the disc for the startup screen. For the way of storing in memory, see "Storing the picture in memory" (page 52).

Settings for Display (SCREEN SETUP)

Storing the picture in memory

During playback, when you find the scene to be stored in memory, press PICTURE MEMORY on the remote.

The picture is stored in memory.




Notes

- The player can store in memory only one scene. The stored picture appears in both the background and the startup screen.
- When the picture is stored in memory by pressing PICTURE MEMORY, the picture stored before is not retained in memory.

Custom Settings (CUSTOM SETUP)

Select "CUSTOM SETUP" after pressing SET UP. "CUSTOM SETUP" allows you to set the playback conditions.

Default settings are underlined.



AUTO PLAY

Selects the setting of Auto Play when you connect the AC power cord to the AC outlet.

- QEE: Does not use "TIMER," "DEMO1" or "DEMO2" to start playing.
- TIMER: Starts playing a disc automatically when you connect the AC power cord to the AC outlet. By connecting a timer (not supplied), you can start playing at any time you want.
- DEMO1: Starts playing the demonstration 1 automatically.
- DEMO2: Starts playing the demonstration 2 automatically.

DIMMER

Adjusts the lighting of the front panel display.

- BRIGHT: makes the front panel display bright.
- DARK: makes the front panel display dark.
- OFF: turns off the lighting of the front panel display.

PAUSE MODE

Selects the picture in pause mode.

- AUTO: A picture including subjects that move dynamically is output with no jitter. Normally select this position.
- FRAME: A picture including subjects that do not move dynamically is output with high resolution.

BOOKMARK RESET

Select "BOOKMARK RESET" The BOOKMARK reset display appears. And then press ENTER to reset all bookmarks.

PARENTAL CONTROL

Sets a password and playback limitation level when you play DVDs with playback limitation for children. For details, see "Limiting Playback by Children (Parental Control)."

PLAYBACK MEMORY

You can have the player store the settings of SUBTITLE and VIDEO EQ, etc., of each disc up to 200 discs. (Playback Memory)

Set the Playback Memory function on or off.

- ON: stores the settings in memory when you eject the disc.
- OFF: does not store the settings in memory.

Following settings are stored in memory with the Playback Memory function.


- AUDIO (page 31)
- SUBTITLE (page 32)
- ANGLE (page 33)
- VIRTUAL 3D SURROUND (page 34)
- VIDEO EQ (page 43)
- DNR (page 43)

Note


The player can store in memory the settings of up to 200 discs. When you have the player store over 200 discs in memory, each new setting erases the setting from those first stored.

Limiting Playback by Children (Parental Control)


Select "CUSTOM SETUP" after pressing SET UP. Playing some DVDs can be limited depending on the age of users. The "Parental Control" function allows you to set a playback limitation level.




1 Select "PARENTAL CONTROL" using \uparrow/\downarrow , then press ENTER.




■ When you have not entered a password yet
The display for entering a password appears.




■ When you have already entered a password
The display for confirming the password appears. Skip Step 2.



2 Enter a password in 4 digits using the number buttons, then press ENTER. The digits change to asterisks (*), and the display for confirming the password appears.




3 To confirm your password, enter it using the number buttons, then press ENTER. The display for setting the playback limitation level and changing the password appears.




Custom Settings (CUSTOM SETUP)


4 Select "STANDARD" using \uparrow/\downarrow , then press \rightarrow .




5 Select an area as the standard for playback limitation level using \uparrow/\downarrow , then press \rightarrow . When you select "OTHERS", select and enter the standard code in the table below using number buttons.



6 Select "LEVEL" using \uparrow/\downarrow , then press \rightarrow .



7 Select the level you want using \uparrow/\downarrow , then press ENTER.



The lower the value is, the more strict the limitation.

To return to the normal screen
Press SET UP.

To turn off the Parental Control function and play the DVD after entering your password
Set "LEVEL" to "OFF" in Step 7, then press \rightarrow .

To change the password

1 After Step 3, select "CHANGE PASSWORD" using \uparrow/\downarrow , then press \rightarrow or ENTER. The display for changing the password appears.

2 Follow Steps 2 and 3 to enter a new password.

■ You can turn off the Parental Control function just after inserting the DVD (Parental Control Temporarily Cancelled). When you set a playback limitation level and insert the DVD, the PARENTAL CONTROL display appears. Enter the password to turn off the Parental Control function. When you stop playing the DVD, the level returns to the original level.

■ If you have forgot your password

Enter the 6 digits number "199703" in Step 2 to clear the current password. To enter a new password, follow the procedure from Step 2 again.

Notes


- When you play DVDs which do not have the Parental Control function, playback cannot be limited on this player.
- When you do not set a password, you cannot change the settings for playback limitation.
- Depending on the DVD, you may be asked to change the parental control level while playing the disc. In this case, enter the password, then change the level. When you stop playing the DVD, the level returns to the original level.

Standard	Code number
Austria	2046
Belgium	2057
Canada	3079
China	3092
Denmark	2115
Finland	2165
France	2174
Germany	2109
Hong Kong	2219
Indonesia	2208
Italy	2254
Japan	2276
Malaysia	2363
Netherlands	2376
Norway	2309
Philippines	2424
Russian	2485
Singapore	2501
Spain	2149
Sweden	2499
Switzerland	2086
Taiwan	2543
Thailand	2538
United Kingdom	2104

Settings for Sound (AUDIO SETUP)

Select "AUDIO SETUP" after pressing SET UP. "AUDIO SETUP" allows you to set the sound according to the playback conditions.

Default settings are underlined.



AUDIO ATT (attenuation)

Selects the setting of the output from the LINE OUT (AUDIO 1, 2) and S.I. OUTPUT connectors according to the audio equipment to be connected.

- QEE: turns off the audio attenuation.
- ON: reduces the audio output level so that no sound distortion occurs.

Note

The setting does not affect the output from the DIGITAL OUT OPTICAL and COAXIAL connectors.

AUDIO FILTER

Selects the type of digital filter to reduce the noise of a frequency higher than 22.05kHz (fs 44.1kHz), 24kHz (fs 48kHz) or 48kHz (fs 96kHz).

- SHARP: makes the sound clear and provides smooth sound reproduction. Normally set this position.
- SLOW: makes the sound warm and deep.

Note

Depending on the disc, the effect on the sound may be difficult to hear.

Settings for Sound (AUDIO SETUP)

■AUDIO DRC (Dynamic Range Control)

Makes the sound clear with the volume turned down at night, etc., when you play a DVD. This affects the output from the DIGITAL OUT connectors only when "PCM" in "DIGITAL OUT" is set to "ON," and it affects the output from the LINE OUT (AUDIO 1,2), and 5.1CH OUTPUT connectors.

- **STANDARD:** Normally select this position.
- **TY MODE:** makes the low sound clear even if you turned the volume down, so it is good for playing at night. It is especially recommended when you listen to the sound using the speakers of the TV.
- **WIDE RANGE:** It gives you the feeling of being at a live performance. When you use high quality speakers, it is more effective.

Notes

- When you play DVDs without the AUDIO DRC function, the effect on the sound may be difficult to hear.
- When this item is set to "WIDE RANGE," the sound volume from other than the 5.1CH OUTPUT connectors may be less than usual.
- "WIDE RANGE" cannot be selected when you have selected "NONE" in "SIZE" under "SPEAKER SETUP."

■TRACK SELECTION

Gives the sound track which contains the highest number of the channels priority when you play a DVD on which multiple audio formats are recorded. If multiple audio channels are recorded in PCM, DTS or Dolby Digital (AC-3) format, the higher-numbered channel audio recorded in PCM, DTS or Dolby Digital (AC-3) format is played.

- **QEE:** No priority given.
- **AUTO:** Priority given.

Notes

- When the player stores the settings in memory with the Playback Memory function, the player may not give priority even if you select "AUTO."
- When you set this item to "AUTO," the language may change depending on the "AUDIO" settings in "LANGUAGE SETUP." The "TRACK SELECTION" setting has higher priority than that of "AUDIO" settings in "LANGUAGE SETUP" (page 50).
- If you set "DTS" in "AUDIO SETUP" to "OFF," the DTS sound track is not played even if you set this item to "AUTO" and the highest-numbered channel audio is recorded in DTS format.
- If PCM, DTS and Dolby Digital (AC-3) sound tracks have the same number of the highest channels, the player selects PCM, DTS and Dolby Digital (AC-3) sound tracks, in this order.
- Depending on the DVD, the audio with priority may be predetermined. In this case, you cannot give priority to the DTS or Dolby Digital (AC-3) format by selecting "AUTO."

■DOWNMIX*

Switches the mixing down methods when you play a DVD on which the sound in Dolby Digital (AC-3) format is recorded.

- **DOLBY SURROUND:** when the player is connected to an audio component that conforms to Dolby surround. (Pro Logic)
- **NORMAL:** when the player is connected to a normal audio component.

- The setting affects the following connectors:
—LINE OUT (AUDIO 1, 2) connectors
—DIGITAL OUT (OPTICAL, COAXIAL) connectors.

■DIGITAL OUT

Selects output signals via the DIGITAL OUT OPTICAL and COAXIAL connectors.

- **ON:** Normally select this position. When you select "ON," set "DOLBY DIGITAL" and "DTS." For details on setting them, see "Setting for the Signal to the Digital Output."
- **OFF:** when the player does not output the sound signals via DIGITAL OUT OPTICAL and COAXIAL connectors, if you select this position, the influence of the digital circuit upon the analog one is minimum.


Notes

- When you play the sound tracks with 96 kHz sampling frequency, the output signals from the DIGITAL OUT (OPTICAL, COAXIAL) are converted to 48 kHz (sampling frequency). Sampling frequency stays at 96 kHz only when the signals are output from LINE OUT (AUDIO 1, 2) connectors.
- When you select "OFF," you cannot set "DOLBY DIGITAL" and "DTS."

Setting for the Signal to the Digital Output

When you select "ON," set "DOLBY DIGITAL" and "DTS."

Switches the methods of outputting audio signals when you connect a digital component such as a receiver (amplifier) having a digital connector, an audio component having a built-in DTS decoder, a DAT or MD via the DIGITAL OUT OPTICAL or COAXIAL connector using an optical or coaxial digital connecting cord. For details on the connection, see page 11.



■DOLBY DIGITAL

Selects output Dolby Digital (AC-3) signals via the DIGITAL OUT OPTICAL and COAXIAL connectors. You cannot select this item when you set "DIGITAL OUT" to "OFF."

- **D-PCM (Downmix PCM):** when you play the Dolby Digital (AC-3) sound tracks, the output audio signals are mixed down to 2 channels. With the settings of the item "DOWNMIX" in "AUDIO SETUP," you can select whether the signals conform to Dolby surround (Pro Logic) or not.
- **DOLBY DIGITAL:** when the player is connected to an audio component with a built-in Dolby Digital (AC-3) decoder.

Note

If the player is connected to an audio component lacking a built-in Dolby Digital (AC-3) decoder, do not set "DOLBY DIGITAL" in "AUDIO SETUP" to "DOLBY DIGITAL." Otherwise, when you play the Dolby Digital (AC-3) sound track, a loud noise or no sound will come out from the speakers, affecting your ears or causing the speakers to be damaged.

■DTS

Selects output DTS signals via the DIGITAL OUT OPTICAL and COAXIAL connectors. You cannot select this item when you set "DIGITAL OUT" to "OFF."

- **QEE:** when the player is connected to an audio component lacking a built-in DTS decoder.
- **ON:** when the player is connected to an audio component having a built-in DTS decoder.

Note

Select the setting correctly. Otherwise, no sound or strange sound will come out from the speakers, affecting your ears or causing the speakers to be damaged.

- Do not play the DTS sound tracks without connecting the player to an audio component having a built-in DTS decoder. You cannot hear the DTS sound unless you connect the player to an audio component having a built-in DTS decoder.

- When you play the DTS sound track on a CD, a loud noise will come out from the LINE OUT (AUDIO 1, 2), 5.1CH OUTPUT (FRONT L/R) and PHONES connectors, affecting your ears or causing the speakers or headphones to be damaged.
- When you play the DTS sound track on a DVD, no sounds will come out from the LINE OUT (AUDIO 1, 2), 5.1CH OUTPUT (FRONT L/R) and PHONES connectors.

Settings for Sound (AUDIO SETUP)

Notes on playing the DTS sound tracks on a CD

- Do not play the DTS sound tracks without connecting the player to an audio component having a built-in DTS decoder. The player outputs the DTS signal via the DIGITAL OUT OPTICAL and COAXIAL connectors even if "DTS" in "AUDIO SETUP" is set to "OFF" in the setup display, affecting your ears or causing the speakers to be damaged.
- The DTS indicator on the front panel does not light up even if the player outputs DTS signal via the DIGITAL OUT OPTICAL and COAXIAL connectors.
- Set the sounds to "STEREO" when you play the DTS sound tracks on a CD. (See "Changing the Sounds" on page 31.) If you set the sounds to "1/L" or "2/R," no sounds will come out from the DIGITAL OUT OPTICAL and COAXIAL connectors.

Notes on playing the DTS sound tracks on a DVD


- No sounds will come out from the LINE OUT (AUDIO 1, 2) and PHONES connectors.
- If the player is connected to an audio component lacking a built-in DTS decoder, do not set "DTS" in "DIGITAL OUT" to "ON" in the setup display. Otherwise, when you play the DTS sound track, a loud noise will come out from the speakers, affecting your ears or causing the speakers to be damaged.
- When you set "DTS" in "AUDIO SETUP" to "OFF," no sound will come out from the DIGITAL OUT OPTICAL and COAXIAL connectors even if you play DTS sound tracks on DVDs.

Speaker Set Up

Select "SPEAKER SETUP" after pressing SET UP.

To obtain the best possible surround sound, first specify the size of the speakers you have connected and their distance from your listening position, then set the balance and level. Use the test tone to adjust the speaker volumes to the same level.

For the speaker hook ups, see pages 12 to 13.



■SIZE

Selects the size of the speakers to be connected.


- **FRONT**
—**LARGE:** Normally select this.
—**SMALL:** When the sound cracks or the effects of the surround is difficult to hear, select this. This activates the Dolby Digital (AC-3) bass redirection circuitry and outputs the bass frequencies of the speaker from subwoofers.
- **CENTER**
—**NONE:** If you will not connect a center speaker, select this.
—**LARGE:** Normally select this.
—**SMALL:** When the sound cracks, select this. This activates the Dolby Digital (AC-3) bass redirection circuitry and outputs the bass frequencies of the speaker from some other speakers.
- **REAR**
—**NONE:** If you will not connect a rear speaker, select this.
—**LARGE (REAR/SIDE):** Normally select this.
—**SMALL (REAR/SIDE):** When the sound cracks or the effects of the surround is difficult to hear, select this. This activates the Dolby Digital (AC-3) bass redirection circuitry and outputs the bass frequencies of the speaker from some other speakers.
- **SUBWOOFER**
—**NONE:** If you do not connect a subwoofer, select this. This activates the Dolby Digital (AC-3) bass redirection circuitry and outputs the LFE signals from the front speakers.
—**YES:** If you connect a subwoofer, select this to output the LFE (low frequency effects) channel from the subwoofer.

*Rear speaker position (REAR/SIDE)

These items let you specify the location of your rear speakers for proper implementation of "VIRTUAL REAR SHIFT" and "VIRTUAL MULTI REAR" in the Control Menu display. Refer to the illustration below.

- Set to "SIDE" if the location of your rear speakers corresponds to section A.
- Set to "REAR" if the location of your rear speakers corresponds to section B.

This setting affects only the "VIRTUAL REAR SHIFT" and "VIRTUAL MULTI REAR" mode.



Notes

- When you select an item, the sound cuts off for a moment.
- The cut off frequency for the subwoofer is fixed at 100Hz.
- Set the subwoofer's cut off frequency as high as possible.
- Depending on the settings of other speakers, the subwoofer may output excessive sound.
- If your speakers are too small to reproduce low bass frequencies, please set all speaker settings to "SMALL" and utilize a subwoofer for low frequency sound.

■DISTANCE

You can vary the distance of each speaker as follows. Default adjustments are in the parentheses.

- **FRONT (131/3.6m)**
Front speaker distance can be set in 1 foot/0.3 meter steps from 4 to 50 feet/1.2 to 15.2 meters.
- **CENTER (121/3.6m)**
Center speaker distance can be set in 1 foot/0.3 meter steps from a distance 2 feet/0.6 meter farther to the front speaker to a distance 5 feet/1.5 meters closer to your listening position.
- **REAR (101/3.0m)**
Rear speaker distance can be set in 1 foot/0.3 meter steps from a distance equal to the front speaker distance to a distance 16 feet/5 meters closer to your listening position.

Notes

- When you set the distance, the sound cuts off for a moment.
- If each of the front or rear speakers are not placed an equal distance from your listening position, set the distance of the closest speaker.
- Do not place the rear speaker farther away from your listening position than the front speakers.

■BALANCE

You can vary the balance of each speaker as follows. Default adjustments are in the parentheses.

- **FRONT (0dB)**
Adjust the balance between the front left and right speakers (-6dB to +6dB, 0.5dB steps).
- **REAR (0dB)**
Adjust the balance between the rear left and right speakers (-6dB to +6dB, 0.5dB steps).

Note

When you select "YES A" or "YES B" in "VIRTUAL 3D SURROUND" in the Control Menu display, you cannot adjust the level or the balance of the speakers except for the front speakers.

■LEVEL

You can vary the level of each speaker as follows. Default adjustments are in the parentheses.

- **CENTER (0dB)**
Adjust the level of the center speaker (-6dB to +6dB, 0.5dB steps).
- **REAR (0dB)**
Adjust the level of the rear speakers (-6dB to +6dB, 0.5dB steps).
- **SUBWOOFER (0dB)**
Adjust the level of the subwoofer (-10dB to +6dB, 0.5dB steps).

■TEST TONE

You can hear the test tone from each speaker in sequence.

- **QEE:** The test tone is not emitted from speakers.
- **ON:** During adjustment of "BALANCE" or "LEVEL," the test tone is emitted from both speakers simultaneously.

Note

While you are playing a disc, you cannot hear the test tone. Execute the test tone after you stop playback.

To adjust the volume of all the speakers at one time

Use the receiver's (amplifier's) volume control.


To return to the default setting

Select the item, then press CLEAR.


Adjusting the speaker volume

- 1 While you stop playback, select "SPEAKER SETUP" after pressing SET UP.
- 2 Select "TEST TONE" and set "TEST TONE" to "ON." You will hear the test tone from each speaker in sequence.
- 3 From your listening position, select "BALANCE" or "LEVEL" and adjust the value of "BALANCE" and "LEVEL" using $\frac{1}{4}$. During this adjustment, the test tone is emitted from both speakers simultaneously.
- 4 Select "TEST TONE" and set "TEST TONE" to "OFF" to turn off the test tone.

Controlling the TV or the AV Receiver (Amplifier) with the Supplied Remote

If you adjust the remote signal, you can control your TV with the supplied remote. Default setting is to control Sony TVs with the  mark.

When you connect the player to a Sony AV receiver (amplifier), you can also set the input of the receiver (amplifier) to this player with the supplied remote.



Controlling TVs with the remote

- Slide TV/DVD switch to TV.
- Hold down I/O (POWER), and enter your TV's manufacturer's code (see the table) using the number buttons. Then release I/O (POWER).

Code numbers of controllable TVs


If more than one code number is listed, try entering them one at a time until you find the one that works with your TV.

Notes

- If you enter a new code number, the code number previously entered will be erased.
- When you replace the batteries of the remote commander, the code number automatically resets to 01 (Sony). Reset the appropriate code number.

Manufacturer	Code number	Manufacturer	Code number
Sony (default)	01	Panasonic	06,19
Alai	04	Philco	03,04
AOC	04	Philips	08
Centurion	12	Pioneer	16
Coronado	03	Portland	03
Curtis-Mathes	12	Quasar	06,18
Daytron	12	Radio Shack	05,14
Emerson	03,04,14	RCA	04,10
Fisher	11	Sampo	12
General Electric	06,10	Sanyo	11
Gold Star	03,04,17	Scott	12
Hitachi	02,03	Sears	07,10,11
J.C. Penney	04,12	Sharp	03,05,18
JVC	09	Sylvania	08,12
KMC	03	Telnila	03,08,14
Magnavox	03,08,12	Toshiba	07
Marantz	04,13	Wards	03,04,12
MGA/Mitsubishi	04,12,13,17	Yorx	12
NBC	04,12	Zenith	15

When you set the TV/DVD switch to TV, you can control your TV using the keys below.



By pressing	You can
I/O (POWER)	Turn the TV on or off
TV/VIDEO	Select the input source for the TV
VOL*	Adjust the volume of the TV
CH*	Change the channel of the TV
Number buttons and ENTER	Select the channel of the TV

* You can control the TV regardless of the position of the TV / DVD switch.

Note

Depending on the TV, you may not be able to control your TV or to use some of the buttons above.

Controlling an AV receiver (amplifier) with the remote


- Slide TV/DVD switch to DVD.
- Hold down I/O (POWER), and enter your AV receiver's manufacturer's code (see the table below) using the number buttons. Then release I/O (POWER).

Manufacturer	Code number
Sony	91(default), 88, 89
Denon	84, 85, 86
Kenwood	92, 93
Onkyo	81, 82, 83
Pioneer	99
Sansui	87
Technics	97, 98
Yamaha	94, 95, 96

Code numbers of controllable receivers (amplifiers)

If more than one code number is listed, try entering them one at a time until you find the one that works with your receiver (amplifier).

You can also change the sound volume of the AV receiver (amplifier) using AV VOL and AV MUTING.



Notes

- Depending on the AV receiver (amplifier), you may not be able to control your AV receiver (amplifier).
- You can control the AV receiver (amplifier) regardless of the position of the TV / DVD switch.

Self-diagnosis function

When the self-diagnosis function works to prevent the player from malfunctioning, a five-character service number (combination of a letter and digit) flashes on the screen. In this case, check the following table.



First three characters	Cause and/or Corrective Action
C13	<ul style="list-style-type: none"> The disc is dirty. Clean the disc with a cleaning cloth. (page 6)
C31	<ul style="list-style-type: none"> The disc is not inserted correctly. Open the disc tray and insert the disc correctly.
Exx (xx is any number)	<ul style="list-style-type: none"> To prevent the player from malfunctioning, the self-diagnosis function has worked. When you contact your Sony dealer or local authorized Sony service facility, give the 5-character service number. (example: E61-10)

Language Code List

For details, see page 32, 50.


The language spellings conform to the ISO 639-1988 (E/F) standard.

Code	Language	Code	Language	Code	Language	Code	Language
1027	Afar	1186	Scots Gaelic	1350	Malayalam	1513	Sinhali
1028	Abkhazian	1194	Galician	1352	Mongolian	1514	Sesotho
1032	Afrikaans	1196	Guarani	1353	Moldavian	1515	Sundanese
1037	Amharic	1203	Gujarati	1356	Marathi	1516	Swedish
1044	Arabic	1209	Hausa	1357	Malay	1517	Swahili
1045	Assamese	1217	Hindi	1358	Maltese	1521	Tamil
1051	Aymara	1226	Croatian	1363	Burmese	1525	Telugu
1052	Azerbaijani	1229	Hungarian	1365	Nauru	1527	Tajik
1053	Bashkir	1233	Armenian	1369	Nepali	1528	Thai
1057	Byelorussian	1235	Interlingua	1376	Dutch	1529	Tigrinya
1059	Bulgarian	1239	Interlingue	1379	Norwegian	1531	Turkmen
1060	Bihari	1245	Inupiak	1393	Occitan	1532	Tagalog
1061	Bislama	1248	Indonesian	1403	(Afari) Oromo	1534	Setswana
1066	Bengali; Bangla	1253	Icelandic	1408	Oriya	1535	Tonga
1067	Tibetan	1254	Italian	1417	Punjabi	1538	Turkish
1070	Breton	1257	Hebrew	1428	Polish	1539	Tsonga
1079	Catalan	1261	Japanese	1435	Pashto; Pushto	1540	Tatar
1093	Corsican	1269	Yiddish	1436	Portuguese	1543	Twi
1097	Czech	1283	Javanese	1463	Quechua	1557	Ukrainian
1102	Welsh	1287	Georgian	1481	Rhaeto-Romanic	1564	Urdu
1105	Danish	1297	Kazakh	1482	Kirundi	1572	Uzbek
1109	German	1298	Greenlandic	1483	Romanian	1581	Vietnamese
1130	Bhutani	1299	Cambodian	1489	Russian	1587	Volapik
1142	Greek	1300	Kananda	1491	Kinyarwanda	1613	Wolof
1144	English	1301	Korean	1495	Sanskrit	1632	Xhosa
1145	Esperanto	1305	Kashmiri	1498	Sindhi	1665	Yoruba
1149	Spanish	1307	Kurdish	1501	Singho	1684	Chinese
1150	Estonian	1311	Kirghiz	1502	Serbo-Croatian	1697	Zulu
1151	Basque	1313	Latin	1503	Singhalese	1703	Not specified
1157	Persian	1326	Lingala	1505	Slovak		
1165	Finnish	1327	Laotian	1506	Slovenian		
1166	Fiji	1332	Lithuanian	1507	Samoan		
1171	Faroese	1334	Latvian; Lettish	1508	Shona		
1174	French	1345	Malagasy	1509	Somali		
1181	Frisian	1347	Maori	1511	Albanian		
1183	Irish	1349	Macedonian	1512	Serbian		

Index to Parts and Controls


Refer to the pages indicated in parentheses for details.

Front Panel



- 1 **IR (remote sensor) (7)**
Accepts the remote control signals.
- 2 **I/O (POWER) button and indicator (15)**
Turns on and off the power of the player.
- 3 **VIRTUAL 3D SURROUND button/indicator (35)**
Selects the item of "VIRTUAL 3D SURROUND." Each time you press the button, the item changes. When you do not set "VIRTUAL 3D SURROUND" to "OFF," the indicator lights up.
- 4 **SHUFFLE button (38)**
Displays the "SHUFFLE" display on the TV screen.
- 5 **DOLBY DIGITAL indicator (34)**
Lights up as follows:
- playing back Dolby Digital (AC-3) soundtrack on the DVD
- the disc is not inserted
- 6 **Disc tray (15)**
Place a disc on the tray.
- 7 **OPEN/CLOSE button (15)**
Opens or closes the disc tray.
- 8 **SEARCH buttons (17)**
Press to locate a scene.
- 9 **PREV/NEXT (DIRECT SEARCH dial) button (16)**
Turn to select a chapter or track, and then press to go back to the selected chapter or track.
- 10 **Click shuttle (17)**
Changes the playback speed.
- 11 **ENTER button**
Selects and executes the items or settings.
- 12 **JOG button / Indicator (17)**
Press to play a disc frame by frame.
- 13 **PHONE connector (15)**
Connect the headphones to this connector.
- 14 **PHONE LEVEL control (15)**
Adjusts the headphone volume.
- 15 **PROGRAM button (36)**
Displays the "PROGRAM" display on the TV screen.
- 16 **Front Panel Display (21)**
Indicates the playing time, etc.
- 17 **REPEAT button (39)**
Displays the "REPEAT" display on the TV screen.
- 18 **CLEAR button (37, 38, 39)**
Press to return to the continuous play, etc.
- 19 **PLAY button (15)**
Plays a disc.
- 20 **PAUSE button (16)**
Pauses playing a disc.
- 21 **STOP button (16, 18)**
Stops playing a disc.
- 22 **TITLE button (19)**
Displays the title menu on the TV screen.
- 23 **DVD MENU button (19)**
Displays the DVD menu on the TV screen.
- 24 **RETURN button (20, 24)**
Press to return to the previously selected screen, etc.


Rear Panel



- 1 **DIGITAL OUT (OPTICAL) connector (11)**
Connects to an audio component using the optical digital connecting cord.
- 2 **DIGITAL OUT (COAXIAL) connector (11)**
Connects to an audio component using the coaxial digital connecting cord.
- 3 **S-LINK connector (8)**
Connects to the S-link connector on an external component.
- 4 **LINE OUT (AUDIO 1, 2) connectors (8, 10)**
Connects to the audio input connector on the TV or receiver (amplifier).
- 5 **LINE OUT (VIDEO 1, 2) connectors (8)**
Connects to the video input connector on the TV or monitor.
- 6 **S VIDEO OUT (1, 2) connectors (8, 10)**
Connects to the S video input connector on the TV or VCR.
- 7 **COMPONENT VIDEO OUT connectors (9)**
Connects to a monitor or projector having component video input connectors (Y, PB/B-Y, PR/R-Y) that conform to output signals from the player.
- 8 **5.1 CH OUTPUT connectors (13)**
Connects to a receiver (amplifier) having 5.1 channel input connectors.

Index to Parts and Controls

Remote




- 1 **TV/DVD switch (60)**
Selects to control the player or the TV with the remote.
- 2 **OPEN/CLOSE button (15)**
Opens or closes the disc tray.
- 3 **Number buttons**
Selects the items or settings.
- 4 **CLEAR button (37, 38, 39)**
Press to return to the continuous play etc.
- 5 **REPEAT button (39)**
Displays the "REPEAT" display on the TV screen.
- 6 **PROGRAM button (36)**
Displays the "PROGRAM" display on the TV screen.
- 7 **SHUFFLE button (38)**
Displays the "SHUFFLE" display on the TV screen.
- 8 **ANGLE button (33)**
Changes the angles when playing a DVD.
- 9 **AUDIO button (31)**
Changes the sound while playing a DVD or VIDEO CD.
- 10 **SUBTITLE button (32)**
Displays the SUBTITLE menu in the Control Menu display.
- 11 **PREV/NEXT buttons (16)**
Press to go to the next chapter or track or to go back to the previous chapter or track.
- 12 **PLAY button (15)**
Plays a disc.
- 13 **SEARCH buttons (17)**
Press to locate a scene.
- 14 **DISPLAY button (23)**
Displays the Control Menu display on the TV screen to set or adjust the items.
- 15 **TITLE button (19)**
Displays the title menu on the TV screen.
- 16 **DVD MENU button (19)**
Displays the DVD menu on the TV screen.
- 17 **Click shuttle (17)**
Changes the playback speed.
- 18 **ENTER button**
Selects and executes the items or settings.
- 19 **SET UP button (47)**
Displays the setup display on the TV screen to set or adjust the items.
- 20 **I/O (POWER) button (15)**
Turns on and off the power of the player and TV.
- 21 **TV operation buttons (60)**
Controls TVs.
- 22 **TIME/TEXT button (21)**
Displays the playing time of the disc, etc., on the front panel display.
- 23 **INPUT button (30)**
Press when labeling a disc.
- 24 **ENTER button**
Executes the items or settings.
- 25 **PICTURE MEMORY button (51)**
Press to store a picture in memory.
- 26 **BOOK MARK button (46)**
Press to set a bookmark.
- 27 **Receiver operation buttons (61)**
Controls AV receivers (amplifiers).
- 28 **STOP button (16, 18)**
Stops playing a disc.
- 29 **PAUSE button (16)**
Pauses playing a disc.
- 30 **JOG button / Indicator (17)**
Press to play a disc frame by frame.
- 31 **RETURN button (20, 24)**
Press to return to the previously selected screen, etc.


SECTION 2 DISASSEMBLY

Note: Follow the disassembly procedure in the numerical order given.


2-1. CASE REMOVAL




2-3. AU-208/212 BOARD REMOVAL (S330/S530D/S550D)




2-2. MB-82/85 BOARD REMOVAL




2-4. AU-210 BOARD REMOVAL (S705D)




2-5. POWER BLOCK REMOVAL




2-7. FRONT PANEL REMOVAL




2-6. TRAY COVER REMOVAL




2-8. MECHANISM DECK REMOVAL




2-9. TRAY REMOVAL



2-10. OPTICAL PICK-UP REMOVAL




2-11. BELT, LOADING MOTOR (M001), MS-29/TK-51 BOARD REMOVAL




2-12. INTERNAL VIEW

DC motor (loading)
1-541-632-11

Optical pick-up (KHM-220AAA/J1RP)
8-820-081-03




2-13. CIRCUIT BOARDS LOCATION




SECTION 3
BLOCK DIAGRAMS


3-1. OVERALL BLOCK DIAGRAM



3-2. RF/SERVO BLOCK DIAGRAM




3-3. SIGNAL PROCESS/VIDEO BLOCK DIAGRAM







3-5. AUDIO (1) BLOCK DIAGRAM



3-6. AUDIO (2) BLOCK DIAGRAM
- DVP-S330/S530D/S550D -




3-7. AUDIO (3) BLOCK DIAGRAM
– DVP-S705D –



05

3-8. INTERFACE CONTROL BLOCK DIAGRAM





SECTION 4
PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS.
(In addition to this, the necessary note is printed in each block.)

For printed wiring boards:








- — : indicates a lead wire mounted on the component side.
- — : indicates a lead wire mounted on the printed side.
- : Through hole.
- ▨ : Pattern from the side which enables seeing.
(The other layers' patterns are not indicated.)

Caution:



Pattern face side: (Side B)	Parts on the pattern face side seen from the pattern face are indicated.
Parts face side: (Side A)	Parts on the parts face side seen from the parts face are indicated.

- Abbreviation
CND : Canadian


For schematic Diagram:

- Caution when replacing chip parts.
New parts must be attached after removal of chip.
Be careful not to heat the minus side of tantalum capacitor, because it is damaged by the heat.
- All resistors are in ohms, $\frac{1}{4}$ W (Chip resistors : $\frac{1}{10}$ W) unless otherwise specified.
k Ω : 1000 Ω , MW : 1000 k Ω .
- All capacitors are in μ F unless otherwise noted. pF : μ F
50V or less are not indicated except for electrolytics and tantalums.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
-  : nonflammable resistor.
-  : fusible resistor.
-  : panel designation.
-  : internal component.
-  : adjustment for repair.
-  : B+ Line.
-  : B- Line.
- Circled numbers refer to waveforms.
- Voltages are dc between measurement point.
- Readings are taken with a color-bar signals on DVD reference disc and when playing CD reference disc.
- Readings are taken with a digital multimeter (DC 10 MW).
- Voltage variations may be noted due to normal production tolerances.

Note:

The components identified by mark  or dotted line with mark  are critical for safety.
Replace only with part number specified.


Note:

Les composants identifiés par une marque  sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.


When indicating parts by reference number, please include the board name.

- Abbreviation
CND : Canadian


4-1. FRAME SCHEMATIC DIAGRAM
FRAME (1) SCHEMATIC DIAGRAM



FRAME (2) SCHEMATIC DIAGRAM
- DVP-S330/S530D/S550D -




FRAME (3) SCHEMATIC DIAGRAM
- DVP-S705D -



4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

TK-51 (RF/SERVO) PRINTED WIRING BOARD

– Ref. No.: TK-51 board; 2,000 series –




TK-51 BOARD (SIDE A)


CN001	B-2
CN002	C-2
CN003	D-2
CN004	D-3
D003	B-2
IC001	C-1
Q001	B-2
Q002	D-1

There are few cases that the part isn't mounted in this model is printed on this diagram.

TK-51 BOARD(SIDE A)




TK-51 BOARD(SIDE B)




• Waveforms

① IC001 ① (DVD play)
200 mV/DIV 100 ns/DIV




536 mVp-p

② IC001 ① (CD play)
500 mV/DIV 500 ns/DIV




880 mVp-p

③ IC001 ②⑨ (DVD play)
200 mV/DIV 500 ms/DIV




592 mVp-p

④ IC001 ②⑨ (CD play)
200 mV/DIV 20 ms/DIV




448 mVp-p

⑤ IC001 ③⑨ (DVD play)
500 mV/DIV 50 ms/DIV




1.3 Vp-p

⑥ IC001 ③⑨ (CD play)
500 mV/DIV 200 ms/DIV




1.7 Vp-p

⑦ IC001 ④⑩ (DVD play)
100 mV/DIV 50 ms/DIV




180 mVp-p

⑧ IC001 ④⑩ (CD play)
500 mV/DIV 50 ms/DIV




860 mVp-p

⑨ IC001 ⑤④ (DVD play)
500 mV/DIV 100 ns/DIV



1.5 Vp-p

⑩ IC001 ⑤④ (CD play)
500 mV/DIV 500 ns/DIV




1.5 Vp-p

DVP-S330/S530D/S550D/S705D

TK-51 (RF/SERVO) SCHEMATIC DIAGRAM • See page 4-9 for printed wiring board and page 4-12 for waveforms.

– Ref. No.: TK-51 board; 2,000 series –






Note:
The components identified by mark Δ or dotted line with mark Δ are critical for safety.
Replace only with part number specified.

Note:
Les composants identifiés par une marque Δ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

MS-29 (LOADING) PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM
– Ref. No.: MS-29 board; 3,000 series –

There are few cases that the part isn't mounted in this model is printed on this diagram.



MB-82/85 BOARD(SIDE A)

CN001	D-2
CN002	D-4
CN003	D-5
CN004	C-1
CN005	B-1
CN006	C-7
CN007	C-1
CN010	B-6
CN011	D-6
CN012	D-6

D801	C-6
D802	C-6
D803	C-6
D804	C-6
D805	C-5
D807	C-5

IC001	A-2
IC003	A-3
IC004	B-3
IC202	A-5
IC205	A-6
IC302	D-3
IC303	C-4
IC401	C-2
IC501	A-2
IC601	A-4
IC701	C-5
IC904	A-1

Q801	C-5
Q802	C-6
Q803	C-6

Power Block
(SRV902UC (S330/S530: US, Canadian/S550D)
(HS-030SH (S705D)
(HS-030SF (S530D: E)
(SWITCHING REGULATOR)

TK-51
(RF/SERVO)

FR-146 (\$330)
FR-148 (\$705D)
FR-150 (\$530D/\$550D)
(IR/POWER SWITCH)

(RELAY)

AU-208 (\$330)
AU-210 (\$705D)
AU-212 (\$530D/\$550D)
(AUDIO)

HP-109 (S705D)
HP-111 (S530D/S550D)
(HEADPHONE)

MS-29
(LOADING)

SW-315 (S705D)
SW-317 (S530D/S550D)
(SURROUND SWITCH)

FL-97 (S330)
FL-99 (S705D)
FL-101 (S530D/S550D)
(FUNCTION SWITCH)


MB-82 (S705D)
MB-85 (S330/S530D/S550D)
(SIGNAL PROCESS/SERVO)

SIGNAL PROCESS

MB-82/85

4-18

MB-82/85 BOARD(SIDE B)




MB-82/85 BOARD (SIDE B)


D701	C-2
D806	C-2
IC005	A-6
IC201	A-3
IC203	A-3
IC204	B-2
IC207	A-2
IC304	C-3
IC402	C-5
IC403	C-5
IC404	D-6
IC502	C-6
IC602	A-4
IC702	B-1
IC801	C-2
IC802	C-1
IC803	C-1
IC902	A-6
IC905	B-6
IC906	B-6
IC907	C-6

MB-82 : 1-672-676-
MB-85 : 1-672-751-


– Ref. No.: MB-82/85 board; 1,000 series –




– Ref. No.: MB-82/85 board; 1,000 series –




① IC401 ⑤④






– Ref. No.: MB-82/85 board; 1,000 series –




MB-82/85 (ARP) SCHEMATIC DIAGRAM • See page 4-17 for printed wiring board.

– Ref. No.: MB-82/85 board; 1,000 series –




– Ref. No.: MB-82/85 board; 1,000 series –




2.4 Vp-p (12.5 MHz)

2 IC202 ⑤


A square wave signal waveform is shown within a rectangular frame. The waveform consists of a series of horizontal segments at a constant high level, followed by vertical segments dropping to a constant low level, and then horizontal segments at the low level. This pattern repeats across the width of the frame.

4 Vp-p (25.3 MHz)


– Ref. No.: MB-82/85 board; 1,000 series –




MB-82/85 (CLOCK GENERATOR, AUDIO DSP, V EQ/NR) SCHEMATIC DIAGRAM • See page 4-17 for printed wiring board and page 4-40 for waveforms.
– Ref. No.: MB-82/85 board; 1,000 series –



– Ref. No.: MB-82/85 board; 1,000 series –




MB-82/85 (BIAS) SCHEMATIC DIAGRAM • See page 4-17 for printed wiring board.
– Ref. No.: MB-82/85 board; 1,000 series –




• Waveforms

① IC004 ②, ⑤, ⑦




4.2 Vp-p (26.9 MHz)

② IC003 ⑤, ⑦




DVD: 6.2 Vp-p (37.0 MHz)
CD : 5 Vp-p (33.6 MHz)

③ IC001 ⑥




4.2 Vp-p (27.0 MHz)

④ IC001 ⑫




4.6 Vp-p (33.8 MHz)

⑤ IC001 ⑬




DVD: 5.6 Vp-p (36.8 MHz)
CD : 5.2 Vp-p (33.9 MHz)

⑥ IC001 ⑭ (DVD play)




4.2 Vp-p (25.3 MHz)

⑦ IC001 ⑭ (CD play)



4.7 Vp-p (22.5 MHz)

⑧ IC001 ⑰



DVD: 5.8 Vp-p (36.5 MHz)
CD : 5.1 Vp-p (33.8 MHz)



AU-208 (AUDIO, VIDEO BUFFER) PRINTED WIRING BOARD

– Ref. No.: AU-208 board; 2,000 series –
– DVP-S330 –


There are few cases that the part isn't mounted in this model is printed on this diagram.

AU-208 BOARD


CN301	B-2
D301	A-11
D304	A-8
D305	A-8
D306	A-8
D307	A-7
D308	C-2
D431	B-6
D432	B-6
D561	A-2
IC301	C-11
IC302	A-11
IC321	B-4
IC431	B-7
IC505	A-1
Q301	B-5
Q303	A-11
Q304	B-2
Q305	B-5
Q321	B-5
Q322	B-5
Q341	A-1
Q433	C-8
Q434	B-8
Q435	C-6
Q436	B-6
Q575	C-11



• Waveforms



AU-208 (AUDIO, VIDEO BUFFER) SCHEMATIC DIAGRAM
- Ref. No.: AU-208 board; 2,000 series -
- DVP-S330 -





AU-210 (AUDIO, VIDEO BUFFER) PRINTED WIRING BOARD


– Ref. No.: AU-210 board; 3,000 series –
– DVP-S705D –

There are few cases that the part isn't mounted in this model is printed on this diagram.

AU-210 BOARD(SIDE A)



AU-210 BOARD(SIDE B)



AU-210 BOARD
(SIDE B)

CN301	C-5
CN401	C-11
CN402	C-2
CN403	C-3
CN404	C-4
CN405	C-4
CN407	C-5
D301	A-4
D302	A-4
D303	A-4
D304	A-4
D401	C-11
D402	C-11
D403	C-11
D404	C-11
D405	C-4
D406	B-4
D407	B-4
D408	B-4
D409	B-4
D410	A-11
D411	A-11
D421	B-5
D422	B-5
D423	B-5
D424	B-5
D425	C-4
IC301	B-1
IC302	B-3
IC303	A-1
IC401	C-7
IC403	B-7
IC404	B-8
IC405	C-9
IC406	C-10
IC407	B-7
IC408	B-8
IC409	B-9
IC410	B-10
IC411	B-5
IC412	B-11
IC415	C-5
Q301	B-2
Q302	B-2
Q303	A-1
Q401	B-4
Q402	B-4
Q403	B-4
Q404	B-4
Q405	B-4
Q410	A-7
Q411	A-6
Q412	A-8
Q413	A-8
Q414	A-9
Q415	A-9
Q416	A-10
Q417	A-10
Q418	B-5
Q419	B-5
Q420	B-12
Q421	B-11
Q422	A-11
Q423	A-11
Q424	A-11
Q431	B-4
Q432	B-5
Q433	B-5
Q434	B-5
Q435	C-5
Q437	C-7
Q438	C-8


DVP-S330/S530D/S550D/S705D

AU-210 (AUDIO) SCHEMATIC DIAGRAM • See page 4-45 for printed wiring board.

– Ref. No.: AU-210 board; 3,000 series –

– DVP-S705D –

AU-210 BOARD (1/2)




AU-210 BOARD (1/2)
(SEE PAGE 4-51)


NO MARK: DVD/CD PLAY
• SIGNAL PATH

VIDEO SIGNAL			AUDIO SIGNAL
CHROMA	Y	Y/CHROMA	
PB	⇒	⇒⇒	⇒⇒⇒

AU-210 (VIDEO BUFFER) SCHEMATIC DIAGRAM • See page 4-45 for printed wiring board.
– Ref. No.: AU-210 board; 3,000 series –
– DVP-S705D –





• Waveforms



AU-212 (AUDIO, VIDEO BUFFER) PRINTED WIRING BOARD


– Ref. No.: AU-212 board; 2,000 series –
– DVP-S530D/S550D –

There are few cases that the part isn't mounted in this model is printed on this diagram.




AU-212 (AUDIO) SCHEMATIC DIAGRAM

- Ref. No.: AU-212 board; 2,000 series -
- DVP-S530D/S550D -




AU-212 (VIDEO BUFFER) SCHEMATIC DIAGRAM • See page 4-53 for printed wiring board.

– Ref. No.: AU-212 board; 2,000 series –
– DVP-S530D/S550D –



• Waveforms





FL-97/101 (FUNCTION SWITCH, IF CON) PRINTED WIRING BOARD

– Ref. No.: FL-97/101 board; 2,000 series –
– DVP-S330/S530D/S550 –

There are few cases that the part isn't mounted in this model is printed on this diagram.

FL-97/101 BOARD

- CN201 C-1
- CN202 C-10
- CN203 C-12
- D202 A-10
- D203 C-1
- D204 C-13
- D205 B-12
- D206 B-1
- D207 B-1
- IC201 B-9
- IC202 A-10
- IC203 B-12
- Q201 B-1





FL-99 (FUNCTION SWITCH, IF CON) PRINTED WIRING BOARD


– Ref. No.: FL-99 board; 2,000 series –
– DVP-S705D –

There are few cases that the part isn't mounted in this model is printed on this diagram.

FL-99 BOARD(SIDE A)




FL-99 BOARD
(SIDE B)





FL-97/99/101 (IF CON) SCHEMATIC DIAGRAM • See pages 4-59 and 4-61 for printed wiring board.

– Ref. No.: FL-97/99/101 board; 2,000 series –




SW-315/317 (SURROUND SWITCH), FR-146/148/150 (IR/POWER SWITCH) PRINTED WIRING BOARDS


There are few cases that the part isn't mounted in this model is printed on this diagram.

– DVP-S705D –

SW-315 BOARD
(SIDE A)




SW-315 BOARD
(SIDE B)




FR-146/150 BOARD

CN001	B-3
CN002	A-5
CN003	A-2
D001	A-4
D002	A-4
D003	B-4
D004	A-4
D071	A-1
IC051	A-1
Q001	A-3
Q002	A-3




FR-148 BOARD(SIDE A)




FR-148 BOARD(SIDE B)

CN001	B-3
CN002	A-5
CN003	A-2
D001	A-4
D002	A-4
D003	B-4
D004	A-4
D071	A-1
IC051	A-1
Q001	A-3
Q002	A-3



SW-315/317 (SURROUND SWITCH), FR-146/148/150 (IR/POWER SWITCH) SCHEMATIC DIAGRAM

– Ref. No.: SW-315/317 board and FR-146/148/150 board; 4,000 series –




HP-109/111 (HEADPHONE) PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAM


– Ref. No.: HP-109/111 board; 2,000 series –

There are few cases that the part isn't mounted in this model is printed on this diagram.




– DVP-S530D/S550D –



– DVP-S530D/S550D/S705D –



– DVP-S705D –




RY-12 (RELAY) PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM

– Ref. No.: RY-12 board; 2,000 series –



There are few cases that the part isn't mounted in this model is printed on this diagram.

– DVP-S705D –

RY-12 BOARD



– DVP-S705D –




Note:
The components identified by mark \triangle or dotted line with mark \triangle are critical for safety. Replace only with part number specified.

Note:
Les composants identifiés par une marque \triangle sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

HS-030SF/030SH (SWITCHING REGULATOR) SCHEMATIC DIAGRAM

– Ref. No.: HS-030SF/030SH board; 6,000 series –
– DVP-S530D: E/S705D –



5-1. SYSTEM CONTROL PIN FUNCTION (MB-82/85 BOARD IC202)

Pin No.	Pin name	I/O	Function
1	PB5	O	Analog filter gain control
2	PB6	O	VES gain control “H”: VES
3	PB7	O	Rear CH boost control “H”: rear boost
4	VCC3	-	Power supply
5	CLK	O	CPU clock out (25 MHz)
6	CS5	O	Not used
7	CS4	O	Chip select signal for ARP, SERVO DSP and HGA
8	CS3	O	Chip select signal for SDRAM and AV DEC
9	CS2	O	Chip select signal for REG and AV DEC
10	CS1	O	Chip select signal for external SRAM
11	CS0	O	Chip select signal for external FLASH ROM
12	NMI	I	Not used (fixed at “H”)
13	HST	I	Not used (fixed at “H”)
14	RST	I	Reset signal input from IF CON
15	GND	-	Ground
16	MD0	I	Input of mode select 0 (fixed at “1”)
17	MD1	I	Input of mode select 1 (fixed at “0”)
18	MD2	I	Input of mode select 2 (fixed at “0”)
19	RDY	I	Wait signal input
20	P81	I	Test terminal (fixed at “H”)
21	P82	I	Test terminal (fixed at “L”)
22	RD	O	Read enable signal output
23	WR0	O	High byte write enable signal output (16 bit and 8 bit)
24	WR1	O	Low byte write enable signal output (16 bit only)
25-32	D16-D23	I/O	Data bus D0-D7 (16 bit)
33-39	D24-D30	I/O	Data bus D8-D14 (16 bit), D0-D6 (8 bit)
40	GND	-	Ground
41	D31	I/O	Data bus D15 (16 bit), D7 (8 bit)
42	A00	O	Address bus A0
43	VCC5	-	Power supply
44-64	A01-A21	O	Address bus A1-A21
65	GND	-	Ground
66	P66	O	PLL IC control output “H”: DOUBLE
67	P67	I	DIAG mode signal input “L”: DIAG

Pin No.	Pin name	I/O	Function
68	EOP0	I	Not used
69	AVCC	-	Power supply
70	AVRH	-	Reference power supply (+3.3V)
71	AGND	-	Ground
72	AN0	I	Set of mode 0
73	AN1	I	Set of mode 1
74	AN2	I	Set of mode 2
75	AN3	I	Set of mode 3 (fixed at “H”)
76	SI0	I	Serial data input from IF CON and EEPROM
77	SO0	O	Serial data output to IF CON and EEPROM
78	SC0	O	Serial clock output to IF CON and EEPROM
79	SI1	I	Serial bus 1 (for data input)
80	SO1	O	Serial bus 1 (for data output)
81	SI2	I	Serial bus 2 (for data input)
82	SO2	O	Serial bus 2 (for data output)
83	PF7	O	Reset signal output
84	DACK1	O	Output of DMA-ACK 0 to AV DEC
85	DACK0	O	Output of DMA-ACK 1 to AV DEC
86	DREQ1	I	Input of DMA-REQ 0 from AV DEC
87	DREQ0	I	Input of DMA-REQ 1 from AV DEC
88	INT3	I	Input of interrupt from HGA
89	SC1	O	Serial clock output
90	GND	-	Ground
91	X1	O	Clock output (12.5MHz)
92	X0	I	Clock input (12.5MHz)
93	VCC5	-	Power supply
94	INT1	I	Input of interrupt ARP and SERVO DSP
95	INT0	I	Input of interrupt from AV DEC
96	PB0	I	Rear panel lime input select (“H”: DISC “L”: EXT)
97	PB1	O	Chip select signal to IF CON
98	PB2	O	Chip select signal to DAC (Lt and Rt)
99	PB3	O	Chip select signal to DAC (L and R)
100	PB4	O	DVD/CD select (“H”: 44.1kHz “L”: 48kHz)

SECTION 6 TEST MODE

6-1. GENERAL DESCRIPTION

The Test Mode allows you to make diagnosis and adjustment easily using the remote commander and monitor TV. The instructions, diagnostic results, etc. are given on the on-screen display (OSD).

6-2. STARTING TEST MODE

Press **[TITLE]**, **[CLEAR]**, **[POWER]** buttons on the remote commander in this order with the power of main unit in OFF status, and the Test Mode starts, then the menu shown below will be displayed on the TV screen. At the bottom of menu screen, the model name and revision number are displayed.

To execute each function, select the desired menu and press its number on the remote commander.

To exit from the Test Mode, press the POWER button.

```
Test Mode Menu

0. Syscon Diagnosis
1. Drive Auto Adjustment
2. Drive Manual Operation
3. Mecha Aging
4. Emergency History
5. Version Information
6. Video Level Adjustment
Exit: Power Key

—
Model      : DPX12xxxx
Revision: 1.000
```

6-3. SYSCON DIAGNOSIS

The same contents as board detail check by serial interface can be checked from the remote commander.

On the Test Mode Menu screen, press **[0]** key on the remote commander, and the following check menu will be displayed.

```
### Syscon Diagnosis ###
      Check Menu

0. Quit
1. All
2. Version
3. Peripheral
4. Servo
5. Supply
6. AV Decoder
7. Video
8. Audio
—
```

0. Quit

Quit the Syscon Diagnosis and return to the Test Mode Menu.

1. All

All items continuous check

This menu checks all diagnostic items continuously. Normally, all items are checked successively one after another automatically unless an error is found, but at a certain item that requires judgment through a visual check to the result, the following screen is displayed for the key entry.

```
### Syscon Diagnosis ###

Diag All Check
No. 2 Version

2-3. ROM Check Sum
Check Sum = 2005

Press NEXT Key to Continue
Press PREV Key to Repeat

—
```

For the ROM Check, the check sum calculated by the Syscon is output, and therefore you must compare it with the specified value for confirmation.

Following the message, press **[NEXT]** key to go to the next item, or **[PREV]** key to repeat the same check again. To quit the diagnosis and return to the Check Menu screen, press **[STOP]** or **[ENTER]** key. If an error occurred, the diagnosis is suspended and the error code is displayed as shown below.

```
### Syscon Diagnosis ###

3-3. EEPROM Check
Error 03: EEPROM Write/Reed N
Address   : 00000001
Write Data : 2492
Read Data  : 2490
Press NEXT Key to Continue
Press PREV Key to Repeat

—
```

Press **[STOP]** key to quit the diagnosis, or **[PREV]** key to repeat the same item where an error occurred, or **[NEXT]** key to continue the check from the item next to faulty item.

Selecting 2 and subsequent items calls the submenu screen of each item.

For example, if “5. Supply” is selected, the following submenu will be displayed.

```
### Syscon Diagnosis ###
      Check Menu
      No. 5 Supply

0. Quit
1. All
2. ARP Register Check
3. ARP to RAM Data Bus
4. ARP to RAM Address Bus
5. ARP RAM Check

—
```

0. Quit

Quit the submenu and return to the main menu.

1. All

All submenu items continuous check

This menu checks 2 and subsequent items successively. At the item where visual check is required for judgment or an error occurred, the checking is suspended and the message is output for key entry. Normally, all items are checked successively one after another automatically unless an error is found.

Selecting 2 and subsequent items executes respective menus and outputs the results.
For the contents of each submenu, see “Check Items List”.

General Description of Checking Method

2. Version

- (2-2) Revision
ROM revision number is displayed.
Error: Not detected.
The revision number defined in the source file of ROM (IC205) is displayed with four digits.
- (2-3) ROM Check Sum
Check sum is calculated.
Error: Not detected.
The 8-bit data are added at addresses 0x000F0000 ~ 0x002EFFFF of ROM (IC205) and the result is displayed with 4-digit hexadecimal number. Error is not detected. Compare the result with the specified value.
- (2-4) Model Type
Model code is displayed.
Error: Not detected.
The model code read from EEPROM (IC201) is displayed with 2-digit hexadecimal number.

	Model Type	
DVP-S330 (US, Canadian)	0	0
DVP-S530D (US, Canadian)	2	0
DVP-S530D (E)	2	2
DVP-S550D (US, Canadian)	3	0
DVP-S705D (Hong Kong, Singapore)	4	2

- (2-5) Region
Region code is displayed.
Error: Not detected.
The region code determined from the model code is displayed.

3. Peripheral

- (3-2) Gate Array Check
Data write → read, and accord check
Error 02: Gate array write/read discord
Data 0x00~0xFF are written to the address 0xF of GA (IC601), then read and checked if they accord.
- (3-3) EEPROM Check
Data write → read, and accord check
Error 03: EEPROM write/read discord
Data 0x9249, 0x2942, 0x4294 are written to addresses 0x00~0xFF of EEPROM (IC201), then read and checked. Before writing, the data are saved, then after checking, they are written to restore the contents of EEPROM.
- (3-4) NAND Flash Check
Data clear → write → read, and accord check
This check is conducted to the DVP-S550D/DVP-S705D only.
Error 04: Clear error
05: Write error
06: Read data discord
21: Faulty blocks exceed 10

The data clear, write, read, and check are executed to the block 0 of Flash memory (IC602).
In case of a faulty block, its address is displayed.
An error is output if faulty blocks exceed 10.

4. Servo

- (4-2) Servo DSP Check
Data write → read, and accord check
Error 12: Read data discord
Data 0x9249, 0x2942, 0x4294 are written to the address 0x602 of RAM in the Servo DSP (IC701), then read and checked.
- (4-3) DSP Driver Test
Test signal data → DSP Driver
Error: Not detected.
Caution: Do not conduct this test with a mechanical deck connected.
The maximum voltage is applied to the Servo Driver IC (IC801, IC802). If mechanical deck is connected, the motor and optics could be damaged. Disconnect mechanical deck following the output message, then enter specified 4- or 5-digit number from the remote commander, and press the **[ENTER]**. The test is conducted only when the input data accord. Check the output level, then press the **[NEXT]** to finish the test.
This test is skipped if “All” is selected.

Supplement: How to disconnect mechanical deck
Disconnect flat cables connected to the CN002 and CN003 of MB-82/85 board. Also, disconnect harness from the CN011.

5. Supply

- Caution: Do not conduct this check with a mechanical deck connected.
An access is made to the stream supply and servo control IC (IC303) and external RAM (IC304) using check data. If mechanical deck is connected, the motor and optics could be damaged. This check is also executed by the “All” menu item.

Supplement: How to disconnect mechanical deck
Disconnect flat cables connected to the CN002 and CN003 of MB-82/85 board. Also, disconnect harness from the CN011.

- (5-2) ARP Register Check
Data write → read, and accord check
Error 08: ARP register write, and read data discord
Data 0x00 to 0xFF are written to the TMAX register (address 0xC6) in ARP (IC303), then they are read and checked.
- (5-3) ARP to RAM Data Bus
Data write → read, and accord check
Error 09: ARP ↔ RAM data bus error
Data 0x0001 to 0x8000 where one bit each is set to 1 are written to the address 0 of RAM (IC304) connected to the ARP (IC303) through the bus, then they are read and checked. In case of discord, written bit pattern and read data are displayed. If data where multiple bits are 1 are read, the bits concerned may touch each other. Further, if data where certain bit is always 1 or 0 regardless of written data, the line could be disconnected or shorted.

(5-4) ARP to RAM Address Bus

Data write → other address read discord check

Error 10: ARP → RAM address bus error

Caution: Address and data display in case of an error is different from the display of other diagnosis (described later).

Before starting the test, all addresses of RAM (IC304) are cleared to 0x0000.

First, 0xA55A is written to the address 0x000000, and the address data are read and checked from addresses 0x000001 to 0x800000 while shifting 1 bit each. Next, the data at that address is cleared, and it is written to the address 0x000001, and read and checked in the same manner. This check is repeated up to the address 0x800000 while shifting the address data by 1 bit each.

If data other than 0 is read at the addresses except written address, an error is given because all addresses were already cleared to 0. In this check, the error display pattern is different from that of other diagnosis; read data, written address, and read address are displayed in this order. However, the message uses same template, and accordingly exchange Address and Data when reading. The following display, for example,

```
### Syscon Diagnosis ###

5-4. ARP to RAM Address Bus
Error 10: ARP - RAM Address B
Address   : 0000A55A
Write Data: 00000000
Read Data : 00080000
Press NEXT Key to Continue
Press PREV Key to Repeat
—
```

shows the data 0xA55A was read from address 0x00080000 though it was written to the address 0x00000000. This implies that these addresses are in the form of shadow. Also, if the read data is not 0xA55A, another error will be present.

(5-5) ARP RAM Check

Data write → read, and accord check

Error 11: ARP RAM read data discord

The program code data stored in ROM are copied to all areas of RAM (IC304) connected to the ARP (IC303) through the bus, then they are read and checked if they accord. If the detail check was selected initially, the data are written to all areas and read, then the same test is conducted once again with the data where all bits are inverted between 1 and 0. If discord is detected, faulty address, written data, and read data are displayed following the error code 11, and the test is suspended.

6. AV Decoder

(6-2) 1930 RAM

Data write → read, and accord check

Error 13: AVD RAM read data discord

The program code data stored in ROM (IC205) are copied to all areas of RAM (IC402, IC403) connected to the AVD (IC401) through the bus, then they are read and checked if they accord. Further, the same test is conducted once again with the data where all bits are inverted between 1 and 0. If discord is detected, faulty address, written data, and read data are displayed following the error code 13, and the test is suspended.

(6-3) 1930 SP

ROM → AVD RAM → Video OUT

Error: Not detected.

The data including sub picture streams in ROM (IC205) are transferred to the RAM (IC402, IC403) in AVD (IC401), and output as video signals from the AVD (IC401).

They are output from all video terminals (Composite, Y/C, Component) except EURO AV terminal.

7. Video

(7-2) Color Bar

AVD color bar command write → Video OUT

Error: Not detected.

The command is transferred to the AVD, and the color bar signals are output from video terminals.

They are output from all video terminals (Composite, Y/C, Component) except EURO AV terminal.

8. Audio

(8-2) ARP → 1930

Error 14: ARP → 1930 video NG

15: ARP → 1930 audio NG

(8-3) Test Tone

A pink noise signal is output from the AVD (IC401) through optical coaxial digital terminal and analog audio terminal.

Error: Not detected.

For DVP-S330 (2ch models):

All channels → 2ch Left → 2ch Right are checked in this order.

For DVP-S530D/DVP-S550D/DVP-S705D

(DD models):

All channels → 2ch Left → 2ch Right → Front Left → Front Right → Rear Left → Rear Right → Center → Sub Woofer are checked in this order.

Note: Sub Woofer is checked only for low-frequency components, and no sound will be heard unless a proper super woofer is connected.

Check Items List

- 2) Version
 - (2-2) Revision
 - (2-3) ROM Check Sum
 - (2-4) Model Type
 - (2-5) Region
- 3) Peripheral
 - (3-2) Gate Array Check
 - (3-3) EEPROM Check
 - (3-4) NAND Flash Check
 - (DVP-S550D/DVP-S705D only)
- 4) Servo
 - (4-2) Servo DSP Check
 - (4-3) DSP Driver Test
- 5) Supply
 - (5-2) ARP Register Check
 - (5-3) ARP to RAM Data Bus
 - (5-4) ARP to RAM Address Bus
 - (5-5) ARP RAM Check
- 6) AV Decoder
 - (6-2) 1930 RAM
 - (6-3) 1930 SP
- 7) Video
 - (7-2) Color Bar
- 8) Audio
 - (8-2) ARP → 1930
 - (8-3) Test Tone

Error Codes List

- 00: Error not detected
- 01: RAM write/read data discord
- 02: Gate array NG
- 03: EEPROM NG
- 04: Flash memory clear error
- 05: Flash memory write error
- 06: Flash memory read data discord
- 08: ARP register read data discord
- 09: ARP ↔ RAM data bus error
- 10: ARP ↔ RAM address bus error
- 11: ARP RAM read data discord
- 12: Servo DSP NG
- 13: 1930 SDRAM NG
- 14: ARP → 1930 video NG
- 15: ARP → 1930 audio NG
- 16: 1910 UCODE download NG
- 17: System call error (function not supported)
- 18: System call error (parameter error)
- 19: System call error (illegal ID number)
- 20: System call error (time out)
- 21: NAND Flash faulty blocks exceed 10
- 90: Error occurred
- 91: User verification NG
- 92: Diagnosis cancelled

6-4. DRIVE AUTO ADJUSTMENT

On the Test Mode Menu screen, press **[1]** key on the remote commander, and the drive auto adjustment menu will be displayed.

```
## Drive Auto Adjustment ##

      Adjustment Menu

0. ALL
1. DVD-SL
2. CD
3. DVD-DL
4. SACD

Exit: RETURN
```

Normally, **[0]** is selected to adjust DVD (single layer), CD, DVD (dual layer), and SACD in this order. But, individual items can be adjusted for the case where adjustment is suspended due to an error. In this mode, the adjustment can be made easily through the operation following the message displayed on the screen.

The disc used for adjustment must be the one specified for adjustment. However, for SACD disc, use the player with initial data if the disc is not available.

0. ALL

Select **[0]** and press **[ENTER]** key, and the servo set data in EEPROM will be initialized. Then, 1. DVD-SL disc, 2. CD disc, 3. DVD-DL disc, and 4. SACD disc are adjusted in this order. Each time one disc was adjusted, it is ejected. Replace it with the specified disc following the message. Though the message to confirm whether discs other than SACD disc are adjusted is not displayed, you can finish the adjustment if pressing the **[STOP]** button. During adjustment of each disc, the measurement for disc type judgment is made. As automatic adjustment does not judge the disc type unlike conventional models, take care not to insert wrong type discs. Also, do not give a shock during adjustment.

1. DVD-SL (single layer)

Select **[1]**, insert DVD single layer disc, and press **[ENTER]** key, and the adjustment will be made through the following steps, then adjusted values will be written to the EEPROM.

DVD Single Layer Disc Adjustment Steps

1. SLED TILT Reset
2. Disc Check Memory SL
3. Wait 300 msec
4. Set Disc Type SL
5. LD ON
6. Spdl Start
7. Wait 1 sec
8. Focus Servo ON 0
9. Auto Track Offset Adjust
10. CLVA ON
11. Wait 500 msec
12. Tracking ON
13. Wait 1 sec
14. Sled ON
15. Check CLV Lock
16. Auto LFO Adjust
17. Auto Focus Offset Adjust
18. Auto Tilt Position Adjust
19. Auto Focus Gain Adjust
20. Auto Focus Offset Adjust
21. EQ Boost Adjust
22. Auto LFO Adjust
23. Auto Track Gain Adjust, Search Check
24. 32Tj Fwd
25. 32Tj Rev
26. 500Tj Fwd
27. 500Tj Rev
28. All Servo Stop
29. Eep Copy Loop Filter Offset

2. CD

Select [2], insert CD disc, and press [ENTER] key, and the adjustment will be made through the following steps, then adjusted values will be written to the EEPROM.

CD Adjustment Steps

1. Sled Tilt Rest
2. Disc Check Memory CD
3. Wait 500 msec
4. Set Disc Type CD
5. LD ON
6. Spdl Start
7. Wait 500 msec
8. Focus Servo ON 0
9. Auto Track Offset Adjust
10. CLVA ON
11. Wait 500 msec
12. Tracking ON
13. (TC Display Start)
14. Wait 1 sec
15. Jitter Display Start
16. Sled ON
17. Check CLV ON
18. Auto LFO Adjust
19. Auto Focus Offset Adjust
- 20.
21. Auto Focus Gain Adjust
22. Auto Focus Offset Adjust
23. Eq Boost Adjust
24. Auto LFO Adjust
25. Auto Track Gain Adjust, Search Check
26. 32Tj Fwd
27. 32Tj Rev
28. 500Tj Fwd
29. 500Tj Rev
30. All Servo Stop

3. DVD-DL (dual layer)

Select [3], insert DVD dual layer disc, and press [ENTER] key, and the adjustment will be made through the following steps, then adjusted values will be written to the EEPROM.

DVD Dual Layer Disc Adjustment Steps

1. Sled Tilt Reset
2. Disc Check Memory DL
3. Wait 500 msec
4. Set Disc Type DL
5. LD ON
6. Spdl Start
7. Wait 1 sec, Layer 1 Adjust
8. Focus Servo ON 0
9. Auto Track Offset Adjust
10. Clva ON
11. Wait 500 msec
12. Tracking ON
13. Wait 500 msec
14. Sled ON
15. Check CLV Lock
16. Auto Loop Filter Offset Auto Focus Adjust
- 17.
18. Auto Focus Gain Adjust
19. Auto Focus Offset Adjust
20. Eq Boost Adjust
21. Auto Loop Filter Offset
22. Auto Track Gain Adjust, Search Check
23. 32Tj Fwd
24. 32Tj Rev
25. 500Tj Fwd
26. 500Tj Rev, Layer 0 Adjust
27. Fj (L1 -> L0)
28. Auto Track Offset Adjust L0
29. Clva ON
30. Wait 500 msec
31. Tracking ON
32. Wait 500 msec
33. Sled ON
34. Check CLV Lock
35. Auto Focus Filter Offset
36. Auto Focus Adjust
- 37.
38. Auto Focus Gain Adjust
39. Auto Focus Offset Adjust
40. Eq Boost Adjust
41. Auto Loop Filter Offset
42. Auto Track Gain Adjust, Search Check
43. 32Tj Fwd
44. 32Tj Rev
45. 500Tj fwd
46. 500Tj Rev, Layer Jump Check
47. Lj (L0 -> L1)
48. Lj (L1 -> L0)
49. All Servo Stop

4. SACD

Select [4], insert SACD disc, and press [ENTER] key, and the adjustment will be made through the following steps, then adjusted values will be written to the EEPROM. However, if SACD disc is not available, use the player with initial data, skipping the SACD adjustment. In this case, you can finish the adjustment if pressing the [STOP] button.

SACD Adjustment Steps

1. Sled Tilt Reset
2. Set Disc Type CD
3. LD ON
4. Spdl Start
5. Wait 500 msec
6. Focus Servo ON 0
7. Auto track Offset Adjust
- 8.
9. CLVA ON
10. Wait 500 msec
11. Tracking ON
12. Wait 1 sec
13. Sled ON
14. Check CLV ON
15. Auto Focus Offset Adjust
- 17.
18. Auto Focus Gain Adjust
19. Auto Focus Offset Adjust
20. Eq Boost Adjust
21. Auto LFO Adjust
22. Auto Track Gain Adjust
23. 32Tj Fwd
24. 32Tj Rev
25. 500Tj Fwd
26. 500Tj Rev
27. All Servo Stop */

6-5. DRIVE MANUAL OPERATION

On the Test Mode Menu screen, select [2], and the manual operation menu will be displayed. For the manual operation, each servo on/off control and adjustment can be executed manually.

```
## Drive Manual Operation ##

      Operation Menu
1. Disc type
2. Servo Control
3. Track/Layer Jump
4. Manual Adjustment
5. Auto Adjustment
6. Memory Check

0. Disc Check Memory

Exit: Return
```


In using the manual operation menu, take care of the following points. These commands do not provide protection, thus requiring correct operation. The sector address or time code field is displayed when a disc is loaded.

1. Set correctly the disc type to be used on the Disc Type screen.
The disc type must be set after a disc was loaded.
The set disc type is cleared when the tray is opened.
2. After power ON, if the Drive Manual Operation was selected, first perform "Reset SLED TILT" by opening 1. Disc Type screen.
3. In case of an alarm, immediately press the [STOP] button to stop the servo operation, and turn the power OFF.

Basic operation (controllable from front panel or remote commander)

[POWER]	Power OFF
[STOP]	Servo stop
[OPEN/CLOSE]	Stop+Eject/Loading
[RETURN]	Return to Operation Menu or Test Mode Menu
[NEXT], [PREV]	Transition between sub modes of menu
[1] to [9], [0]	Selection of menu items
Cursor UP/DOWN	Increase/Decrease in manually adjusted value

0. Disc Check Memory



On this screen, the mirror time is measured to judge the disc and it is written to the EEPROM. First load DVD SL disc and press [1], next load CD disc and press [2], and finally load DVD DL disc and press [3].


The adjustment must be executed more than once after default data were written. External vibration or shock to the player must not be given. Reference value for DVD is from 10 to 20, and for CD, from 28 to 4F.

Check that the value of CD is larger than that of DVD.

When those values are beyond a range perform this adjustment again.

From this screen, you can go to another mode by pressing [NEXT] or [PREV] key, but you cannot enter this mode from another mode. You can enter this mode from the Operation Menu screen only.


1. Disc Type




On this screen, select the disc type. To select the disc type, press the number of the loaded disc. The selected disc type is displayed at the bottom. Selecting [1] automatically selects and displays the disc type. In case of wrong display, retry "Disc Check Memory". Also, opening the tray causes the set disc type to be cleared. In this case, set the disc type again after loading.

In performing manual operation, the disc type must be set.

Once the disc type has been selected, the sector address or time code display field will appear as shown below. These values are displayed when PLL is locked.



Display when DVD SL 12cm disc was selected



Display when CD 12cm disc was selected


[0] Reset SLED TILT Reset the Sled and Tilt to initial position.

[1] Disk Type Check Judge automatically the loaded disc. As the judged result is displayed at the bottom of screen, make sure that it is correct.

If Disc Check Memory menu has not been executed after EEPROM default setting, the disc type cannot be judged. In this case, return to the initial menu and make a check for three types of discs (SL, DL, CD).

[2] to [9] Select the loaded disc. The adjusted value is written to the address of selected disc. No further entry is necessary if [1] was selected.

2. Servo Control



On this screen, the servo on/off control necessary for replay is executed. Normally, turn on each servo from 1 sequentially and when CLVA is turned on, the usual trace mode becomes active. In the trace mode, DVD sector address or CD time code is displayed. This is not displayed where the spindle is not locked.

The spindle could run overriding the control if the spindle system is faulty or RF is not present. In such a case, do not operate CLVA.

[0] Reset SLED TILT	Reset the Sled and Tilt to initial position.
[1] LD	Turn ON/OFF the laser.
[2] SP	Turn ON/OFF the spindle.
[3] Focus	Search the focus and turn on the focus.
[4] TRK	Turn ON/OFF the tracking servo.
[5] Sled	Turn ON/OFF the sled servo.
[6] CLVA	Turn ON/OFF normal servo of spindle servo.
[7] FCS. Srch	Apply same voltage as that of focus search to the focus drive to check the focus drive system.
→ Sled FWD	Move the sled outward. Perform this operation with the tracking servo turned off.
← Sled REV	Move the sled inward. Perform this operation with the tracking servo turned off.
↑ Tilt UP	Move the tilt upward.
↓ Tilt DOWN	Move the tilt downward.

The following menus are normally not used.

3. Track/Layer Jump

4. Manual Adjustment

5. Auto Adjustment

The persons who do not know well about these menus should not use them.

6. Memory Check

EEPROM DATA				
	CD	- DVD -		
ID No. 00	SACD	SL	L0	L1
Focus Gain	xx xx	xx	xx	xx
TRK. Gain	xx xx	xx	xx	xx
Focus Offset	xx xx	xx	xx	xx
TRK. Offset	xx xx	xx	xx	xx
L. F. Offset	xx xx	xx	xx	xx
EQ Boost	xx xx	xx	xx	xx
Jitter	xx xx	xx	xx	xx
Mirror Time	xx xx	xx	xx	xx
- CLEAR: Default Set				

This screen displays current servo adjusted data stored in the EEPROM. Though adjusted data can be initialized with the [CLEAR] key, they cannot be restored after initialization.

So, before clearing, make a note of the adjusted data.

For reference, the drive has been designed so that the gain center value is 20 and offset value is 80. Other values will be in a range of 10 to 80. If extreme value such as 00 or FF is set, adjustment will be faulty. In such a case, check for disc scratch or cable disconnection, then perform adjustment again.

6-6. MECHA AGING

### Mecha Aging ###	
Press OPEN key	
Abort: STOP key	

On the Test Mode Menu screen, selecting [3] executes the aging of mechanism. First, open the tray and load a disc. Press the [PLAY] key, and the aging will start. When the tray is closed, the disc type and size are judged and displayed. During aging, the repeat cycle is displayed. Aging can be aborted at any time by pressing the [STOP] key. After the operation has stopped, unload the disc and press again the [STOP] key or the [RETURN] key to return to the Test Mode Menu.

6-7. EMERGENCY HISTORY

### MEG. History ###	
Laser Hours	CD xxxxxxxh
	DVD xxxxxxxh
1. 00 00 00 00 00 00 00 00	
00 00 00 00 00 00 00 00	
2. 00 00 00 00 00 00 00 00	
00 00 00 00 00 00 00 00	
Select: 1 - 9	Scroll: UP/DOWN
(1: Last EMG.)	Exit: Return

On the Test Mode Menu screen, selecting [4] displays the information such as servo emergency history. The history information from last 1 up to 10 can be scrolled with [↑] key or [↓] key. Also, specific information can be displayed by directly entering that number with ten keys.

The upper two lines display the laser ON total hours. Data below minutes are omitted.

Clearing History Information

Clearing laser hours

- ⊙ Press [DISPLAY] and [CLEAR] keys in this order. Both CD and DVD data are cleared.

Clearing emergency history


- ⊙ Press [TITLE] and [CLEAR] keys in this order.

Initializing set up data

- ⊙ Press [DVD] and [CLEAR] keys in this order.

The data have been initialized when "Set Up Initialized" message is displayed. The EMG. History screen will be restored soon.

How to see Emergency History



① : Emergency Code

② : Don't Care

These codes are used for verification of software designing.

③ : Historical order 1 to 9

Emergency Codes List

- 10: Communication to IC001 (TK-51/54 board) failed.
- 11: Each servo for focus, tracking, and spindle is unlocked.
- 12: Communication to EEPROM, IC201 (MB-82/85 board) failed.
- 13: Writing of hours meter data to EEPROM, IC201 (MB-82/85 board) failed.
- 14: Communication to Servo DSP IC701 (MB-82/85 board) failed, or Servo DSP is faulty.
- 20: Initialization of tilt servo and sled servo failed. They are not placed in the initial position.
- 21: Tilt servo operation error
- 22: Syscon made a request to move the tilt servo to wrong position.
- 23: Sled servo operation error
- 24: Syscon made a request to move the sled servo to wrong position.
- 30: Tracking balance adjustment error
- 31: Tracking gain adjustment error
- 32: Focus balance adjustment error
- 33: Focus bias adjustment error
- 34: Focus gain adjustment error
- 35: Tilt servo adjustment error
- 36: RF equalizer adjustment error
- 37: RF group delay adjustment error
- 38: Jitter value after adaptive servo operation is too large.
- 40: Focus servo does not operate.
- 41: With a dual layer (DL) disc, focus jump failed.50: CLV (spindle) servo does not operate.
- 51: Spindle does not stop.
- 60: With a DVD disc, Syscon made a request to seek nonexistent address.
- 61: With a CD disc, Syscon made a request to seek nonexistent address.
- 62: With a CD disc, Syscon made a request to seek nonexistent track No. and index No.
- 63: With a DVD disc, seeking of target address failed.
- 64: With a CD disc, seeking of target address failed.
- 65: With a CD disc, seeking of target index failed.
- 70: With a DVD disc, physical information data could not be read.
- 71: With a CD disc, TOC data could not be read.
- 80: Disc type judgment failed.
- 81: As disc type judgment failed, retry was repeated.
- 82: As disc type judgment failed, a measurement error occurred.
- 83: Disc type could not be judged within the specified time.
- 84: Illegal command code was received from Syscon.
- 85: Illegal command was received from Syscon.

6-8. VERSION INFORMATION

## Version Information ##		
IF con.	Ver. x. xxx (xxxx)	
	Group	00
SYScon.	Ver. x. xxx (xxxx)	
	Model	xx
	Region	0x
	SW1	??
	SW2	??
Exit: RETURN		

On the Test Mode Menu screen, selecting [5] displays the ROM version and region code.

The parenthesized hexadecimal number in version field is checksum value of ROM.

6-9. VIDEO LEVEL ADJUSTMENT


On the Test Mode Menu screen, selecting [6] displays color bars for video level adjustment. During display of color bars, OSD disappears but the menu screen will be restored if pressing any key.

Measurement point : LINE OUT VIDEO
(75 Ω terminating resistance)

Measuring instrument : Oscilloscope

Adjustment device : RV401 on MB-82/85 board

Specified value : 1.0 ± 0.02 Vpp



SECTION 7 ELECTRICAL ADJUSTMENTS

In making adjustment, refer to 7-3. Adjustment Related Parts Arrangement.

Note: During diagnostic check, the characters and color bars can be seen only with the NTSC monitor. Therefore, for diagnostic check, use the monitor that supports both NTSC and PAL modes

This section describes procedures and instructions necessary for adjusting electrical circuits in this set.

Instruments required:

- 1) Color monitor TV
- 2) Oscilloscope 1 or 2 phenomena, band width over 100 MHz, with delay mode
- 3) Frequency counter (over 8 digits)
- 4) Digital voltmeter
- 5) Standard commander
(RMT-D108A/D109A/D111A/D111E)
- 6) DVD reference disc
HLX-501 (J-6090-071-A) (dual layer)
HLX-503 (J-6090-069-A) (single layer)
HLX-504 (J-6090-088-A) (single layer)
HLX-505 (J-6090-089-A) (dual layer)
- 7) SACD reference disc
HLXA-509 (J-6090-090-A)

7-1. POWER SUPPLY ADJUSTMENT

1. Power Supply Check (HS-030SF/030SH BOARD, SRV902UC BOARD)

Mode	E-E
Instrument	Digital voltmeter
+5 V Check	
Test point	CN202 pin ⑤
Specification	5.0 ± 0.2 Vdc
+3.3 V Check	
Test point	CN202 pin ⑦
Specification	3.3 ± 0.2 Vdc
EVER+5 V Check	
Test point	CN203 pin ②
Specification	5.0 ± 0.2 Vdc
P_CONT Check	
Test point	CN203 pin ①
Specification	4V – 5 Vdc
A +12 V Check	
Test point	CN202 pin ①
Specification	$9.5^{+1.5}_{-0.5}$ Vdc
–12 V Check	
Test point	CN203 pin ⑤
Specification	-12.0 ± 1.0 Vdc
M +12 V Check	
Test point	CN202 pin ②
Specification	12.0 ± 1.0 Vdc

Checking method:

- 1) Confirm that each voltage satisfies the specification.

2. +3.3 V Adjustment (SRV902UC BOARD) (DVP-S330/S530D: US, Canadian/S550D)

Mode	PB
Measuring Instrument	Digital voltmeter
Measurement Point	CN202 pin ⑦
Adjusting Element	VR201
Specified Value	3.3 ± 0.2 V

7-2. ADJUSTMENT OF VIDEO SYSTEM

1. Video Level Adjustment (MB-82/85 BOARD)

<Purpose>

This adjustment is made to satisfy the NTSC standard, and if not adjusted correctly, the brightness will be too large or small.

Mode	Video level adjustment in test mode
Signal	Color bars
Test point	LINE OUT (VIDEO) connector (75 Ω terminated)
Instrument	Oscilloscope
Adjusting element	RV401
Specification	1.0 ± 0.02 Vp-p

Adjusting method:

- 1) In the test mode initial menu "6" Video Level Adjustment, set so that color bars are generated.
- 2) Adjust the RV401 to attain 1.0 ± 0.02 Vp-p.




Figure 7-1

2. S-terminal Output Check (MB-82/85 BOARD)

<Purpose>

Check S-terminal video output. If it is incorrect, pictures will not be displayed correctly in spite of connection to the TV with a S-terminal cable.

Mode	Video level adjustment in test mode
Signal	Color bars
Test point	S VIDEO OUT (S-Y) connector (75 Ω terminated)
Instrument	Oscilloscope
Specification	1.0 ± 0.1 Vp-p

Checking method:

- 1) In the test mode initial menu "6" Video Level Adjustment, set so that color bars are generated.
- 2) Confirm that the S-Y level is 1.0 ± 0.1 Vp-p.



Figure 7-2

3. Checking Component Video Output B-Y (MB-82/85 BOARD) (DVP-S530D/S550D/S705D)

<Purpose>

This checks component video output B-Y. If it is incorrect, correct colors will not be displayed when connected to, for instance, projector.

Mode	Video level adjustment in test mode
Signal	Color bars
Test point	COMPONENT VIDEO OUT (B-Y) connector (75 Ω terminated)
Instrument	Oscilloscope
Specification	700 ± 70 mVp-p

Checking method:

- 1) Confirm that the B-Y level is 700 ± 70 mVp-p.




Figure 7-3

4. Checking Component Video Output R-Y (MB-82/85 BOARD) (DVP-S530D/S550D/S705D)

<Purpose>

This checks component video output R-Y. If it is incorrect, correct colors will not be displayed when connected to, for instance, projector.

Mode	Video level adjustment in test mode
Signal	Color bars
Test point	COMPONENT VIDEO OUT (R-Y) connector (75 Ω terminated)
Instrument	Oscilloscope
Specification	700 ± 70 mVp-p

Checking method:

- 1) Confirm that the R-Y level is 700 ± 70 mVp-p.



Figure 7-4

5. Checking Component Video Output Y
(MB-82/85 BOARD) (DVP-S530D/S550D/S705D)

<Purpose>
This checks component video output Y. If it is incorrect, correct brightness will not be attained when connected to, for instance, projector.

Mode	Video level adjustment in test mode
Signal	Color bars
Test point	COMPONENT VIDEO OUT (Y) connector (75 Ω terminated)
Instrument	Oscilloscope
Specification	1.0 ± 0.1 Vp-p

Checking method:
1) Confirm that the Y level is 1.0 ± 0.1 Vp-p.





Figure 7-5

6. Checking S Video Output S-C (MB-82/85 BOARD)

<Purpose>
This checks whether the S-C satisfies the NTSC Standard. If it is not correct, the colors will be too dark or light.

Mode	Video level adjustment in test mode
Signal	Color bars
Test point	CN005 pin ⑤
Instrument	Oscilloscope
Specification	286 ± 50 mVp-p

Connection:




Checking method:
1) Confirm that the S-C burst is 286 ± 50 mVp-p.




Figure 7-6

7-3. ADJUSTMENT RELATED PARTS ARRANGEMENT


MB-82/85 BOARD (SIDE A)



HS-030SF/030SH BOARD (SIDE A)



SRV902UC BOARD (SIDE A)



SECTION 8

REPAIR PARTS LIST

8-1. EXPLODED VIEWS



NOTE:


- -XX and -X mean standardized parts, so they may have some difference from the original one.
- Items marked “*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list and accessories and packing materials are given in the last of the electrical parts list.

Example:


KNOB, BALANCE (WHITE) . . . (RED)

[illegible]

The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.


Les composants identifiés par une
marque  sont critiques pour la
sécurité.
Ne les remplacer que par une pièce
portant le numéro spécifié.

8-1-1. CASE ASSEMBLY (S330/S530D/S550D)




<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>	<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
1	3-975-726-41	EMBLEM, DVD		7	1-418-320-21	COMMANDER, STANDARD (RMT-D108A)	
2	3-053-498-01	COVER (BK), TRAY					(S530D)
3	3-970-608-01	SUMITITE (B3), +BV		7	1-418-320-41	COMMANDER, STANDARD (RMT-D109A)	
4	3-710-901-41	SCREW, TAPPING					(S330)
5	3-053-510-01	CASE, TOP		8	3-053-633-01	COVER, BATTERY (for RMT-D108A/D109A)	
							(S330/S530D)
6	3-973-973-01	FOOT (S)		9	1-418-321-11	COMMANDER, STANDARD (RMT-D111A)	
							(S550D)
				10	3-055-539-01	COVER, BATTERY (for RMT-D111A)	(S550D)

8-1-2. CASE ASSEMBLY (S705D)




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51	3-053-493-01	ORNAMENT (M), TRAY		57	3-053-984-01	SCREW (+BV/CU)	
52	3-053-492-01	ORNAMENT (AL), TRAY (Hong Kong)		58	X-3602-115-1	FOOT ASSY	
52	3-053-492-21	ORNAMENT (AL), TRAY (Singapore)		59	1-418-321-61	COMMANDER, STANDARD (RMT-D111E/N)	(Hong Kong)
53	3-975-726-31	EMBLEM, DVD (Singapore)		59	1-418-321-71	COMMANDER, STANDARD (RMT-D111E/H)	(Singapore)
53	3-975-726-51	EMBLEM, DVD (Hong Kong)		60	3-055-539-01	COVER, BATTERY	(for RMT-D111E/N/D111E/H)
54	3-970-608-01	SUMITITE (B3), +BV					
55	3-710-901-51	SCREW, TAPPING					
56	X-3949-708-1	CASE ASSY, TOP (Singapore)					
56	X-3949-709-1	CASE ASSY, TOP (Hong Kong)					

8-1-3. FRONT PANEL ASSEMBLY




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
101	X-3949-295-1	PANEL ASSY, FRONT (S330)		113	3-053-482-31	KNOB (ACS) (S705D: Hong Kong)	
101	X-3949-300-1	PANEL ASSY, FRONT (S530D)		113	3-053-482-41	KNOB (ACS) (S705D: Singapore)	
101	X-3949-301-1	PANEL ASSY, FRONT (S550D)		114	3-988-016-01	STICK, CURSOR (S530D/S550D)	
101	X-3949-306-1	PANEL ASSY, FRONT (S705D: Hong Kong)		114	3-988-016-21	STICK, CURSOR (S705D: Hong Kong)	
101	X-3949-307-1	PANEL ASSY, FRONT (S705D: Singapore)		114	3-988-016-61	STICK, CURSOR (S705D: Singapore)	
102	3-053-483-01	WINDOW (FL)		115	1-418-097-11	ENCODER, ROTARY (S530D/S550D/S705D)	
103	3-974-997-31	WINDOW, REMOTE CONTROL	(S330/S530D/S550D)	116	4-951-620-01	SCREW (2.6X8), +BVTP	
103	3-974-997-41	WINDOW, REMOTE CONTROL	(S705D: Hong Kong)	117	1-771-564-11	SWITCH, TACTILE (S330)	
103	3-974-997-51	WINDOW, REMOTE CONTROL	(S705D: Singapore)	118	3-053-496-31	STICK (L), CURSOR (S330)	
104	4-942-568-31	EMBLEM (NO.5), SONY (S705D: Hong Kong)		119	3-945-284-51	KNOB, VOLUME (S530D/S550D)	
104	4-942-568-61	EMBLEM (NO.5), SONY (S705D: Singapore)		119	3-945-284-81	KNOB, VOLUME (S705D: Singapore)	
104	4-963-404-21	EMBLEM (5-A), SONY (S330/S530D/S550D)		119	3-945-284-71	KNOB, VOLUME (S705D: Hong Kong)	
106	X-3949-309-1	BUTTON (VES) ASSY (S530D/S550D)		120	2-118-268-01	NUT (M9), HEXAGON (S530D/S550D/S705D)	
106	X-3949-310-1	BUTTON (VES) ASSY (S705D: Hong Kong)		* 121	3-684-436-01	PLATE, MOUNT (S530D/S550D/S705D)	
106	X-3949-311-1	BUTTON (VES) ASSY (S705D: Singapore)		* 122	A-6065-219-A	HP-111 BOARD, COMPLETE (S530D/S550D)	
107	3-053-479-01	BUTTON (PROG) (S530D/S550D)		* 122	A-6065-257-A	HP-109 BOARD, COMPLETE (S705D)	
107	3-053-479-11	BUTTON (PROG) (S705D: Hong Kong)		* 123	A-6065-221-A	SW-317 BOARD, COMPLETE (S530D/S550D)	
107	3-053-479-21	BUTTON (PROG) (S705D: Singapore)		* 123	A-6065-243-A	SW-315 BOARD, COMPLETE (S705D)	
108	3-053-517-01	BUTTON (OPEN) (S330/S530D/S550D)		* 124	A-6065-218-A	FR-150 BOARD, COMPLETE (S530D)	
108	3-053-517-11	BUTTON (OPEN) (S705D: Hong Kong)		* 124	A-6065-237-A	FR-150 BOARD, COMPLETE (S550D)	
108	3-053-517-21	BUTTON (OPEN) (S705D: Singapore)		* 124	A-6065-241-A	FR-148 BOARD, COMPLETE (S705D)	
109	3-053-480-01	BUTTON (PLAY) (S530D/S550D/S705D)		* 124	A-6065-262-A	FR-146 BOARD, COMPLETE (S330)	
109	3-053-480-11	BUTTON (PLAY) (S705D: Hong Kong)		125	3-054-216-01	PLATE (SL), GROUND	
109	3-053-480-21	BUTTON (PLAY) (S705D: Singapore)		126	3-053-512-01	PLATE (S), GROUND	
110	3-053-504-01	CUSHION (S330/S530D/S550D)		127	1-790-167-11	CABLE, FLEXIBLE FLAT (FMF-35)	
111	3-053-481-01	BEARING (ACS) (S550D)		* 128	A-6065-220-A	FL-101 BOARD, COMPLETE (S530D: US, Canadian)	
112	X-3949-294-1	RING ASSY, SHUTTLE (S530D/S550D)		* 128	A-6065-223-A	FL-101 BOARD, COMPLETE (S530D: E)	
112	X-3949-312-1	RING ASSY, SHUTTLE (S705D: Hong Kong)		* 128	A-6065-236-A	FL-101 BOARD, COMPLETE (S550D)	
112	X-3949-313-1	RING ASSY, SHUTTLE (S705D: Singapore)		* 128	A-6065-240-A	FL-99 BOARD, COMPLETE (S705D)	
113	3-053-482-01	KNOB (ACS) (S550D)		* 128	A-6065-263-A	FL-97 BOARD, COMPLETE (S330)	

8-1-4. CHASSIS ASSEMBLY



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
* 151	A-6065-216-A	MB-85 BOARD, COMPLETE (S530D: US, Canadian)		* 159	1-468-358-21	POWER BLOCK (SRV902UC) (S330/S530D: US, Canadian/S550D)	
* 151	A-6065-224-A	MB-85 BOARD, COMPLETE (S530D: E)		* 159	1-468-359-11	POWER BLOCK (HS-030SH) (S705D)	
* 151	A-6065-238-A	MB-85 BOARD, COMPLETE (S550D)		* 159	1-468-359-21	POWER BLOCK (HS-030SF) (S530D: E)	
* 151	A-6065-245-A	MB-82 BOARD, COMPLETE (S705D)		160	3-053-507-01	PANEL, REAR (S530D: US, Canadian/S550D)	
* 151	A-6065-265-A	MB-85 BOARD, COMPLETE (S330)		160	3-053-507-11	PANEL, REAR (S530D: E)	
152	3-970-608-01	SUMITITE (B3), +BV		160	3-053-507-61	PANEL, REAR (S330)	
153	1-790-166-11	CABLE, FLEXIBLE FLAT (FMT-25)		160	X-3949-711-1	PANEL ASSY, REAR (S705D)	
154	1-790-163-11	CABLE, FLEXIBLE FLAT (FMA-7)		△ 161	1-769-744-91	CORD, POWER (E, Hong Kong, Singapore)	
155	1-790-164-11	CABLE, FLEXIBLE FLAT (FMA-8) (S530D/S550D/S705D)		△ 161	1-783-531-31	CORD, POWER (US, Canadian)	
156	1-790-165-11	CABLE, FLEXIBLE FLAT (FMA-9) (S530D/S550D/S705D)		162	4-966-267-11	BUSHING (FBS001), CORD	
* 157	3-669-610-00	SPACER		163	3-970-608-51	SUMITITE (B3), +BV	
* 158	A-6065-217-A	AU-212 BOARD, COMPLETE (S530D: US, Canadian/S550D)		* 164	A-6065-255-A	RY-12 BOARD, COMPLETE (S705D)	
* 158	A-6065-222-A	AU-212 BOARD, COMPLETE (S530D: E)		165	3-055-791-01	SUMITITE (B3) (RING), +BV (S705D)	
* 158	A-6065-260-A	AU-210 BOARD, COMPLETE (S705D)		165	3-970-608-01	SUMITITE (B3), +BV (S330/S530D/S550D)	
* 158	A-6065-264-A	AU-208 BOARD, COMPLETE (S330)		166	3-055-418-01	COVER, EJECT	
				167	3-054-650-01	SPRING, EMC	
				△ T901	1-431-175-21	TRANSFORMER, POWER (S705D)	

8-1-5. MECHANISM DECK ASSEMBLY



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
* 201	A-6065-214-A	TK-51 BOARD, COMPLETE		* 213	A-6065-012-A	MS-29 BOARD, COMPLETE	
202	A-6062-120-A	LOADING ASSY		214	3-053-845-01	CHUCK PLATE	
203	3-053-837-01	TRAY		215	3-053-844-01	YOKE	
204	3-053-841-01	PULLEY GEAR		216	3-053-846-01	YOKE HOLDER	
205	3-053-840-01	CAM DRIVING GEAR		217	3-053-848-01	CHUCK HOLDER	
206	3-053-839-01	TRAY DRIVING GEAR		218	3-053-847-01	INSULATOR	
207	4-974-711-01	SCREW (2X5) (P TYIGHT), (+) PTTWH		219	4-981-923-01	SCREW (M), STEP	
208	3-053-842-01	BELT		△ 220	8-820-081-03	OPTICAL PICK-UP KHM-220AAA/J1RP	
209	3-053-849-01	SPRING, TENSION		221	3-053-843-01	MOTOR PULLEY	
210	3-053-838-01	CHUCK CAM		222	3-055-097-01	SEAL, TRAY DUST	
211	3-053-836-01	BASE UNIT HOLDER		M001	1-541-632-11	MOTOR, DC (LOADING)	
212	3-053-835-01	BASE, LOADING					

8-2. ELECTRICAL PARTS LIST

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS**
All resistors are in ohms.
METAL: Metal-film resistor.
METAL OXIDE: Metal oxide-film resistor.
F: nonflammable

- Items marked “*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS**
In each case, u: μ , for example:
uA. . . : μ A. . . uPA. . . : μ PA. . .
uPB. . . : μ PB. . . uPC. . . : μ PC. . .
uPD. . . : μ PD. . .
- CAPACITORS**
uF: μ F
- COILS**
uH: μ H
- Not all of the parts for POWER BLOCK (HS-030SF/030SH and SRV902UC) are listed.

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
*	A-6065-264-A	AU-208 BOARD, COMPLETE (S330)		C350	1-163-233-11	CERAMIC CHIP 18PF 5% 50V	
*	A-6065-217-A	AU-212 BOARD, COMPLETE (S530D: US, Canadian/S550D)		C351	1-163-233-11	CERAMIC CHIP 18PF 5% 50V	
*	A-6065-222-A	AU-212 BOARD, COMPLETE (S530D: E)		C352	1-163-233-11	CERAMIC CHIP 18PF 5% 50V	
	*****			C353	1-163-233-11	CERAMIC CHIP 18PF 5% 50V	(S530D/S550D)
		(Ref.No. 2,000 Series)		C354	1-163-233-11	CERAMIC CHIP 18PF 5% 50V	(S530D/S550D)
		< CAPACITOR >		C355	1-163-233-11	CERAMIC CHIP 18PF 5% 50V	(S530D/S550D)
C302	1-126-926-11	ELECT 1000uF 20% 10V		C401	1-104-665-11	ELECT 100uF 20% 10V	(S530D/S550D)
C303	1-163-021-91	CERAMIC CHIP 0.01uF 10% 50V		C404	1-104-665-11	ELECT 100uF 20% 10V	(S530D/S550D)
C304	1-163-021-91	CERAMIC CHIP 0.01uF 10% 50V					
C305	1-163-239-11	CERAMIC CHIP 33PF 5% 50V		C431	1-104-664-11	ELECT 47uF 20% 16V	
C306	1-163-239-11	CERAMIC CHIP 33PF 5% 50V		C432	1-104-664-11	ELECT 47uF 20% 16V	
C307	1-163-239-11	CERAMIC CHIP 33PF 5% 50V		C433	1-104-665-11	ELECT 100uF 20% 10V	
C312	1-163-239-11	CERAMIC CHIP 33PF 5% 50V		C434	1-163-021-91	CERAMIC CHIP 0.01uF 10% 50V	
C313	1-163-239-11	CERAMIC CHIP 33PF 5% 50V		C435	1-104-665-11	ELECT 100uF 20% 10V	
C314	1-163-239-11	CERAMIC CHIP 33PF 5% 50V	(S530D/S550D)	C436	1-163-131-00	CERAMIC CHIP 390PF 5% 50V	
C315	1-126-935-11	ELECT 470uF 20% 6.3V	(S530D/S550D)	C437	1-163-021-91	CERAMIC CHIP 0.01uF 10% 50V	
C316	1-104-665-11	ELECT 100uF 20% 10V	(S530D/S550D)	C438	1-163-131-00	CERAMIC CHIP 390PF 5% 50V	
C317	1-126-935-11	ELECT 470uF 20% 6.3V	(S530D/S550D)	C439	1-163-133-00	CERAMIC CHIP 470PF 5% 50V	
C318	1-104-665-11	ELECT 100uF 20% 10V	(S530D/S550D)	C440	1-163-021-91	CERAMIC CHIP 0.01uF 10% 50V	
C319	1-126-935-11	ELECT 470uF 20% 6.3V	(S530D/S550D)	C442	1-163-133-00	CERAMIC CHIP 470PF 5% 50V	
C320	1-104-665-11	ELECT 100uF 20% 10V	(S530D/S550D)	C443	1-163-021-91	CERAMIC CHIP 0.01uF 10% 50V	
C321	1-104-665-11	ELECT 100uF 20% 10V		C447	1-136-850-11	FILM 0.1uF 5% 63V	
C322	1-104-665-11	ELECT 100uF 20% 10V		C448	1-104-664-11	ELECT 47uF 20% 16V	
C323	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V		C449	1-104-664-11	ELECT 47uF 20% 16V	
C324	1-126-935-11	ELECT 470uF 20% 6.3V		C450	1-136-850-11	FILM 0.1uF 5% 63V	
C325	1-126-935-11	ELECT 470uF 20% 6.3V		C501	1-104-664-11	ELECT 47uF 20% 16V	(S530D/S550D)
C326	1-104-664-11	ELECT 47uF 20% 16V		C502	1-104-664-11	ELECT 47uF 20% 16V	(S530D/S550D)
C327	1-163-021-91	CERAMIC CHIP 0.01uF 10% 50V		C503	1-163-021-91	CERAMIC CHIP 0.01uF 10% 50V	(S530D/S550D)
C328	1-104-664-11	ELECT 47uF 20% 16V	(S530D/S550D)	C504	1-163-131-00	CERAMIC CHIP 390PF 5% 50V	(S530D/S550D)
C329	1-163-021-91	CERAMIC CHIP 0.01uF 10% 50V	(S530D/S550D)	C505	1-163-131-00	CERAMIC CHIP 390PF 5% 50V	(S530D/S550D)
C343	1-163-259-91	CERAMIC CHIP 220PF 5% 50V		C506	1-163-021-91	CERAMIC CHIP 0.01uF 10% 50V	(S530D/S550D)
C344	1-126-960-11	ELECT 1uF 20% 50V		C507	1-163-133-00	CERAMIC CHIP 470PF 5% 50V	(S530D/S550D)
C345	1-163-021-91	CERAMIC CHIP 0.01uF 10% 50V		C508	1-163-133-00	CERAMIC CHIP 470PF 5% 50V	(S530D/S550D)

Ref. No.	Part No.	Description	Remark
C509	1-136-850-11	FILM	0.1uF 5% 63V (S530D/S550D)
C512	1-136-850-11	FILM	0.1uF 5% 63V (S530D/S550D)
C513	1-104-664-11	ELECT	47uF 20% 16V (S530D/S550D)
C514	1-104-664-11	ELECT	47uF 20% 16V (S530D/S550D)
C541	1-104-664-11	ELECT	47uF 20% 16V (S530D/S550D)
C542	1-104-664-11	ELECT	47uF 20% 16V (S530D/S550D)
C543	1-163-130-00	CERAMIC CHIP	360PF 5% 50V (S530D/S550D)
C544	1-163-275-11	CERAMIC CHIP	0.001uF 5% 50V (S530D/S550D)
C545	1-163-021-91	CERAMIC CHIP	0.01uF 10% 50V (S530D/S550D)
C546	1-163-130-00	CERAMIC CHIP	360PF 5% 50V (S530D/S550D)
C547	1-163-275-11	CERAMIC CHIP	0.001uF 5% 50V (S530D/S550D)
C548	1-163-021-91	CERAMIC CHIP	0.01uF 10% 50V (S530D/S550D)
C549	1-104-664-11	ELECT	47uF 20% 16V (S530D/S550D)
C550	1-104-664-11	ELECT	47uF 20% 16V (S530D/S550D)
C571	1-104-664-11	ELECT	47uF 20% 16V (S530D/S550D)
C572	1-104-664-11	ELECT	47uF 20% 16V (S530D/S550D)
C573	1-163-130-00	CERAMIC CHIP	360PF 5% 50V (S530D/S550D)
C574	1-163-020-00	CERAMIC CHIP	0.0082uF 10% 50V (S530D/S550D)
C575	1-163-021-91	CERAMIC CHIP	0.01uF 10% 50V (S530D/S550D)
C576	1-163-145-00	CERAMIC CHIP	0.0015uF 5% 50V (S530D/S550D)
C577	1-163-275-11	CERAMIC CHIP	0.001uF 5% 50V (S530D/S550D)
C578	1-163-021-91	CERAMIC CHIP	0.01uF 10% 50V (S530D/S550D)
C579	1-104-664-11	ELECT	47uF 20% 16V (S530D/S550D)
C580	1-104-664-11	ELECT	47uF 20% 16V (S530D/S550D)
< CONNECTOR >			
CN301	1-785-698-11	CONNECTOR, FFC/FPC 28P	
CN302	1-785-695-11	CONNECTOR, FFC/FPC 13P (S530D/S550D)	
CN303	1-785-694-11	CONNECTOR, FFC/FPC 7P (S530D/S550D)	
CN401	1-564-002-11	PIN, CONNECTOR 3P (S530D/S550D)	
< DIODE >			
D301	8-719-988-61	DIODE	1SS355TE-17
D304	8-719-071-15	DIODE	HZM6.8ZWA1TL
D305	8-719-071-15	DIODE	HZM6.8ZWA1TL
D306	8-719-071-15	DIODE	HZM6.8ZWA1TL
D307	8-719-071-15	DIODE	HZM6.8ZWA1TL
D308	8-719-988-61	DIODE	1SS355TE-17
D431	8-719-988-61	DIODE	1SS355TE-17
D432	8-719-988-61	DIODE	1SS355TE-17

Ref. No.	Part No.	Description	Remark
D525	8-719-988-61	DIODE	1SS355TE-17 (S530D/S550D)
D526	8-719-988-61	DIODE	1SS355TE-17 (S530D/S550D)
D551	8-719-988-61	DIODE	1SS355TE-17 (S530D/S550D)
D552	8-719-988-61	DIODE	1SS355TE-17 (S530D/S550D)
D561	8-719-071-15	DIODE	HZM6.8ZWA1TL (S330/S530D: US, Canadian/S550D)
D591	8-719-988-61	DIODE	1SS355TE-17 (S530D/S550D)
D592	8-719-988-61	DIODE	1SS355TE-17 (S530D/S550D)
< EARTH TERMINAL >			
* ET301	1-537-738-21	TERMINAL, EARTH	
* ET302	1-537-738-21	TERMINAL, EARTH	
* ET303	1-537-738-21	TERMINAL, EARTH	
< FERRITE BEAD >			
FB305	1-414-553-11	FERRITE	0UH
FB306	1-414-553-11	FERRITE	0UH
FB307	1-414-553-11	FERRITE	0UH
FB308	1-414-553-11	FERRITE	0UH
FB310	1-414-553-11	FERRITE	0UH
FB311	1-414-553-11	FERRITE	0UH
FB312	1-414-553-11	FERRITE	0UH
FB313	1-414-553-11	FERRITE	0UH
FB314	1-414-553-11	FERRITE	0UH
FB315	1-414-553-11	FERRITE	0UH
FB316	1-414-553-11	FERRITE	0UH
FB317	1-414-553-11	FERRITE	0UH
FB318	1-414-553-11	FERRITE	0UH
FB319	1-414-553-11	FERRITE	0UH
FB320	1-414-553-11	FERRITE	0UH (S530D/S550D)
FB321	1-414-553-11	FERRITE	0UH (S530D/S550D)
FB322	1-414-553-11	FERRITE	0UH (S530D/S550D)
FB341	1-414-135-11	FERRITE	0UH
FB342	1-414-553-11	FERRITE	0UH
FB401	1-414-553-11	FERRITE	0UH (S530D/S550D)
FB402	1-414-553-11	FERRITE	0UH (S530D/S550D)
FB403	1-414-553-11	FERRITE	0UH (S530D/S550D)
FB404	1-414-553-11	FERRITE	0UH (S530D/S550D)
FB405	1-414-553-11	FERRITE	0UH (S530D/S550D)
FB406	1-414-553-11	FERRITE	0UH (S530D/S550D)
FB407	1-414-553-11	FERRITE	0UH (S530D/S550D)
FB408	1-414-553-11	FERRITE	0UH (S530D/S550D)
FB409	1-414-553-11	FERRITE	0UH (S530D/S550D)
FB561	1-414-553-11	FERRITE	0UH (S330/S530D: US, Canadian/S550D)
FB562	1-414-553-11	FERRITE	0UH (S330/S530D: US, Canadian/S550D)
< IC >			
IC301	8-759-701-58	IC	NJM78M08FA
IC302	8-759-982-54	IC	RC79M09FA
IC303	8-759-563-79	IC	BA7660F-E2 (S530D/S550D)
IC321	8-759-563-79	IC	BA7660F-E2
IC401	8-759-909-71	IC	BA4558F (S530D/S550D)
IC431	8-759-909-71	IC	BA4558F
IC502	8-759-909-71	IC	BA4558F (S530D/S550D)
IC505	8-749-921-12	IC	GP1F32T
IC541	8-759-909-71	IC	BA4558F (S530D/S550D)
IC571	8-759-909-71	IC	BA4558F (S530D/S550D)

Ref. No.	Part No.	Description	Remark
< JACK >			
J303	1-784-675-21	JACK, PIN 3P (COMPONENT VIDEO OUT) (S530D/S550D)	
J501	1-764-188-21	JACK (SMALL TYPE) (DIA. 3.5) (S-LINK) (S330/S530D: US, Canadian/S550D)	
J502	1-779-382-11	JACK, PIN 1P (COAXIAL)	
J505	1-785-535-11	JACK BLOCK, PIN (LINE OUT/S VIDEO OUT)	
J508	1-785-536-11	JACK, PIN (6P) (5.1CH OUTPUT) (S530D/S550D)	
< JUMPER RESISTOR >			
JR400	1-216-296-91	SHORT	0 (S330)
JR400	1-216-295-91	SHORT	0 (S530D/S550D)
JR401	1-216-295-91	SHORT	0 (S530D/S550D)
JR401	1-216-296-91	SHORT	0 (S330)
JR402	1-216-295-91	SHORT	0 (S530D/S550D)
JR402	1-216-296-91	SHORT	0 (S330)
JR403	1-216-295-91	SHORT	0
JR404	1-216-295-91	SHORT	0
JR405	1-216-296-91	SHORT	0
JR406	1-216-295-91	SHORT	0
JR407	1-216-296-91	SHORT	0
JR408	1-216-295-91	SHORT	0 (S530D/S550D)
JR408	1-216-296-91	SHORT	0 (S330)
JR409	1-216-295-91	SHORT	0 (S530D/S550D)
JR409	1-216-296-91	SHORT	0 (S330)
JR410	1-216-296-91	SHORT	0 (S530D/S550D)
JR410	1-216-295-91	SHORT	0 (S330)
JR411	1-216-296-91	SHORT	0
JR412	1-216-296-91	SHORT	0
JR413	1-216-296-91	SHORT	0
JR414	1-216-296-91	SHORT	0
JR415	1-216-295-91	SHORT	0 (S530D/S550D)
JR415	1-216-296-91	SHORT	0 (S330)
JR416	1-216-296-91	SHORT	0
JR417	1-216-295-91	SHORT	0 (S530D/S550D)
JR417	1-216-296-91	SHORT	0 (S330)
JR418	1-216-296-91	SHORT	0 (S530D/S550D)
JR418	1-216-295-91	SHORT	0 (S330)
JR419	1-216-296-91	SHORT	0
JR420	1-216-295-91	SHORT	0 (S530D/S550D)
JR420	1-216-296-91	SHORT	0 (S330)
JR421	1-216-296-91	SHORT	0
JR422	1-216-296-91	SHORT	0
JR423	1-216-295-91	SHORT	0 (S530D/S550D)
JR424	1-216-296-91	SHORT	0 (S530D/S550D)
JR424	1-216-295-91	SHORT	0 (S330)
JR425	1-216-295-91	SHORT	0
JR426	1-216-295-91	SHORT	0
JR427	1-216-295-91	SHORT	0
JR428	1-216-295-91	SHORT	0
JR429	1-216-296-91	SHORT	0
JR430	1-216-296-91	SHORT	0
JR431	1-216-295-91	SHORT	0
JR432	1-216-295-91	SHORT	0
JR433	1-216-295-91	SHORT	0 (S530D/S550D)
JR433	1-216-296-91	SHORT	0 (S330)
JR434	1-216-295-91	SHORT	0 (S530D/S550D)
JR434	1-216-296-91	SHORT	0 (S330)
JR435	1-216-296-91	SHORT	0 (S330)
JR436	1-216-296-91	SHORT	0 (S330)

Ref. No.	Part No.	Description	Remark
< COIL >			
L301	1-412-953-11	INDUCTOR	15uH
L302	1-412-953-11	INDUCTOR	15uH
L303	1-412-953-11	INDUCTOR	15uH
L304	1-412-953-11	INDUCTOR	15uH (S530D/S550D)
L305	1-412-953-11	INDUCTOR	15uH (S530D/S550D)
L306	1-412-953-11	INDUCTOR	15uH (S530D/S550D)
L307	1-412-963-11	INDUCTOR	100uH (S530D/S550D)
L321	1-412-963-11	INDUCTOR	100uH
< TRANSISTOR >			
Q301	8-729-424-08	TRANSISTOR	UN2111
Q303	8-729-216-22	TRANSISTOR	2SA1162
Q304	8-729-421-19	TRANSISTOR	UN2213
Q305	8-729-424-08	TRANSISTOR	UN2111
Q306	8-729-424-08	TRANSISTOR	UN2111 (S530D/S550D)
Q307	8-729-424-08	TRANSISTOR	UN2111 (S530D/S550D)
Q308	8-729-424-08	TRANSISTOR	UN2111 (S530D/S550D)
Q309	8-729-424-08	TRANSISTOR	UN2111 (S530D/S550D)
Q310	8-729-424-08	TRANSISTOR	UN2111 (S530D/S550D)
Q311	8-729-424-08	TRANSISTOR	UN2111 (S530D/S550D)
Q314	8-729-424-08	TRANSISTOR	UN2111 (S530D/S550D)
Q315	8-729-421-19	TRANSISTOR	UN2213 (S530D/S550D)
Q321	8-729-421-19	TRANSISTOR	UN2213
Q322	8-729-424-08	TRANSISTOR	UN2111
Q341	8-729-120-28	TRANSISTOR	2SC1623-L5L6
Q401	8-729-046-97	TRANSISTOR	2SD1938(F)-T(TX).SO (S530D/S550D)
Q402	8-729-046-97	TRANSISTOR	2SD1938(F)-T(TX).SO (S530D/S550D)
Q431	8-729-046-97	TRANSISTOR	2SD1938(F)-T(TX).SO (S530D/S550D)
Q432	8-729-046-97	TRANSISTOR	2SD1938(F)-T(TX).SO (S530D/S550D)
Q433	8-729-046-97	TRANSISTOR	2SD1938(F)-T(TX).SO (S330)
Q434	8-729-046-97	TRANSISTOR	2SD1938(F)-T(TX).SO (S330)
Q435	8-729-046-97	TRANSISTOR	2SD1938(F)-T(TX).SO
Q436	8-729-046-97	TRANSISTOR	2SD1938(F)-T(TX).SO
Q503	8-729-046-97	TRANSISTOR	2SD1938(F)-T(TX).SO (S530D/S550D)
Q504	8-729-046-97	TRANSISTOR	2SD1938(F)-T(TX).SO (S530D/S550D)
Q543	8-729-046-97	TRANSISTOR	2SD1938(F)-T(TX).SO (S530D/S550D)
Q544	8-729-046-97	TRANSISTOR	2SD1938(F)-T(TX).SO (S530D/S550D)
Q573	8-729-046-97	TRANSISTOR	2SD1938(F)-T(TX).SO (S530D/S550D)
Q574	8-729-046-97	TRANSISTOR	2SD1938(F)-T(TX).SO (S530D/S550D)
Q575	8-729-424-08	TRANSISTOR	UN2111 (S330)
< RESISTOR >			
R301	1-216-042-00	METAL CHIP	510 5% 1/10W
R302	1-216-042-00	METAL CHIP	510 5% 1/10W
R303	1-216-042-00	METAL CHIP	510 5% 1/10W
R304	1-216-021-00	METAL CHIP	68 5% 1/10W (S530D/S550D)
R305	1-216-073-00	METAL CHIP	10K 5% 1/10W
R306	1-216-021-00	METAL CHIP	68 5% 1/10W (S530D/S550D)
R307	1-216-073-00	METAL CHIP	10K 5% 1/10W

AU-208**AU-212**

Ref. No.	Part No.	Description		Remark
R308	1-216-021-00	METAL CHIP	68	5% 1/10W (S530D/S550D)
R309	1-216-097-91	RES,CHIP	100K	5% 1/10W
R310	1-216-042-00	METAL CHIP	510	5% 1/10W (S530D/S550D)
R311	1-216-042-00	METAL CHIP	510	5% 1/10W (S530D/S550D)
R312	1-216-042-00	METAL CHIP	510	5% 1/10W (S530D/S550D)
R313	1-216-097-91	RES,CHIP	100K	5% 1/10W (S530D/S550D)
R314	1-216-097-91	RES,CHIP	100K	5% 1/10W (S530D/S550D)
R315	1-216-097-91	RES,CHIP	100K	5% 1/10W (S530D/S550D)
R316	1-216-097-91	RES,CHIP	100K	5% 1/10W (S530D/S550D)
R317	1-216-073-00	METAL CHIP	10K	5% 1/10W (S530D/S550D)
R318	1-216-097-91	RES,CHIP	100K	5% 1/10W
R319	1-216-097-91	RES,CHIP	100K	5% 1/10W (S530D/S550D)
R320	1-216-097-91	RES,CHIP	100K	5% 1/10W (S530D/S550D)
R321	1-216-073-00	METAL CHIP	10K	5% 1/10W
R322	1-216-073-00	METAL CHIP	10K	5% 1/10W
R323	1-216-021-00	METAL CHIP	68	5% 1/10W
R324	1-216-021-00	METAL CHIP	68	5% 1/10W
R325	1-216-021-00	METAL CHIP	68	5% 1/10W
R326	1-216-021-00	METAL CHIP	68	5% 1/10W
R327	1-216-021-00	METAL CHIP	68	5% 1/10W
R328	1-216-021-00	METAL CHIP	68	5% 1/10W
R330	1-216-073-00	METAL CHIP	10K	5% 1/10W
R333	1-216-049-91	RES,CHIP	1K	5% 1/10W (S530D/S550D)
R334	1-216-097-91	RES,CHIP	100K	5% 1/10W (S530D/S550D)
R341	1-216-057-00	METAL CHIP	2.2K	5% 1/10W
R342	1-216-063-91	RES,CHIP	3.9K	5% 1/10W
R343	1-216-055-00	METAL CHIP	1.8K	5% 1/10W
R344	1-216-033-00	METAL CHIP	220	5% 1/10W
R345	1-216-021-00	METAL CHIP	68	5% 1/10W
R346	1-216-025-91	RES,CHIP	100	5% 1/10W
R347	1-216-295-91	SHORT	0	
R348	1-216-097-91	RES,CHIP	100K	5% 1/10W
R401	1-216-085-00	METAL CHIP	33K	5% 1/10W (S530D/S550D)
R402	1-216-085-00	METAL CHIP	33K	5% 1/10W (S530D/S550D)
R403	1-216-085-00	METAL CHIP	33K	5% 1/10W (S530D/S550D)
R404	1-216-085-00	METAL CHIP	33K	5% 1/10W (S530D/S550D)
R405	1-216-085-00	METAL CHIP	33K	5% 1/10W (S530D/S550D)
R406	1-216-077-00	METAL CHIP	15K	5% 1/10W (S530D/S550D)
R407	1-216-077-00	METAL CHIP	15K	5% 1/10W (S530D/S550D)
R408	1-216-085-00	METAL CHIP	33K	5% 1/10W (S530D/S550D)
R409	1-216-025-91	RES,CHIP	100	5% 1/10W (S530D/S550D)

Ref. No.	Part No.	Description		Remark
R410	1-216-025-91	RES,CHIP	100	5% 1/10W (S530D/S550D)
R411	1-216-049-91	RES,CHIP	1K	5% 1/10W (S530D/S550D)
R412	1-216-049-91	RES,CHIP	1K	5% 1/10W (S530D/S550D)
R431	1-216-109-00	METAL CHIP	330K	5% 1/10W
R432	1-216-069-00	METAL CHIP	6.8K	5% 1/10W
R433	1-216-069-00	METAL CHIP	6.8K	5% 1/10W
R434	1-216-109-00	METAL CHIP	330K	5% 1/10W
R435	1-216-069-00	METAL CHIP	6.8K	5% 1/10W
R436	1-216-069-00	METAL CHIP	6.8K	5% 1/10W
R437	1-216-071-00	METAL CHIP	8.2K	5% 1/10W (S530D/S550D)
R438	1-216-071-00	METAL CHIP	8.2K	5% 1/10W (S530D/S550D)
R439	1-216-069-00	METAL CHIP	6.8K	5% 1/10W
R440	1-216-295-91	SHORT	0	(S530D/S550D)
R441	1-216-069-00	METAL CHIP	6.8K	5% 1/10W
R443	1-216-057-00	METAL CHIP	2.2K	5% 1/10W
R444	1-216-057-00	METAL CHIP	2.2K	5% 1/10W
R445	1-216-049-91	RES,CHIP	1K	5% 1/10W (S530D/S550D)
R446	1-216-047-91	RES,CHIP	820	5% 1/10W (S530D/S550D)
R447	1-216-049-91	RES,CHIP	1K	5% 1/10W (S530D/S550D)
R448	1-216-047-91	RES,CHIP	820	5% 1/10W (S530D/S550D)
R449	1-216-109-00	METAL CHIP	330K	5% 1/10W
R450	1-216-109-00	METAL CHIP	330K	5% 1/10W
R451	1-216-041-00	METAL CHIP	470	5% 1/10W
R452	1-216-041-00	METAL CHIP	470	5% 1/10W
R455	1-216-097-91	RES,CHIP	100K	5% 1/10W
R456	1-216-049-91	RES,CHIP	1K	5% 1/10W
R457	1-216-049-91	RES,CHIP	1K	5% 1/10W
R458	1-216-041-00	METAL CHIP	470	5% 1/10W
R459	1-216-041-00	METAL CHIP	470	5% 1/10W
R460	1-216-041-00	METAL CHIP	470	5% 1/10W
R461	1-216-041-00	METAL CHIP	470	5% 1/10W
R462	1-216-056-00	RES,CHIP	2K	5% 1/10W (S330)
R463	1-216-049-91	RES,CHIP	1K	5% 1/10W (S330)
R464	1-216-049-91	RES,CHIP	1K	5% 1/10W (S330)
R465	1-216-056-00	RES,CHIP	2K	5% 1/10W (S330)
R475	1-216-295-91	SHORT	0	(S330)
R476	1-216-295-91	SHORT	0	(S330)
R477	1-216-295-91	SHORT	0	(S330)
R478	1-216-295-91	SHORT	0	(S330)
R479	1-216-295-91	SHORT	0	(S330)
R501	1-216-109-00	METAL CHIP	330K	5% 1/10W (S530D/S550D)
R502	1-216-069-00	METAL CHIP	6.8K	5% 1/10W (S530D/S550D)
R503	1-216-109-00	METAL CHIP	330K	5% 1/10W (S530D/S550D)
R504	1-216-069-00	METAL CHIP	6.8K	5% 1/10W (S530D/S550D)
R510	1-216-069-00	METAL CHIP	6.8K	5% 1/10W (S530D/S550D)

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
R511	1-216-069-00	METAL CHIP	6.8K 5% 1/10W (S530D/S550D)	R562	1-216-049-91	RES,CHIP 1K 5% 1/10W (S530D/S550D)	
R512	1-216-071-00	METAL CHIP	8.2K 5% 1/10W (S530D/S550D)	R563	1-216-049-91	RES,CHIP 1K 5% 1/10W (S330/S530D: US, Canadian/S550D)	
R513	1-216-069-00	METAL CHIP	6.8K 5% 1/10W (S530D/S550D)	R564	1-216-295-91	SHORT 0 (S530D/S550D)	
R514	1-216-071-00	METAL CHIP	8.2K 5% 1/10W (S530D/S550D)	R569	1-216-295-91	SHORT 0 (S530D/S550D)	
R517	1-216-057-00	METAL CHIP	2.2K 5% 1/10W (S530D/S550D)	R571	1-216-109-00	METAL CHIP 330K 5% 1/10W (S530D/S550D)	
R519	1-216-057-00	METAL CHIP	2.2K 5% 1/10W (S530D/S550D)	R572	1-216-109-00	METAL CHIP 330K 5% 1/10W (S530D/S550D)	
R520	1-216-069-00	METAL CHIP	6.8K 5% 1/10W (S530D/S550D)	R573	1-216-069-00	METAL CHIP 6.8K 5% 1/10W (S530D/S550D)	
R521	1-216-109-00	METAL CHIP	330K 5% 1/10W (S530D/S550D)	R574	1-216-077-00	METAL CHIP 15K 5% 1/10W (S530D/S550D)	
R522	1-216-109-00	METAL CHIP	330K 5% 1/10W (S530D/S550D)	R575	1-216-069-00	METAL CHIP 6.8K 5% 1/10W (S530D/S550D)	
R523	1-216-041-00	METAL CHIP	470 5% 1/10W (S530D/S550D)	R576	1-216-077-00	METAL CHIP 15K 5% 1/10W (S530D/S550D)	
R524	1-216-041-00	METAL CHIP	470 5% 1/10W (S530D/S550D)	R577	1-216-057-00	METAL CHIP 2.2K 5% 1/10W (S530D/S550D)	
R525	1-216-049-91	RES,CHIP	1K 5% 1/10W (S530D/S550D)	R578	1-216-061-00	METAL CHIP 3.3K 5% 1/10W (S530D/S550D)	
R526	1-216-025-91	RES,CHIP	100 5% 1/10W (S530D/S550D)	R579	1-216-069-00	METAL CHIP 6.8K 5% 1/10W (S530D/S550D)	
R527	1-216-025-91	RES,CHIP	100 5% 1/10W (S530D/S550D)	R580	1-216-079-00	METAL CHIP 18K 5% 1/10W (S530D/S550D)	
R528	1-216-049-91	RES,CHIP	1K 5% 1/10W (S530D/S550D)	R585	1-216-109-00	METAL CHIP 330K 5% 1/10W (S530D/S550D)	
R541	1-216-109-00	METAL CHIP	330K 5% 1/10W (S530D/S550D)	R586	1-216-109-00	METAL CHIP 330K 5% 1/10W (S530D/S550D)	
R542	1-216-069-00	METAL CHIP	6.8K 5% 1/10W (S530D/S550D)	R587	1-216-041-00	METAL CHIP 470 5% 1/10W (S530D/S550D)	
R543	1-216-109-00	METAL CHIP	330K 5% 1/10W (S530D/S550D)	R588	1-216-041-00	METAL CHIP 470 5% 1/10W (S530D/S550D)	
R544	1-216-069-00	METAL CHIP	6.8K 5% 1/10W (S530D/S550D)	R589	1-216-049-91	RES,CHIP 1K 5% 1/10W (S530D/S550D)	
R545	1-216-069-00	METAL CHIP	6.8K 5% 1/10W (S530D/S550D)	R590	1-216-025-91	RES,CHIP 100 5% 1/10W (S530D/S550D)	
R546	1-216-069-00	METAL CHIP	6.8K 5% 1/10W (S530D/S550D)	R591	1-216-025-91	RES,CHIP 100 5% 1/10W (S530D/S550D)	
R547	1-216-069-00	METAL CHIP	6.8K 5% 1/10W (S530D/S550D)	R592	1-216-049-91	RES,CHIP 1K 5% 1/10W (S530D/S550D)	
R548	1-216-069-00	METAL CHIP	6.8K 5% 1/10W (S530D/S550D)	R593	1-216-295-91	SHORT 0 (S530D/S550D)	
R549	1-216-057-00	METAL CHIP	2.2K 5% 1/10W (S530D/S550D)	R598	1-216-295-91	SHORT 0 (S530D/S550D)	
R553	1-216-057-00	METAL CHIP	2.2K 5% 1/10W (S530D/S550D)	* A-6065-260-A AU-210 BOARD, COMPLETE (S705D) ***** (Ref.No. 3,000 Series)			
R555	1-216-109-00	METAL CHIP	330K 5% 1/10W (S530D/S550D)	< CAPACITOR >			
R556	1-216-109-00	METAL CHIP	330K 5% 1/10W (S530D/S550D)	C302	1-104-665-11	ELECT 100uF 20% 10V	
R557	1-216-041-00	METAL CHIP	470 5% 1/10W (S530D/S550D)	C303	1-104-665-11	ELECT 100uF 20% 10V	
R558	1-216-041-00	METAL CHIP	470 5% 1/10W (S530D/S550D)	C304	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	
R559	1-216-049-91	RES,CHIP	1K 5% 1/10W (S530D/S550D)	C305	1-126-935-11	ELECT 470uF 20% 6.3V	
R560	1-216-025-91	RES,CHIP	100 5% 1/10W (S530D/S550D)	C306	1-126-935-11	ELECT 470uF 20% 6.3V	
R561	1-216-025-91	RES,CHIP	100 5% 1/10W (S530D/S550D)	C307	1-104-664-11	ELECT 47uF 20% 25V	
				C309	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	
				C310	1-163-259-91	CERAMIC CHIP 220PF 5% 50V	
				C311	1-163-259-91	CERAMIC CHIP 220PF 5% 50V	
				C312	1-163-259-91	CERAMIC CHIP 220PF 5% 50V	
				C313	1-163-259-91	CERAMIC CHIP 220PF 5% 50V	
				C314	1-163-259-91	CERAMIC CHIP 220PF 5% 50V	
				C315	1-163-259-91	CERAMIC CHIP 220PF 5% 50V	

AU-210

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
C316	1-126-960-11	ELECT	1uF	20%	50V	C452	1-136-850-11	FILM	0.1uF	5%	63V
C317	1-163-259-91	CERAMIC CHIP	220PF	5%	50V	C453	1-136-850-11	FILM	0.1uF	5%	63V
C318	1-104-665-11	ELECT	100uF	20%	10V	C454	1-119-828-31	ELECT	100uF	20%	50V
C319	1-104-665-11	ELECT	100uF	20%	10V	C455	1-124-673-11	ELECT	100uF	20%	10V
C320	1-104-665-11	ELECT	100uF	20%	10V	C456	1-124-673-11	ELECT	100uF	20%	10V
C321	1-163-259-91	CERAMIC CHIP	220PF	5%	50V	C457	1-124-673-11	ELECT	100uF	20%	10V
C322	1-163-259-91	CERAMIC CHIP	220PF	5%	50V	C458	1-124-673-11	ELECT	100uF	20%	10V
C323	1-126-935-11	ELECT	470uF	20%	6.3V	C459	1-124-673-11	ELECT	100uF	20%	10V
C324	1-126-935-11	ELECT	470uF	20%	6.3V	C460	1-124-673-11	ELECT	100uF	20%	10V
C325	1-126-935-11	ELECT	470uF	20%	6.3V	C461	1-104-665-11	ELECT	100uF	20%	25V
C326	1-163-259-91	CERAMIC CHIP	220PF	5%	50V	C464	1-104-665-11	ELECT	100uF	20%	25V
C327	1-163-259-91	CERAMIC CHIP	220PF	5%	50V	C465	1-128-200-11	ELECT	47uF	20%	63V
C328	1-104-664-11	ELECT	47uF	20%	25V	C466	1-163-009-11	CERAMIC CHIP	0.001uF	10%	50V
C330	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V	C467	1-128-200-11	ELECT	47uF	20%	63V
C331	1-126-967-11	ELECT	47uF	20%	25V	C468	1-136-850-11	FILM	0.1uF	5%	63V
C401	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V	C469	1-126-967-11	ELECT	47uF	20%	25V
C402	1-126-926-11	ELECT	1000uF	20%	10V	C470	1-136-850-11	FILM	0.1uF	5%	63V
C403	1-128-204-11	ELECT	470uF	20%	63V	C471	1-136-850-11	FILM	0.1uF	5%	63V
C404	1-128-204-11	ELECT	470uF	20%	63V	C472	1-136-850-11	FILM	0.1uF	5%	63V
C405	1-163-239-11	CERAMIC CHIP	33PF	5%	50V	C473	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C406	1-163-239-11	CERAMIC CHIP	33PF	5%	50V	C474	1-136-850-11	FILM	0.1uF	5%	63V
C407	1-163-239-11	CERAMIC CHIP	33PF	5%	50V	C475	1-136-850-11	FILM	0.1uF	5%	63V
C408	1-163-239-11	CERAMIC CHIP	33PF	5%	50V	C485	1-163-233-11	CERAMIC CHIP	18PF	5%	50V
C409	1-163-239-11	CERAMIC CHIP	33PF	5%	50V	C486	1-163-233-11	CERAMIC CHIP	18PF	5%	50V
C410	1-163-239-11	CERAMIC CHIP	33PF	5%	50V	C487	1-163-233-11	CERAMIC CHIP	18PF	5%	50V
C411	1-119-828-31	ELECT	100uF	20%	50V	C488	1-163-233-11	CERAMIC CHIP	18PF	5%	50V
C412	1-119-828-31	ELECT	100uF	20%	50V	C489	1-163-233-11	CERAMIC CHIP	18PF	5%	50V
C413	1-126-967-11	ELECT	47uF	20%	25V	C491	1-163-233-11	CERAMIC CHIP	18PF	5%	50V
C414	1-126-967-11	ELECT	47uF	20%	25V	< CONNECTOR >					
C415	1-126-967-11	ELECT	47uF	20%	25V						
C416	1-126-967-11	ELECT	47uF	20%	25V						
C417	1-126-967-11	ELECT	47uF	20%	25V						
C418	1-126-967-11	ELECT	47uF	20%	25V						
C419	1-136-811-11	FILM	330PF	5%	100V	* CN301	1-564-002-11	PIN, CONNECTOR 3P			
C420	1-117-793-11	MYLAR	330PF	5%	50V	* CN401	1-564-241-11	PIN, CONNECTOR (B4P-VH) 4P			
C421	1-117-793-11	MYLAR	330PF	5%	50V	CN402	1-785-698-11	CONNECTOR, FFC/FPC 28P			
C422	1-106-343-00	MYLAR	1000PF	5%	200V	CN403	1-785-695-11	CONNECTOR, FFC/FPC 13P			
						CN404	1-506-473-11	PIN, CONNECTOR 8P			
						* CN405	1-785-694-11	CONNECTOR, FFC/FPC 7P			
						* CN407	1-564-001-11	PIN, CONNECTOR 2P			
C423	1-136-811-11	FILM	330PF	5%	100V	< DIODE >					
C424	1-117-793-11	MYLAR	330PF	5%	50V						
C425	1-117-793-11	MYLAR	330PF	5%	50V						
C426	1-117-793-11	MYLAR	330PF	5%	50V						
C427	1-127-713-21	FILM	10000PF	5%	50V						
C428	1-130-483-00	MYLAR	0.01uF	5%	50V	D301	8-719-071-15	DIODE	HZM6.8ZWA1TL		
C429	1-130-484-00	MYLAR	0.012uF	5%	50V	D302	8-719-071-15	DIODE	HZM6.8ZWA1TL		
C430	1-136-850-11	FILM	0.1uF	5%	63V	D303	8-719-071-15	DIODE	HZM6.8ZWA1TL		
C431	1-127-713-21	FILM	10000PF	5%	50V	D304	8-719-071-15	DIODE	HZM6.8ZWA1TL		
C432	1-113-577-11	ELECT	47uF	20%	16V	D401	8-719-210-21	DIODE	11EQS04		
						D402	8-719-210-21	DIODE	11EQS04		
						D403	8-719-210-21	DIODE	11EQS04		
						D404	8-719-210-21	DIODE	11EQS04		
C433	1-113-577-11	ELECT	47uF	20%	16V	D405	8-719-988-61	DIODE	1SS355TE-17		
C434	1-130-483-00	MYLAR	0.01uF	5%	50V	D406	8-719-988-61	DIODE	1SS355TE-17		
C437	1-130-484-00	MYLAR	0.012uF	5%	50V						
C440	1-130-484-00	MYLAR	0.012uF	5%	50V	D407	8-719-988-61	DIODE	1SS355TE-17		
C443	1-125-853-21	FILM	470PF	5%	50V	D408	8-719-988-61	DIODE	1SS355TE-17		
						D409	8-719-988-61	DIODE	1SS355TE-17		
C444	1-130-467-00	MYLAR	470PF	5%	50V	D410	8-719-988-61	DIODE	1SS355TE-17		
C445	1-106-343-00	MYLAR	1000PF	5%	200V	D411	8-719-115-87	DIODE	RD9.1JS-T4AB2		
C446	1-130-483-00	MYLAR	0.01uF	5%	50V						
C447	1-125-853-21	FILM	470PF	5%	50V	D421	8-719-988-61	DIODE	1SS355TE-17		
C448	1-130-467-00	MYLAR	470PF	5%	50V	D422	8-719-988-61	DIODE	1SS355TE-17		
						D423	8-719-988-61	DIODE	1SS355TE-17		
C449	1-106-343-00	MYLAR	1000PF	5%	200V	D424	8-719-988-61	DIODE	1SS355TE-17		
C450	1-106-343-00	MYLAR	1000PF	5%	200V	D425	8-719-988-61	DIODE	1SS355TE-17		
C451	1-119-828-31	ELECT	100uF	20%	50V						

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
< EARTH TERMINAL >				L403	1-412-953-11	INDUCTOR 15uH	
* ET401	1-537-738-21	TERMINAL, EARTH		L404	1-412-953-11	INDUCTOR 15uH	
* ET402	1-537-738-21	TERMINAL, EARTH		L405	1-412-953-11	INDUCTOR 15uH	
* ET403	1-537-738-21	TERMINAL, EARTH		L406	1-412-953-11	INDUCTOR 15uH	
< FERRITE BEAD >				< TRANSISTOR >			
FB301	1-414-135-11	FERRITE 0UH		Q301	8-729-421-19	TRANSISTOR UN2213	
FB302	1-414-553-11	FERRITE 0UH		Q302	8-729-424-08	TRANSISTOR UN2111	
FB303	1-414-553-11	FERRITE 0UH		Q303	8-729-120-28	TRANSISTOR 2SC1623-L5L6	
FB304	1-414-553-11	FERRITE 0UH		Q401	8-729-424-08	TRANSISTOR UN2111	
FB305	1-414-553-11	FERRITE 0UH		Q402	8-729-424-08	TRANSISTOR UN2111	
FB306	1-414-553-11	FERRITE 0UH		Q403	8-729-424-08	TRANSISTOR UN2111	
FB307	1-414-553-11	FERRITE 0UH		Q404	8-729-424-08	TRANSISTOR UN2111	
FB308	1-414-553-11	FERRITE 0UH		Q405	8-729-216-22	TRANSISTOR 2SA1162	
FB309	1-414-553-11	FERRITE 0UH		Q410	8-729-046-97	TRANSISTOR 2SD1938(F)-T(TX).SO	
FB310	1-414-553-11	FERRITE 0UH		Q411	8-729-046-97	TRANSISTOR 2SD1938(F)-T(TX).SO	
FB311	1-414-553-11	FERRITE 0UH		Q412	8-729-046-97	TRANSISTOR 2SD1938(F)-T(TX).SO	
FB312	1-414-553-11	FERRITE 0UH		Q413	8-729-046-97	TRANSISTOR 2SD1938(F)-T(TX).SO	
FB313	1-414-553-11	FERRITE 0UH		Q414	8-729-046-97	TRANSISTOR 2SD1938(F)-T(TX).SO	
FB314	1-414-553-11	FERRITE 0UH		Q415	8-729-046-97	TRANSISTOR 2SD1938(F)-T(TX).SO	
FB315	1-414-553-11	FERRITE 0UH		Q416	8-729-046-97	TRANSISTOR 2SD1938(F)-T(TX).SO	
FB316	1-414-553-11	FERRITE 0UH		Q417	8-729-046-97	TRANSISTOR 2SD1938(F)-T(TX).SO	
FB317	1-414-553-11	FERRITE 0UH		Q418	8-729-046-97	TRANSISTOR 2SD1938(F)-T(TX).SO	
FB318	1-414-553-11	FERRITE 0UH		Q419	8-729-046-97	TRANSISTOR 2SD1938(F)-T(TX).SO	
FB319	1-414-553-11	FERRITE 0UH		Q420	8-729-141-10	TRANSISTOR 2SA985A	
FB320	1-414-553-11	FERRITE 0UH		Q421	8-729-141-58	TRANSISTOR 2SC2275A-QP	
FB321	1-414-553-11	FERRITE 0UH		Q422	8-729-224-62	TRANSISTOR 2SK246-GR	
FB401	1-414-553-11	FERRITE 0UH		Q423	8-729-421-19	TRANSISTOR UN2213	
FB402	1-414-553-11	FERRITE 0UH		Q424	8-729-421-19	TRANSISTOR UN2213	
< IC >				Q431	8-729-424-08	TRANSISTOR UN2111	
IC301	8-759-563-79	IC BA7660F-E2		Q432	8-729-424-08	TRANSISTOR UN2111	
IC302	8-759-563-79	IC BA7660F-E2		Q433	8-729-424-08	TRANSISTOR UN2111	
IC303	8-749-921-12	IC GP1F32T		Q434	8-729-424-08	TRANSISTOR UN2111	
IC401	8-759-008-67	IC MC14066BF		Q435	8-729-421-19	TRANSISTOR UN2213	
IC403	8-759-059-79	IC BA15532		Q437	8-729-424-08	TRANSISTOR UN2111	
IC404	8-759-059-79	IC BA15532		Q438	8-729-421-19	TRANSISTOR UN2213	
IC405	8-759-634-51	IC M5218AP		< RESISTOR >			
IC406	8-759-634-51	IC M5218AP		R301	1-216-057-00	METAL CHIP 2.2K 5%	1/10W
IC407	8-759-971-80	IC AD712JN		R302	1-216-073-00	METAL CHIP 10K 5%	1/10W
IC408	8-759-710-59	IC NJM4580D-D		R303	1-216-073-00	METAL CHIP 10K 5%	1/10W
IC409	8-759-710-59	IC NJM4580D-D		R304	1-216-063-91	RES,CHIP 3.9K 5%	1/10W
IC410	8-759-710-59	IC NJM4580D-D		R305	1-216-055-00	METAL CHIP 1.8K 5%	1/10W
IC411	8-759-711-85	IC NJM4580E-D		R306	1-216-021-00	METAL CHIP 68 5%	1/10W
IC412	8-759-711-85	IC NJM4580E-D		R307	1-216-021-00	METAL CHIP 68 5%	1/10W
IC415	8-759-604-35	IC M5F78M05		R308	1-216-021-00	METAL CHIP 68 5%	1/10W
< JACK >				R309	1-216-021-00	METAL CHIP 68 5%	1/10W
J301	1-779-382-21	JACK, PIN 1P (COAXIAL)		R310	1-216-021-00	METAL CHIP 68 5%	1/10W
J302	1-784-675-11	JACK, PIN 3P (COMPONENT VIDEO OUT)		R311	1-216-021-00	METAL CHIP 68 5%	1/10W
J303	1-785-489-11	JACK, PIN 6P (5.1CH OUTPUT)		R312	1-216-033-00	METAL CHIP 220 5%	1/10W
J304	1-778-064-11	JACK, PIN 4P (AUDIO OUT)		R313	1-216-021-00	METAL CHIP 68 5%	1/10W
J305	1-785-538-11	JACK, PIN (2P) (VIDEO OUT)		R314	1-216-025-91	RES,CHIP 100 5%	1/10W
J306	1-694-484-11	TERMINAL, S (2P.V) (S VIDEO OUT)		R315	1-216-021-00	METAL CHIP 68 5%	1/10W
< COIL >				R316	1-216-021-00	METAL CHIP 68 5%	1/10W
L301	1-412-963-11	INDUCTOR 100uH		R317	1-216-021-00	METAL CHIP 68 5%	1/10W
L303	1-412-963-11	INDUCTOR 100uH		R320	1-216-073-00	METAL CHIP 10K 5%	1/10W
L401	1-412-953-11	INDUCTOR 15uH		R348	1-216-097-91	RES,CHIP 100K 5%	1/10W
L402	1-412-953-11	INDUCTOR 15uH		R401	1-216-037-00	METAL CHIP 330 5%	1/10W
				R402	1-216-042-00	METAL CHIP 510 5%	1/10W
				R403	1-216-042-00	METAL CHIP 510 5%	1/10W

AU-210

Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
R404	1-216-042-00	METAL CHIP	510	5%	1/10W	R476	1-216-109-00	METAL CHIP	330K	5%	1/10W
R405	1-216-042-00	METAL CHIP	510	5%	1/10W	R477	1-216-109-00	METAL CHIP	330K	5%	1/10W
R406	1-216-042-00	METAL CHIP	510	5%	1/10W	R478	1-216-109-00	METAL CHIP	330K	5%	1/10W
R407	1-216-042-00	METAL CHIP	510	5%	1/10W	R479	1-259-412-11	CARBON	220	5%	1/6W
R408	1-216-073-00	METAL CHIP	10K	5%	1/10W	R480	1-216-041-00	METAL CHIP	470	5%	1/10W
R409	1-216-097-91	RES,CHIP	100K	5%	1/10W	R481	1-216-041-00	METAL CHIP	470	5%	1/10W
R410	1-216-097-91	RES,CHIP	100K	5%	1/10W	R482	1-216-041-00	METAL CHIP	470	5%	1/10W
R411	1-216-097-91	RES,CHIP	100K	5%	1/10W	R483	1-216-085-00	METAL CHIP	33K	5%	1/10W
R412	1-216-097-91	RES,CHIP	100K	5%	1/10W	R484	1-216-085-00	METAL CHIP	33K	5%	1/10W
R413	1-216-073-00	METAL CHIP	10K	5%	1/10W	R485	1-259-412-11	CARBON	220	5%	1/6W
R414	1-216-097-91	RES,CHIP	100K	5%	1/10W	R486	1-216-041-00	METAL CHIP	470	5%	1/10W
R415	1-216-295-91	SHORT	0			R487	1-216-041-00	METAL CHIP	470	5%	1/10W
R420	1-216-063-91	RES,CHIP	3.9K	5%	1/10W	R488	1-216-041-00	METAL CHIP	470	5%	1/10W
R423	1-216-109-00	METAL CHIP	330K	5%	1/10W	R489	1-216-049-91	RES,CHIP	1K	5%	1/10W
R425	1-216-109-00	METAL CHIP	330K	5%	1/10W	R490	1-216-049-91	RES,CHIP	1K	5%	1/10W
R426	1-216-109-00	METAL CHIP	330K	5%	1/10W	R491	1-216-049-91	RES,CHIP	1K	5%	1/10W
R428	1-216-109-00	METAL CHIP	330K	5%	1/10W	R492	1-216-025-91	RES,CHIP	100	5%	1/10W
R429	1-216-109-00	METAL CHIP	330K	5%	1/10W	R493	1-216-025-91	RES,CHIP	100	5%	1/10W
R430	1-216-066-00	METAL CHIP	5.1K	5%	1/10W	R494	1-216-049-91	RES,CHIP	1K	5%	1/10W
R431	1-216-109-00	METAL CHIP	330K	5%	1/10W	R495	1-216-049-91	RES,CHIP	1K	5%	1/10W
R433	1-216-066-00	METAL CHIP	5.1K	5%	1/10W	R496	1-216-025-91	RES,CHIP	100	5%	1/10W
R437	1-216-066-00	METAL CHIP	5.1K	5%	1/10W	R497	1-216-025-91	RES,CHIP	100	5%	1/10W
R438	1-216-067-00	METAL CHIP	5.6K	5%	1/10W	R498	1-216-049-91	RES,CHIP	1K	5%	1/10W
R439	1-259-452-11	CARBON	10K	5%	1/6W	R499	1-216-049-91	RES,CHIP	1K	5%	1/10W
R440	1-216-073-00	METAL CHIP	10K	5%	1/10W	R500	1-216-025-91	RES,CHIP	100	5%	1/10W
R441	1-216-073-00	METAL CHIP	10K	5%	1/10W	R501	1-216-025-91	RES,CHIP	100	5%	1/10W
R442	1-216-075-00	METAL CHIP	12K	5%	1/10W	R502	1-216-049-91	RES,CHIP	1K	5%	1/10W
R443	1-259-452-11	CARBON	10K	5%	1/6W	R504	1-216-085-00	METAL CHIP	33K	5%	1/10W
R444	1-216-073-00	METAL CHIP	10K	5%	1/10W	R505	1-216-085-00	METAL CHIP	33K	5%	1/10W
R445	1-216-073-00	METAL CHIP	10K	5%	1/10W	R506	1-259-420-11	CARBON	470	5%	1/6W
R446	1-216-073-00	METAL CHIP	10K	5%	1/10W	R507	1-259-420-11	CARBON	470	5%	1/6W
R447	1-259-426-11	CARBON	820	5%	1/6W	R508	1-259-420-11	CARBON	470	5%	1/6W
R448	1-216-047-91	RES,CHIP	820	5%	1/10W	R509	1-259-420-11	CARBON	470	5%	1/6W
R449	1-216-047-91	RES,CHIP	820	5%	1/10W	R510	1-216-085-00	METAL CHIP	33K	5%	1/10W
R450	1-216-063-91	RES,CHIP	3.9K	5%	1/10W	R511	1-216-077-00	METAL CHIP	15K	5%	1/10W
R451	1-259-426-11	CARBON	820	5%	1/6W	R512	1-216-077-00	METAL CHIP	15K	5%	1/10W
R452	1-216-047-91	RES,CHIP	820	5%	1/10W	R513	1-216-085-00	METAL CHIP	33K	5%	1/10W
R453	1-216-047-91	RES,CHIP	820	5%	1/10W	R514	1-216-025-91	RES,CHIP	100	5%	1/10W
R454	1-216-047-91	RES,CHIP	820	5%	1/10W	R515	1-216-025-91	RES,CHIP	100	5%	1/10W
R455	1-259-434-11	CARBON	1.8K	5%	1/6W	R516	1-216-049-91	RES,CHIP	1K	5%	1/10W
R456	1-259-424-11	CARBON	680	5%	1/6W	R517	1-216-049-91	RES,CHIP	1K	5%	1/10W
R457	1-259-424-11	CARBON	680	5%	1/6W	R519	1-259-440-11	CARBON	3.3K	5%	1/6W
R458	1-259-434-11	CARBON	1.8K	5%	1/6W	R520	1-259-404-11	CARBON	100	5%	1/6W
R459	1-216-055-00	METAL CHIP	1.8K	5%	1/10W	R521	1-259-440-11	CARBON	3.3K	5%	1/6W
R460	1-216-045-00	METAL CHIP	680	5%	1/10W	R523	1-259-404-11	CARBON	100	5%	1/6W
R461	1-216-045-00	METAL CHIP	680	5%	1/10W	R524	1-259-466-11	CARBON	39K	5%	1/6W
R462	1-216-055-00	METAL CHIP	1.8K	5%	1/10W	R525	1-259-404-11	CARBON	100	5%	1/6W
R463	1-216-055-00	METAL CHIP	1.8K	5%	1/10W	R526	1-216-081-00	METAL CHIP	22K	5%	1/10W
R464	1-216-045-00	METAL CHIP	680	5%	1/10W	R531	1-216-097-91	RES,CHIP	100K	5%	1/10W
R465	1-216-045-00	METAL CHIP	680	5%	1/10W	R532	1-216-097-91	RES,CHIP	100K	5%	1/10W
R466	1-216-055-00	METAL CHIP	1.8K	5%	1/10W	R533	1-216-097-91	RES,CHIP	100K	5%	1/10W
R467	1-216-055-00	METAL CHIP	1.8K	5%	1/10W	R534	1-216-097-91	RES,CHIP	100K	5%	1/10W
R468	1-216-045-00	METAL CHIP	680	5%	1/10W	R536	1-216-295-91	SHORT	0		
R469	1-216-061-00	METAL CHIP	3.3K	5%	1/10W	R538	1-216-295-91	SHORT	0		
R470	1-216-075-00	METAL CHIP	12K	5%	1/10W	R539	1-216-295-91	SHORT	0		
R471	1-216-109-00	METAL CHIP	330K	5%	1/10W	R540	1-216-295-91	SHORT	0		
R472	1-216-109-00	METAL CHIP	330K	5%	1/10W	R542	1-259-445-11	CARBON	5.1K	5%	1/6W
R473	1-216-109-00	METAL CHIP	330K	5%	1/10W	R543	1-259-445-11	CARBON	5.1K	5%	1/6W
R474	1-216-109-00	METAL CHIP	330K	5%	1/10W	R544	1-216-063-91	RES,CHIP	3.9K	5%	1/10W
R475	1-216-109-00	METAL CHIP	330K	5%	1/10W	R545	1-216-059-00	METAL CHIP	2.7K	5%	1/10W

Ref. No.	Part No.	Description			Remark
R546	1-216-085-00	METAL CHIP	33K	5%	1/10W
R547	1-216-059-00	METAL CHIP	2.7K	5%	1/10W
R548	1-259-445-11	CARBON	5.1K	5%	1/6W
R549	1-259-445-11	CARBON	5.1K	5%	1/6W
R550	1-216-081-00	METAL CHIP	22K	5%	1/10W
R552	1-216-066-00	METAL CHIP	5.1K	5%	1/10W
R553	1-216-066-00	METAL CHIP	5.1K	5%	1/10W
R556	1-216-066-00	METAL CHIP	5.1K	5%	1/10W
R557	1-216-066-00	METAL CHIP	5.1K	5%	1/10W
*	A-6065-263-A	FL-97 BOARD, COMPLETE (S330)			
*	A-6065-240-A	FL-99 BOARD, COMPLETE (S705D)			
*	A-6065-220-A	FL-101 BOARD, COMPLETE			
		(S530D: US, Canadian)			
*	A-6065-223-A	FL-101 BOARD, COMPLETE(S530D: E)			
*	A-6065-236-A	FL-101 BOARD, COMPLETE(S550D)			

		(Ref.No. 2,000 Series)			
	3-053-487-01	HOLDER, FL TUBE			
		< CAPACITOR >			
C201	1-124-259-11	ELECT	4.7uF	20%	16V
C203	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C204	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
		(S330/530D: US, Canadian/S550D)			
C205	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C206	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
		(S330/530D: US, Canadian/S550D)			
C207	1-163-009-11	CERAMIC CHIP	0.001uF	10%	50V
		(S330/530D: US, Canadian/S550D)			
C208	1-163-009-11	CERAMIC CHIP	0.001uF	10%	50V
		(S330/530D: US, Canadian/S550D)			
C209	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
		(S550D/S705D)			
C210	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
		(S550D/S705D)			
C211	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C212	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
		(S530D/S550D/S705D)			
C213	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
		(S530D/S550D/S705D)			
C214	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
		(S530D/S550D/S705D)			
C215	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
C216	1-163-021-91	CERAMIC CHIP	0.01uF	10%	50V
C219	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C220	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C221	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C222	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C223	1-128-131-11	ELECT	22uF	20%	50V
C235	1-163-001-11	CERAMIC CHIP	220PF	10%	50V
C236	1-163-001-11	CERAMIC CHIP	220PF	10%	50V
C237	1-163-001-11	CERAMIC CHIP	220PF	10%	50V
C238	1-163-001-11	CERAMIC CHIP	220PF	10%	50V
C239	1-163-001-11	CERAMIC CHIP	220PF	10%	50V
C240	1-163-001-11	CERAMIC CHIP	220PF	10%	50V
C241	1-163-001-11	CERAMIC CHIP	220PF	10%	50V
C242	1-163-001-11	CERAMIC CHIP	220PF	10%	50V
C243	1-163-001-11	CERAMIC CHIP	220PF	10%	50V

Ref. No.	Part No.	Description	Remark
< CONNECTOR >			
CN201	1-568-666-11	CONNECTOR, BOARD TO BOARD 12P	
CN202	1-785-731-21	CONNECTOR, FFC/FPC 17P	
CN203	1-785-730-21	CONNECTOR, FFC/FPC 9P	
< DIODE >			
D202	8-719-988-61	DIODE 1SS355TE-17	
D203	8-719-069-45	DIODE SELU5E23C-TP15 (DOLBY DIGITAL) (S530D/S550D)	
D203	8-719-069-45	DIODE SELU5E23C-TP15 (MULTI CANNEL) (S705D)	
D204	8-719-056-06	DIODE SLR-342DCT31 (JOG) (S530D/S550D/S705D)	
D205	8-719-073-03	DIODE MA8082-(K8).S0 (S330/S530D: US, Canadian/S550D)	
D206	8-719-018-12	DIODE MA8330-L-TX	
D207	8-719-422-67	DIODE MA8062-H-TX	
< EARTH TERMINAL >			
* ET201	1-537-738-21	TERMINAL, EARTH (S705D)	
< FERRITE BEAD >			
FB201	1-414-135-11	FERRITE 0UH	
< IC >			
IC201	8-759-574-86	IC M38B57MCH-E206FP	
IC202	8-759-326-78	IC PST9140NL	
IC203	8-759-356-27	IC NJM2129M-TE2 (S330/S530D: US, Canadian/S550D)	
< JUMPER RESISTOR >			
JR201	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR202	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR203	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR204	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR205	1-216-296-91	SHORT 0 (S330/S530D/S550D)	
JR206	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR207	1-216-296-91	SHORT 0 (S330/S530D/S550D)	
JR208	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR209	1-216-296-91	SHORT 0 (S330/S530D/S550D)	
JR210	1-216-296-91	SHORT 0 (S330/S530D/S550D)	
JR211	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR212	1-216-296-91	SHORT 0 (S330/S530D/S550D)	
JR214	1-216-296-91	SHORT 0 (S330/S530D/S550D)	
JR216	1-216-296-91	SHORT 0 (S330/S530D/S550D)	
JR217	1-216-296-91	SHORT 0 (S330/S530D/S550D)	
JR218	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR219	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR220	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR224	1-216-296-91	SHORT 0 (S330/S530D/S550D)	
JR226	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR229	1-216-296-91	SHORT 0 (S330/S530D/S550D)	
JR230	1-216-296-91	SHORT 0 (S330/S530D/S550D)	
JR231	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR233	1-216-296-91	SHORT 0 (S330/S530D/S550D)	
JR234	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR235	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR236	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR237	1-216-295-91	SHORT 0 (S330/S530D/S550D)	
JR238	1-216-296-91	SHORT 0 (S330/S530D/S550D)	

FL-97

FL-99

FL-101

Ref. No.	Part No.	Description	Remark		
JR244	1-216-295-91	SHORT	0 (S330/S530D/S550D)		
JR249	1-216-296-91	SHORT	0 (S330/S530D/S550D)		
		< FLUORECENT INDICATOR >			
ND201	1-517-836-11	INDICATOR TUBE, FLUORESCENT			
		< TRANSISTOR >			
Q201	8-729-804-41	TRANSISTOR 2SB1122-S			
		< RESISTOR >			
R201	1-216-073-00	METAL CHIP	10K	5%	1/10W
R202	1-216-053-00	METAL CHIP	1.5K	5%	1/10W
R203	1-216-055-00	METAL CHIP	1.8K	5%	1/10W
R204	1-216-059-00	METAL CHIP	2.7K	5%	1/10W
R205	1-216-061-00	METAL CHIP	3.3K	5%	1/10W
R206	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R207	1-216-071-00	METAL CHIP	8.2K	5%	1/10W
R208	1-216-077-00	METAL CHIP	15K	5%	1/10W
			(S530D/S550D/S705D)		
R209	1-216-091-00	METAL CHIP	56K	5%	1/10W
			(S550D/S705D)		
R211	1-216-073-00	METAL CHIP	10K	5%	1/10W
R212	1-216-053-00	METAL CHIP	1.5K	5%	1/10W
R213	1-216-055-00	METAL CHIP	1.8K	5%	1/10W
R214	1-216-059-00	METAL CHIP	2.7K	5%	1/10W
R215	1-216-061-00	METAL CHIP	3.3K	5%	1/10W
R216	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R217	1-216-071-00	METAL CHIP	8.2K	5%	1/10W
R218	1-216-077-00	METAL CHIP	15K	5%	1/10W
R221	1-216-073-00	METAL CHIP	10K	5%	1/10W
R222	1-216-053-00	METAL CHIP	1.5K	5%	1/10W
			(S530D/S550D/S705D)		
R223	1-216-055-00	METAL CHIP	1.8K	5%	1/10W
			(S530D/S550D/S705D)		
R224	1-216-059-00	METAL CHIP	2.7K	5%	1/10W
			(S530D/S550D/S705D)		
R225	1-216-061-00	METAL CHIP	3.3K	5%	1/10W
			(S530D/S550D/S705D)		
R226	1-216-025-91	RES,CHIP	100	5%	1/10W
			(S530D/S550D/S705D)		
R227	1-216-025-91	RES,CHIP	100	5%	1/10W
			(S530D/S550D/S705D)		
R229	1-216-063-91	RES,CHIP	3.9K	5%	1/10W
R230	1-216-073-00	METAL CHIP	10K	5%	1/10W
R231	1-216-025-91	RES,CHIP	100	5%	1/10W
R232	1-216-025-91	RES,CHIP	100	5%	1/10W
R241	1-216-073-00	METAL CHIP	10K	5%	1/10W
R243	1-216-073-00	METAL CHIP	10K	5%	1/10W
R244	1-216-073-00	METAL CHIP	10K	5%	1/10W
R247	1-216-073-00	METAL CHIP	10K	5%	1/10W
R248	1-216-073-00	METAL CHIP	10K	5%	1/10W
R249	1-216-073-00	METAL CHIP	10K	5%	1/10W
R250	1-216-073-00	METAL CHIP	10K	5%	1/10W
R251	1-216-049-91	RES,CHIP	1K	5%	1/10W
R252	1-216-049-91	RES,CHIP	1K	5%	1/10W
R253	1-216-073-00	METAL CHIP	10K	5%	1/10W
R254	1-216-073-00	METAL CHIP	10K	5%	1/10W
R255	1-216-073-00	METAL CHIP	10K	5%	1/10W
R256	1-216-073-00	METAL CHIP	10K	5%	1/10W
R257	1-216-025-91	RES,CHIP	100	5%	1/10W

Ref. No.	Part No.	Description	Remark		
R258	1-216-025-91	RES,CHIP	100	5%	1/10W
R259	1-216-025-91	RES,CHIP	100	5%	1/10W
R260	1-216-025-91	RES,CHIP	100	5%	1/10W
R261	1-216-025-91	RES,CHIP	100	5%	1/10W
R262	1-216-025-91	RES,CHIP	100	5%	1/10W
R263	1-216-073-00	METAL CHIP	10K	5%	1/10W
			(S530D/S550D/S705D)		
R264	1-216-073-00	METAL CHIP	10K	5%	1/10W
R266	1-216-049-91	RES,CHIP	1K	5%	1/10W
			(S550D)		
R266	1-216-073-00	METAL CHIP	10K	5%	1/10W
			(S330)		
R266	1-216-057-00	METAL CHIP	2.2K	5%	1/10W
			(S705D)		
R267	1-216-049-91	RES,CHIP	1K	5%	1/10W
R268	1-216-089-91	RES,CHIP	47K	5%	1/10W
R270	1-216-073-00	METAL CHIP	10K	5%	1/10W
R271	1-216-073-00	METAL CHIP	10K	5%	1/10W
R272	1-216-065-91	RES,CHIP	4.7K	5%	1/10W
R273	1-216-025-91	RES,CHIP	100	5%	1/10W
R274	1-216-097-91	RES,CHIP	100K	5%	1/10W
R275	1-216-073-00	METAL CHIP	10K	5%	1/10W
R276	1-216-073-00	METAL CHIP	10K	5%	1/10W
R277	1-216-073-00	METAL CHIP	10K	5%	1/10W
R278	1-216-073-00	METAL CHIP	10K	5%	1/10W
R279	1-216-073-00	METAL CHIP	10K	5%	1/10W
R280	1-216-073-00	METAL CHIP	10K	5%	1/10W
			(S330)		
R281	1-216-049-91	RES,CHIP	1K	5%	1/10W
			(S330/S530D: US, Canadian/S550D)		
R282	1-216-049-91	RES,CHIP	1K	5%	1/10W
			(S330/S530D: US, Canadian/S550D)		
R283	1-216-295-91	SHORT	0		
			(S330/S530D: US, Canadian/S550D)		
R284	1-216-073-00	METAL CHIP	10K	5%	1/10W
R285	1-216-045-00	METAL CHIP	680	5%	1/10W
			(S530D/S550D/S705D)		
R286	1-216-073-00	METAL CHIP	10K	5%	1/10W
R287	1-216-037-00	METAL CHIP	330	5%	1/10W
			(S530D/S550D/S705D)		
R288	1-216-073-00	METAL CHIP	10K	5%	1/10W
R289	1-216-073-00	METAL CHIP	10K	5%	1/10W
R298	1-216-025-91	RES,CHIP	100	5%	1/10W
			(S550D/S705D)		
R299	1-216-025-91	RES,CHIP	100	5%	1/10W
			(S550D/S705D)		
		< SWITCH >			
S201	1-771-349-21	SWITCH, KEYBOARD (■)			
S202	1-771-349-21	SWITCH, KEYBOARD (■)			
S208	1-771-349-21	SWITCH, KEYBOARD (JOG)			
			(S530D/S550D/S705D)		
S212	1-771-349-21	SWITCH, KEYBOARD (≡OPEN/CLOSE)			
S213	1-771-349-21	SWITCH, KEYBOARD (▷)			
S214	1-771-349-21	SWITCH, KEYBOARD (TITLE)			
S215	1-771-349-21	SWITCH, KEYBOARD (DVD MENU)			
S216	1-771-349-21	SWITCH, KEYBOARD (RETURN)			
S217	1-771-349-21	SWITCH, KEYBOARD (PREV◀◀)			
			(S330/S530D)		
S217	1-771-349-21	SWITCH, KEYBOARD (◀◀SEARCH)			
			(S550D/S705D)		

				FL-97	FL-99	FL-101	FR-146	FR-148
				FR-150	HP-109	HP-111	MB-82	MB-85
Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark	
S218	1-771-349-21	SWITCH, KEYBOARD (▶▶NEXT) (S330/S530D)				< RESISTOR >		
S218	1-771-349-21	SWITCH, KEYBOARD (SEARCH▶▶) (S550D/S705D)		R002	1-216-073-00	METAL CHIP 10K 5% 1/10W		
S221	1-771-349-21	SWITCH, KEYBOARD (REPEAT) (S530D/S550D/S705D)		R003	1-216-073-00	METAL CHIP 10K 5% 1/10W		
S222	1-771-349-21	SWITCH, KEYBOARD (CLEAR) (S530D/S550D/S705D)		R071	1-216-047-91	RES,CHIP 820 5% 1/10W		
S223	1-771-349-21	SWITCH, KEYBOARD (PROGRAM) (S530D/S550D/S705D)		R072	1-216-037-00	METAL CHIP 330 5% 1/10W		
						< SWITCH >		
S224	1-771-349-21	SWITCH, KEYBOARD (SHUFFLE) (S530D/S550D/S705D)		S071	1-771-349-21	SWITCH, KEYBOARD (I/⏻)		
S230	1-475-235-21	ENCODER, ROTARY (PREV◀◀, ▶▶NEXT) (S550D/S705D)				< TRANSFORMER >		
		< VIBRATOR >		T001	1-433-748-11	TRANSFORMER, DC-DC CONVERTER		
X201	1-577-358-21	VIBRATOR, CERAMIC (4MHz)						
				*	A-6065-257-A	HP-109 BOARD, COMPLETE (S705D)		
				*	A-6065-219-A	HP-111 BOARD, COMPLETE (S530D/S550D)		

						(Ref.No. 3,000 Series)		
						< CONNECTOR >		
*	A-6065-262-A	FR-146 BOARD, COMPLETE (S330)						
*	A-6065-241-A	FR-148 BOARD, COMPLETE (S705D)						
*	A-6065-218-A	FR-150 BOARD, COMPLETE (S530D)		* CN701	1-564-013-11	PIN, CONNECTOR 3P		
*	A-6065-237-A	FR-150 BOARD, COMPLETE (S550D)				< CAPACITOR >		
						(Ref.No. 4,000 Series)		
						< CAPACITOR >		
C001	1-124-234-00	ELECT 22uF 20% 16V		C701	1-163-011-11	CERAMIC CHIP 0.0015uF 10% 50V		
C002	1-137-150-11	FILM 0.01uF 5% 100V		C702	1-163-011-11	CERAMIC CHIP 0.0015uF 10% 50V		
C003	1-115-339-11	CERAMIC CHIP 0.1uF 10% 50V				< DIODE >		
C004	1-115-339-11	CERAMIC CHIP 0.1uF 10% 50V		D701	8-719-071-15	DIODE HZM6.8ZWA1TL		
C005	1-128-131-11	ELECT 22uF 20% 50V		D702	8-719-071-15	DIODE HZM6.8ZWA1TL		
C051	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V				< FERRITE BEAD >		
						< CONNECTOR >		
CN001	1-506-485-11	PIN, CONNECTOR 6P		FB701	1-414-135-11	FERRITE 0UH		
CN002	1-568-672-11	CONNECTOR, BOARD TO BOARD 12P		FB702	1-414-135-11	FERRITE 0UH		
CN003	1-785-712-11	CONNECTOR, BOARD TO BOARD 4P (S530D/S550D/S705D)		FB703	1-414-135-11	FERRITE 0UH		
						< JACK >		
						< DIODE >		
D001	8-719-041-97	DIODE MA113-(TX)		J701	1-785-505-31	JACK, LARGE TYPE (PHONES) (S530D/S550D)		
D002	8-719-041-97	DIODE MA113-(TX)		J701	1-785-505-41	JACK, LARGE TYPE (PHONES) (S705D)		
D003	8-719-041-97	DIODE MA113-(TX)				< JUMPER RESISTOR >		
D004	8-719-041-97	DIODE MA113-(TX)						
D071	8-719-064-11	DIODE SPR-325MVW (ON/STANDBY)		JR701	1-216-295-91	SHORT 0 (S530D/S550D)		
						< VARIABLE RESISTOR >		
						< FERRITE BEAD >		
FB001	1-414-135-11	FERRITE 0UH		RV701	1-225-738-11	RES, VAR, CARBON 500/500 (LEVEL)		
FB002	1-414-135-11	FERRITE 0UH						
FB004	1-469-324-21	FERRITE 0UH						
						< IC >		
IC051	8-749-011-22	IC GP1U27X						
						< COIL >		
L001	1-408-978-21	INDUCTOR 47uH						
						< TRANSISTOR >		
Q001	8-729-808-41	TRANSISTOR 2SD1624-S						
Q002	8-729-808-41	TRANSISTOR 2SD1624-S						
						< CAPACITOR >		
				C001	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V		
				C002	1-164-227-11	CERAMIC CHIP 0.022uF 10% 25V		
				C003	1-126-246-11	ELECT CHIP 220uF 20% 4V		
				C004	1-126-204-11	ELECT CHIP 47uF 20% 16V		

MB-82**MB-85**

Ref. No.	Part No.	Description			Remark
C005	1-126-206-11	ELECT CHIP	100uF	20%	6.3V
C007	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C008	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C010	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C011	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C012	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C013	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C015	1-126-246-11	ELECT CHIP	220uF	20%	4V
C016	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C017	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C018	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C019	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C201	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
C202	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
C203	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C204	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C206	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C209	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C210	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C211	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C212	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C213	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C304	1-110-563-11	CERAMIC CHIP	0.068uF	10%	16V
C307	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C309	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
C310	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C312	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C313	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C314	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C315	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C316	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C317	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C318	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C319	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C320	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C321	1-126-206-11	ELECT CHIP	100uF	20%	6.3V
C322	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C323	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C324	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C325	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
C327	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C328	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C329	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C331	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C333	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C334	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C337	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C338	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C339	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C341	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C343	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C344	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C401	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C402	1-126-209-11	ELECT CHIP	100uF	20%	4V
C403	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
C404	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
C405	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C406	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C408	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C410	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V

Ref. No.	Part No.	Description			Remark
C411	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C413	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C414	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C415	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C416	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C418	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C420	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C422	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C425	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C426	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C428	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C431	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C432	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C433	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C434	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C436	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C438	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C439	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C440	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C441	1-126-209-11	ELECT CHIP	100uF	20%	4V
C443	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C502	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (S550D/S705D)
C505	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (S530D/S550D/S705D)
C506	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (S530D/S550D/S705D)
C508	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (S530D/S550D/S705D)
C510	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (S530D/S550D/S705D)
C512	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (S530D/S550D/S705D)
C513	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (S550D/S705D)
C514	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (S550D/S705D)
C515	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (S550D/S705D)
C516	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (S550D/S705D)
C517	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V (S550D/S705D)
C601	1-104-851-11	TANTAL. CHIP	10uF	20%	10V
C602	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C603	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C604	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C605	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C606	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C607	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C608	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C701	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C702	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C703	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
C704	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
C705	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C706	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C707	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C708	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V
C709	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V
C710	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C711	1-107-826-91	CERAMIC CHIP	0.1uF	10%	16V

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
C712	1-162-968-11	CERAMIC CHIP	0.0047uF 10% 50V	C914	1-104-851-11	TANTAL. CHIP	10uF 20% 10V (S530D/S550D/S705D)
C713	1-162-968-11	CERAMIC CHIP	0.0047uF 10% 50V	C916	1-163-021-91	CERAMIC CHIP	0.01uF 10% 50V (S530D/S550D)
C714	1-162-968-11	CERAMIC CHIP	0.0047uF 10% 50V	C916	1-127-950-21	FILM CHIP	0.01uF 5% 16.5V (S705D)
C715	1-162-968-11	CERAMIC CHIP	0.0047uF 10% 50V	C922	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V (S530D/S550D)
C717	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	C922	1-127-950-21	FILM CHIP	0.01uF 5% 16.5V (S705D)
C801	1-126-204-11	ELECT CHIP	47uF 20% 16V	C923	1-107-826-91	CERAMIC CHIP	0.1uF 10% 16V
C802	1-107-826-91	CERAMIC CHIP	0.1uF 10% 16V	C924	1-104-851-11	TANTAL. CHIP	10uF 20% 10V (S530D/S550D/S705D)
C803	1-107-826-91	CERAMIC CHIP	0.1uF 10% 16V	C925	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V (S530D/S550D/S705D)
C805	1-162-923-11	CERAMIC CHIP	47PF 5% 50V	C926	1-107-826-91	CERAMIC CHIP	0.1uF 10% 16V (S530D/S550D/S705D)
C806	1-162-923-11	CERAMIC CHIP	47PF 5% 50V	C927	1-104-851-11	TANTAL. CHIP	10uF 20% 10V (S530D/S550D/S705D)
C807	1-162-927-11	CERAMIC CHIP	100PF 5% 50V	C928	1-128-391-11	ELECT CHIP	330uF 20% 6.3V (S530D/S550D/S705D)
C808	1-162-927-11	CERAMIC CHIP	100PF 5% 50V	C929	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V (S530D/S550D/S705D)
C809	1-110-563-11	CERAMIC CHIP	0.068uF 10% 16V	C931	1-107-826-91	CERAMIC CHIP	0.1uF 10% 16V (S530D/S550D/S705D)
C810	1-110-563-11	CERAMIC CHIP	0.068uF 10% 16V	C932	1-104-851-11	TANTAL. CHIP	10uF 20% 10V (S530D/S550D/S705D)
C811	1-165-176-11	CERAMIC CHIP	0.047uF 10% 16V	C933	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V (S530D/S550D/S705D)
C812	1-162-967-11	CERAMIC CHIP	0.0033uF 10% 50V	C934	1-107-826-91	CERAMIC CHIP	0.1uF 10% 16V (S530D/S550D/S705D)
C813	1-162-967-11	CERAMIC CHIP	0.0033uF 10% 50V	C935	1-104-851-11	TANTAL. CHIP	10uF 20% 10V (S530D/S550D/S705D)
C814	1-165-176-11	CERAMIC CHIP	0.047uF 10% 16V	C937	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V (S530D/S550D/S705D)
C815	1-110-666-11	ELECT CHIP	22uF 20% 6.3V	C939	1-107-826-91	CERAMIC CHIP	0.1uF 10% 16V (S530D/S550D/S705D)
C816	1-104-601-11	ELECT CHIP	10uF 20% 10V	C940	1-104-851-11	TANTAL. CHIP	10uF 20% 10V (S530D/S550D/S705D)
C817	1-115-467-11	CERAMIC CHIP	0.22uF 10% 10V	< CONNECTOR >			
C818	1-107-826-91	CERAMIC CHIP	0.1uF 10% 16V	CN001	1-785-728-21	PIN (PC BOARD), CONNECTOR 7P	
C819	1-107-826-91	CERAMIC CHIP	0.1uF 10% 16V	CN002	1-779-936-11	CONNECTOR, FFC/FPC 18P	
C820	1-162-957-11	CERAMIC CHIP	220PF 5% 50V	CN003	1-779-936-11	CONNECTOR, FFC/FPC 18P	
C821	1-162-957-11	CERAMIC CHIP	220PF 5% 50V	CN004	1-778-772-11	CONNECTOR, FFC/FPC 7P (S530D/S550D/S705D)	
C822	1-126-204-11	ELECT CHIP	47uF 20% 16V	CN005	1-784-327-11	CONNECTOR, FFC/FPC 28P	
C823	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	CN006	1-774-768-11	CONNECTOR, FFC/FPC 17P	
C824	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	CN007	1-778-274-11	CONNECTOR, FFC/FPC 13P (S530D/S550D/S705D)	
C825	1-162-970-11	CERAMIC CHIP	0.01uF 10% 25V	CN010	1-573-806-21	PIN, CONNECTOR (1.5MM) (SMD)6P	
C830	1-107-826-91	CERAMIC CHIP	0.1uF 10% 16V	CN011	1-573-806-21	PIN, CONNECTOR (1.5MM) (SMD)6P	
C831	1-107-826-91	CERAMIC CHIP	0.1uF 10% 16V	* CN012	1-573-768-21	PIN, CONNECTOR (1.5MM) (SMD)5P	
C832	1-107-826-91	CERAMIC CHIP	0.1uF 10% 16V	< DIODE >			
C833	1-164-677-11	CERAMIC CHIP	0.033uF 10% 16V	D701	8-719-988-61	DIODE 1SS355TE-17	
C834	1-164-677-11	CERAMIC CHIP	0.033uF 10% 16V	D801	8-719-941-09	DIODE DAP202U	
C835	1-107-826-91	CERAMIC CHIP	0.1uF 10% 16V	D802	8-719-988-61	DIODE 1SS355TE-17	
C836	1-115-467-11	CERAMIC CHIP	0.22uF 10% 10V	D803	8-719-941-09	DIODE DAP202U	
C837	1-115-467-11	CERAMIC CHIP	0.22uF 10% 10V	D804	8-719-941-86	DIODE DAN202U	
C904	1-163-021-91	CERAMIC CHIP	0.01uF 10% 50V (S530D/S550D/S705D)	D805	8-719-941-86	DIODE DAN202U	
C905	1-163-021-91	CERAMIC CHIP	0.01uF 10% 50V	D806	8-719-988-61	DIODE 1SS355TE-17	
C906	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V (S330/S530D/S550D)	D807	8-719-988-61	DIODE 1SS355TE-17	
C906	1-127-950-21	FILM CHIP	0.01uF 5% 16.5V (S705D)				
C907	1-104-851-11	TANTAL. CHIP	10uF 20% 10V				
C908	1-128-391-11	ELECT CHIP	330uF 20% 6.3V (S330/S530D/S550D)				
C909	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V (S330/S530D/S550D)				
C909	1-127-950-21	FILM CHIP	0.01uF 5% 16.5V (S705D)				
C910	1-104-851-11	TANTAL. CHIP	10uF 20% 10V				
C911	1-163-021-91	CERAMIC CHIP	0.01uF 10% 50V (S330/S530D/S550D)				
C911	1-127-950-21	FILM CHIP	0.01uF 5% 16.5V (S705D)				
C912	1-127-516-11	ELECT	220uF 20% 10V (S705D)				
C913	1-164-004-11	CERAMIC CHIP	0.1uF 10% 25V (S530D/S550D)				
C913	1-127-950-21	FILM CHIP	0.01uF 5% 16.5V				

Ref. No.	Part No.	Description	Remark			
< FERRITE BEAD >						
FB001	1-469-324-21	FERRITE	OUH			
FB002	1-469-324-21	FERRITE	OUH			
FB003	1-469-324-21	FERRITE	OUH			
FB004	1-469-324-21	FERRITE	OUH			
FB005	1-469-324-21	FERRITE	OUH			
FB006	1-469-324-21	FERRITE	OUH			
FB007	1-469-324-21	FERRITE	OUH			
FB008	1-469-324-21	FERRITE	OUH			
FB010	1-469-116-21	FERRITE	OUH (S530D/S550D/S705D)			
FB011	1-469-116-21	FERRITE	OUH (S530D/S550D/S705D)			
FB012	1-469-116-21	FERRITE	OUH (S530D/S550D/S705D)			
FB014	1-469-116-21	FERRITE	OUH			
FB015	1-469-116-21	FERRITE	OUH			
FB016	1-216-801-11	METAL CHIP	22	5%	1/16W	
FB017	1-469-116-21	FERRITE	OUH			
FB018	1-469-116-21	FERRITE	OUH			
FB019	1-469-116-21	FERRITE	OUH			
FB020	1-469-116-21	FERRITE	OUH			
FB021	1-469-116-21	FERRITE	OUH			
FB022	1-469-116-21	FERRITE	OUH			
FB024	1-469-116-21	FERRITE	OUH			
FB026	1-469-116-21	FERRITE	OUH			
FB028	1-469-116-21	FERRITE	OUH			
FB029	1-469-324-21	FERRITE	OUH			
FB030	1-469-116-21	FERRITE	OUH			
FB031	1-469-116-21	FERRITE	OUH			
FB032	1-469-116-21	FERRITE	OUH			
FB033	1-469-116-21	FERRITE	OUH			
FB035	1-469-116-21	FERRITE	OUH			
FB037	1-469-116-21	FERRITE	OUH			
FB040	1-469-116-21	FERRITE	OUH			
FB043	1-500-283-11	INDUCTOR CHIP	OUH			
FB047	1-469-116-21	FERRITE	OUH			
FB049	1-469-116-21	FERRITE	OUH			
FB051	1-469-116-21	FERRITE	OUH			
FB052	1-500-283-11	INDUCTOR CHIP	OUH			
		(S330/S530D: US, Canadian/S550D)				
FB053	1-500-283-11	INDUCTOR CHIP	OUH			
FB054	1-500-283-11	INDUCTOR CHIP	OUH			
FB055	1-500-283-11	INDUCTOR CHIP	OUH			
FB056	1-500-283-11	INDUCTOR CHIP	OUH			
FB058	1-500-283-11	INDUCTOR CHIP	OUH			
FB060	1-500-283-11	INDUCTOR CHIP	OUH			
FB061	1-469-116-21	FERRITE	OUH (S530D/S550D/S705D)			
FB063	1-469-116-21	FERRITE	OUH (S530D/S550D/S705D)			
FB065	1-469-116-21	FERRITE	OUH (S530D/S550D/S705D)			
FB067	1-469-116-21	FERRITE	OUH (S530D/S550D/S705D)			
FB069	1-469-116-21	FERRITE	OUH (S530D/S550D/S705D)			
FB071	1-469-116-21	FERRITE	OUH (S530D/S550D/S705D)			
FB073	1-469-116-21	FERRITE	OUH (S530D/S550D/S705D)			
FB075	1-469-116-21	FERRITE	OUH (S530D/S550D/S705D)			
FB077	1-469-116-21	FERRITE	OUH (S530D/S550D/S705D)			
FB078	1-216-801-11	METAL CHIP	22	5%	1/16W	
		(S530D/S550D/S705D)				
FB080	1-216-801-11	METAL CHIP	22	5%	1/16W	
FB081	1-216-801-11	METAL CHIP	22	5%	1/16W	
FB083	1-216-801-11	METAL CHIP	22	5%	1/16W	
FB084	1-216-801-11	METAL CHIP	22	5%	1/16W	

Ref. No.	Part No.	Description	Remark			
FB085	1-216-801-11	METAL CHIP	22	5%	1/16W	
FB086	1-216-801-11	METAL CHIP	22	5%	1/16W	
		(S550D/S705D)				
FB087	1-216-801-11	METAL CHIP	22	5%	1/16W	
FB088	1-216-801-11	METAL CHIP	22	5%	1/16W	
		(S530D/S550D/S705D)				
FB090	1-469-116-21	FERRITE	OUH (S550D)			
FB105	1-469-324-21	FERRITE	OUH			
FB106	1-469-324-21	FERRITE	OUH			
< FILTER >						
FL001	1-234-177-21	FILTER, CHIP EMI				
FL002	1-234-177-21	FILTER, CHIP EMI				
FL003	1-233-893-21	FILTER, CHIP EMI				
FL004	1-233-893-21	FILTER, CHIP EMI				
FL005	1-234-177-21	FILTER, CHIP EMI				
FL006	1-234-177-21	FILTER, CHIP EMI				
FL008	1-234-177-21	FILTER, CHIP EMI				
FL009	1-234-177-21	FILTER, CHIP EMI				
FL010	1-234-177-21	FILTER, CHIP EMI				
FL014	1-234-177-21	FILTER, CHIP EMI				
FL015	1-234-177-21	FILTER, CHIP EMI				
FL016	1-234-177-21	FILTER, CHIP EMI				
FL202	1-234-177-21	FILTER, CHIP EMI				
FL203	1-234-177-21	FILTER, CHIP EMI				
FL204	1-234-177-21	FILTER, CHIP EMI				
FL205	1-234-177-21	FILTER, CHIP EMI				
FL301	1-234-177-21	FILTER, CHIP EMI				
FL302	1-234-177-21	FILTER, CHIP EMI				
FL303	1-234-177-21	FILTER, CHIP EMI				
FL401	1-234-177-21	FILTER, CHIP EMI				
FL402	1-234-177-21	FILTER, CHIP EMI				
FL403	1-234-177-21	FILTER, CHIP EMI				
FL404	1-234-177-21	FILTER, CHIP EMI				
FL405	1-234-177-21	FILTER, CHIP EMI				
FL501	1-234-177-21	FILTER, CHIP EMI (S550D/S705D)				
FL502	1-234-177-21	FILTER, CHIP EMI (S530D/S550D/S705D)				
FL503	1-234-177-21	FILTER, CHIP EMI (S550D/S705D)				
FL601	1-234-177-21	FILTER, CHIP EMI				
FL602	1-234-177-21	FILTER, CHIP EMI (S550D/S705D)				
FL701	1-234-177-21	FILTER, CHIP EMI				
FL904	1-234-177-21	FILTER, CHIP EMI (S530D/S550D/S705D)				
< IC >						
IC001	8-759-567-31	IC PLL1700E/2K				
IC003	8-759-531-92	IC TC7WH04FU(TE12R)				
IC004	8-759-531-92	IC TC7WH04FU(TE12R)				
IC005	8-759-486-55	IC NJM2370U33-TE2				
IC201	8-759-469-25	IC AK6440AF-E2				
IC202	8-759-567-36	IC MB91101PFV-G-BND-R				
IC203	8-759-580-60	IC SN74AHCT08PWR				
IC204	8-759-573-65	IC IDT71V016S20PHAU-TL				
IC205	8-759-593-83	IC MBM29LV160B-210B-20 (S330)				
IC205	8-759-594-03	IC MBM29LV160B-230B-20 (S530D)				
IC205	8-759-593-86	IC MBM29LV160B-220B-20 (S550D)				
IC205	8-759-593-85	IC MBM29LV160B-220A-20 (S705D)				
IC207	8-759-427-92	IC PST9126NL				
IC302	8-759-486-55	IC NJM2370U33-TE2				
IC303	8-759-567-27	IC CXD8784R				
IC304	8-759-567-35	IC KM416V1200CT-L6T				

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
IC401	8-752-388-68	IC CXD1930Q		R226	1-216-833-11	METAL CHIP 10K 5%	1/16W
IC402	8-759-567-34	IC KM416S1020CT-G10T		R227	1-216-813-11	METAL CHIP 220 5%	1/16W
IC403	8-759-567-34	IC KM416S1020CT-G10T		R228	1-216-813-11	METAL CHIP 220 5%	1/16W
IC404	8-759-486-55	IC NJM2370U33-TE2		R229	1-216-813-11	METAL CHIP 220 5%	1/16W
IC501	8-752-392-50	IC CXD1901R (S530D/S550D/S705D)		R230	1-216-813-11	METAL CHIP 220 5%	1/16W
IC502	8-752-390-12	IC CXD1857Q (S550D/S705D)		R231	1-216-813-11	METAL CHIP 220 5%	1/16W
IC601	8-759-567-30	IC CXD8788Q		R232	1-216-813-11	METAL CHIP 220 5%	1/16W
IC602	8-759-567-55	IC KM29V16000AT-T (S550D/S705D)		R235	1-216-864-11	METAL CHIP 0 5%	1/16W
IC701	8-759-567-25	IC CXD8791Q		R237	1-216-238-91	RES,CHIP 47K 5%	1/8W (S530D: E/S705D)
IC702	8-759-337-40	IC NJM2904V(Te2)		R238	1-216-238-91	RES,CHIP 47K 5%	1/8W (S530D)
IC801	8-759-522-13	IC BA5981FP-E2		R238	1-216-230-00	RES,CHIP 22K 5%	1/8W (S550D)
IC802	8-759-567-26	IC BA5983FP-E2					
IC803	8-759-338-78	IC BA10324AFV-E2		R238	1-216-224-91	RES,CHIP 12K 5%	1/8W (S705D)
IC902	8-759-572-26	IC CXD8799N-T2		R239	1-216-238-91	RES,CHIP 47K 5%	1/8W (S705D)
IC904	8-759-052-52	IC L78M05T-FA		R239	1-216-230-00	RES,CHIP 22K 5%	1/8W (S530D: E)
IC905	8-759-572-26	IC CXD8799N-T2 (S530D/S550D/S705D)		R240	1-216-238-91	RES,CHIP 47K 5%	1/8W (S530D: E/S705D)
IC906	8-759-572-26	IC CXD8799N-T2 (S530D/S550D/S705D)		R241	1-216-238-91	RES,CHIP 47K 5%	1/8W (S530D)
IC907	8-759-572-26	IC CXD8799N-T2 (S530D/S550D/S705D)					
< COIL >				R241	1-216-230-00	RES,CHIP 22K 5%	1/8W (S550D)
L001	1-414-754-11	INDUCTOR 10uH		R241	1-216-224-91	RES,CHIP 12K 5%	1/8W (S705D)
L402	1-414-754-11	INDUCTOR 10uH		R305	1-218-871-11	RES,CHIP 10K 0.50%	1/16W
< TRANSISTOR >				R306	1-218-831-11	RES,CHIP 220 0.50%	1/16W
Q801	8-729-015-74	TRANSISTOR UN5111-TX		R307	1-218-875-11	RES,CHIP 15K 0.50%	1/16W
Q802	8-729-905-35	TRANSISTOR 2SC4081-R		R308	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
Q803	8-729-905-35	TRANSISTOR 2SC4081-R		R309	1-216-838-11	METAL CHIP 27K 5%	1/16W
< RESISTOR >				R310	1-216-825-11	METAL CHIP 2.2K 5%	1/16W
R001	1-216-833-11	METAL CHIP 10K 5%	1/16W	R311	1-216-821-11	METAL CHIP 1K 5%	1/16W
R002	1-216-833-11	METAL CHIP 10K 5%	1/16W	R313	1-216-833-11	METAL CHIP 10K 5%	1/16W
R003	1-216-833-11	METAL CHIP 10K 5%	1/16W	R314	1-216-833-11	METAL CHIP 10K 5%	1/16W
R004	1-216-821-11	METAL CHIP 1K 5%	1/16W	R315	1-216-833-11	METAL CHIP 10K 5%	1/16W
R005	1-216-821-11	METAL CHIP 1K 5%	1/16W	R316	1-218-855-11	RES,CHIP 2.2K 0.50%	1/16W
R006	1-216-821-11	METAL CHIP 1K 5%	1/16W	R317	1-218-871-11	RES,CHIP 10K 0.50%	1/16W
R007	1-216-864-11	METAL CHIP 0 5%	1/16W	R318	1-216-849-11	METAL CHIP 220K 5%	1/16W
R009	1-216-864-11	METAL CHIP 0 5%	1/16W	R319	1-216-831-11	METAL CHIP 6.8K 5%	1/16W
R010	1-216-801-11	METAL CHIP 22 5%	1/16W	R320	1-218-853-11	RES,CHIP 1.8K 0.50%	1/16W
R014	1-216-801-11	METAL CHIP 22 5%	1/16W	R321	1-218-847-11	RES,CHIP 1K 0.50%	1/16W
R036	1-216-821-11	METAL CHIP 1K 5%	1/16W	R322	1-218-871-11	RES,CHIP 10K 0.50%	1/16W
R037	1-216-825-11	METAL CHIP 2.2K 5%	1/16W	R323	1-216-833-11	METAL CHIP 10K 5%	1/16W
R040	1-216-864-11	METAL CHIP 0 5%	1/16W (S530D/S550D/S705D)	R324	1-216-833-11	METAL CHIP 10K 5%	1/16W
R044	1-216-829-11	METAL CHIP 4.7K 5%	1/16W	R325	1-216-833-11	METAL CHIP 10K 5%	1/16W
R045	1-216-833-11	METAL CHIP 10K 5%	1/16W	R326	1-216-833-11	METAL CHIP 10K 5%	1/16W
R053	1-216-833-11	METAL CHIP 10K 5%	1/16W	R327	1-216-833-11	METAL CHIP 10K 5%	1/16W
R202	1-216-801-11	METAL CHIP 22 5%	1/16W	R328	1-216-833-11	METAL CHIP 10K 5%	1/16W
R203	1-216-833-11	METAL CHIP 10K 5%	1/16W	R329	1-216-833-11	METAL CHIP 10K 5%	1/16W
R204	1-216-833-11	METAL CHIP 10K 5%	1/16W	R330	1-216-833-11	METAL CHIP 10K 5%	1/16W
R205	1-216-845-11	METAL CHIP 100K 5%	1/16W	R331	1-216-833-11	METAL CHIP 10K 5%	1/16W
R206	1-216-845-11	METAL CHIP 100K 5%	1/16W	R332	1-216-833-11	METAL CHIP 10K 5%	1/16W
R207	1-216-833-11	METAL CHIP 10K 5%	1/16W	R337	1-216-809-11	METAL CHIP 100 5%	1/16W
R212	1-216-813-11	METAL CHIP 220 5%	1/16W (S530D/S550D/S705D)	R338	1-216-833-11	METAL CHIP 10K 5%	1/16W
R212	1-216-809-11	METAL CHIP 100 5%	1/16W (S330)	R339	1-216-833-11	METAL CHIP 10K 5%	1/16W
R213	1-216-801-11	METAL CHIP 22 5%	1/16W	R340	1-216-833-11	METAL CHIP 10K 5%	1/16W
R217	1-216-833-11	METAL CHIP 10K 5%	1/16W	R341	1-216-809-11	METAL CHIP 100 5%	1/16W
R222	1-216-833-11	METAL CHIP 10K 5%	1/16W	R403	1-216-833-11	METAL CHIP 10K 5%	1/16W
R223	1-216-833-11	METAL CHIP 10K 5%	1/16W				
R225	1-216-833-11	METAL CHIP 10K 5%	1/16W				

MB-82**MB-85**

Ref. No.	Part No.	Description	Remark		
R404	1-216-864-11	METAL CHIP	0	5%	1/16W
R405	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
R406	1-216-822-11	METAL CHIP	1.2K	5%	1/16W
R407	1-216-833-11	METAL CHIP	10K	5%	1/16W
R409	1-216-864-11	METAL CHIP	0	5%	1/16W
R410	1-216-821-11	METAL CHIP	1K	5%	1/16W
R411	1-216-833-11	METAL CHIP	10K	5%	1/16W
R412	1-216-809-11	METAL CHIP	100	5%	1/16W
R426	1-216-813-11	METAL CHIP	220	5%	1/16W
R427	1-216-813-11	METAL CHIP	220	5%	1/16W
R428	1-216-813-11	METAL CHIP	220	5%	1/16W
R429	1-216-813-11	METAL CHIP	220	5%	1/16W
R430	1-216-813-11	METAL CHIP	220	5%	1/16W
R431	1-216-813-11	METAL CHIP	220	5%	1/16W
R501	1-216-809-11	METAL CHIP	100	5%	1/16W
			(S550D/S705D)		
R502	1-216-806-11	RES,CHIP	56	5%	1/16W
			(S330)		
R519	1-216-809-11	METAL CHIP	100	5%	1/16W
			(S530D/S550D/S705D)		
R520	1-216-833-11	METAL CHIP	10K	5%	1/16W
			(S530D/S550D/S705D)		
R521	1-216-833-11	METAL CHIP	10K	5%	1/16W
			(S530D/S550D/S705D)		
R522	1-216-833-11	METAL CHIP	10K	5%	1/16W
			(S530D/S550D/S705D)		
R527	1-216-833-11	METAL CHIP	10K	5%	1/16W
R528	1-216-833-11	METAL CHIP	10K	5%	1/16W
R529	1-216-864-11	METAL CHIP	0	5%	1/16W
			(S330)		
R530	1-216-864-11	METAL CHIP	0	5%	1/16W
			(S530D/S550D/S705D)		
R536	1-216-864-11	METAL CHIP	0	5%	1/16W
			(S330)		
R537	1-216-806-11	RES,CHIP	56	5%	1/16W
			(S530D/S550D/S705D)		
R538	1-216-864-11	METAL CHIP	0	5%	1/16W
			(S330)		
R539	1-216-864-11	METAL CHIP	0	5%	1/16W
			(S530D/S550D/S705D)		
R540	1-216-864-11	METAL CHIP	0	5%	1/16W
			(S530D/S550D/S705D)		
R541	1-216-864-11	METAL CHIP	0	5%	1/16W
			(S530D/S550D/S705D)		
R543	1-216-864-11	METAL CHIP	0	5%	1/16W
			(S530D/S550D/S705D)		
R544	1-216-864-11	METAL CHIP	0	5%	1/16W
			(S530D/S550D/S705D)		
R604	1-216-833-11	METAL CHIP	10K	5%	1/16W
			(S550D/S705D)		
R605	1-216-833-11	METAL CHIP	10K	5%	1/16W
R606	1-216-833-11	METAL CHIP	10K	5%	1/16W
R630	1-216-833-11	METAL CHIP	10K	5%	1/16W
R631	1-216-833-11	METAL CHIP	10K	5%	1/16W
R632	1-216-833-11	METAL CHIP	10K	5%	1/16W
R633	1-216-833-11	METAL CHIP	10K	5%	1/16W
R634	1-216-833-11	METAL CHIP	10K	5%	1/16W
R635	1-216-833-11	METAL CHIP	10K	5%	1/16W
R636	1-216-815-11	METAL CHIP	330	5%	1/16W
R637	1-216-809-11	METAL CHIP	100	5%	1/16W
R638	1-216-809-11	METAL CHIP	100	5%	1/16W
R639	1-216-809-11	METAL CHIP	100	5%	1/16W
R640	1-216-809-11	METAL CHIP	100	5%	1/16W

Ref. No.	Part No.	Description	Remark		
R641	1-216-809-11	METAL CHIP	100	5%	1/16W
R642	1-216-809-11	METAL CHIP	100	5%	1/16W
R643	1-216-815-11	METAL CHIP	330	5%	1/16W
R647	1-216-833-11	METAL CHIP	10K	5%	1/16W
R701	1-216-805-11	METAL CHIP	47	5%	1/16W
R702	1-216-817-11	METAL CHIP	470	5%	1/16W
R703	1-216-817-11	METAL CHIP	470	5%	1/16W
R704	1-216-817-11	METAL CHIP	470	5%	1/16W
R705	1-216-817-11	METAL CHIP	470	5%	1/16W
R706	1-216-821-11	METAL CHIP	1K	5%	1/16W
R707	1-216-844-11	METAL CHIP	82K	5%	1/16W
R708	1-216-844-11	METAL CHIP	82K	5%	1/16W
R709	1-216-844-11	METAL CHIP	82K	5%	1/16W
R710	1-216-844-11	METAL CHIP	82K	5%	1/16W
R711	1-216-833-11	METAL CHIP	10K	5%	1/16W
R712	1-216-839-11	METAL CHIP	33K	5%	1/16W
R713	1-216-864-11	METAL CHIP	0	5%	1/16W
			(S550D)		
R714	1-216-864-11	METAL CHIP	0	5%	1/16W
			(S550D)		
R715	1-216-864-11	METAL CHIP	0	5%	1/16W
			(S550D)		
R716	1-216-864-11	METAL CHIP	0	5%	1/16W
			(S550D)		
R717	1-216-864-11	METAL CHIP	0	5%	1/16W
			(S550D)		
R720	1-216-821-11	METAL CHIP	1K	5%	1/16W
R721	1-216-821-11	METAL CHIP	1K	5%	1/16W
R722	1-216-801-11	METAL CHIP	22	5%	1/16W
R748	1-216-833-11	METAL CHIP	10K	5%	1/16W
R751	1-216-821-11	METAL CHIP	1K	5%	1/16W
R752	1-216-821-11	METAL CHIP	1K	5%	1/16W
R755	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R757	1-216-864-11	METAL CHIP	0	5%	1/16W
R758	1-216-864-11	METAL CHIP	0	5%	1/16W
R801	1-216-841-11	METAL CHIP	47K	5%	1/16W
R802	1-216-841-11	METAL CHIP	47K	5%	1/16W
R803	1-216-841-11	METAL CHIP	47K	5%	1/16W
R804	1-216-841-11	METAL CHIP	47K	5%	1/16W
R805	1-216-840-11	METAL CHIP	39K	5%	1/16W
R806	1-216-840-11	METAL CHIP	39K	5%	1/16W
R807	1-216-835-11	METAL CHIP	15K	5%	1/16W
R808	1-216-835-11	METAL CHIP	15K	5%	1/16W
R809	1-216-844-11	METAL CHIP	82K	5%	1/16W
R810	1-216-844-11	METAL CHIP	82K	5%	1/16W
R811	1-218-907-11	RES,CHIP	330K	0.50%	1/16W
R812	1-218-895-11	RES,CHIP	100K	0.50%	1/16W
R813	1-218-895-11	RES,CHIP	100K	0.50%	1/16W
R814	1-218-907-11	RES,CHIP	330K	0.50%	1/16W
R815	1-216-836-11	METAL CHIP	18K	5%	1/16W
R816	1-216-845-11	METAL CHIP	100K	5%	1/16W
R817	1-216-852-11	METAL CHIP	390K	5%	1/16W
R818	1-216-852-11	METAL CHIP	390K	5%	1/16W
R819	1-216-849-11	METAL CHIP	220K	5%	1/16W
R820	1-216-851-11	METAL CHIP	330K	5%	1/16W
R821	1-216-840-11	METAL CHIP	39K	5%	1/16W
R822	1-216-845-11	METAL CHIP	100K	5%	1/16W
R823	1-216-833-11	METAL CHIP	10K	5%	1/16W
R824	1-216-833-11	METAL CHIP	10K	5%	1/16W
R825	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R826	1-216-830-11	METAL CHIP	5.6K	5%	1/16W

MB-82

MB-85

MS-29

POWER BLOCK

Ref. No.	Part No.	Description	Remark
R827	1-216-851-11	METAL CHIP	330K 5% 1/16W
R828	1-216-837-11	METAL CHIP	22K 5% 1/16W
R829	1-216-837-11	METAL CHIP	22K 5% 1/16W
R831	1-216-833-11	METAL CHIP	10K 5% 1/16W
R832	1-216-833-11	METAL CHIP	10K 5% 1/16W
R834	1-216-847-11	METAL CHIP	150K 5% 1/16W
R835	1-216-847-11	METAL CHIP	150K 5% 1/16W
R836	1-216-847-11	METAL CHIP	150K 5% 1/16W
R837	1-216-844-11	METAL CHIP	82K 5% 1/16W
R838	1-216-848-11	METAL CHIP	180K 5% 1/16W
R839	1-216-848-11	METAL CHIP	180K 5% 1/16W
R840	1-216-848-11	METAL CHIP	180K 5% 1/16W
R841	1-216-843-11	METAL CHIP	68K 5% 1/16W
R842	1-216-844-11	METAL CHIP	82K 5% 1/16W
R843	1-216-844-11	METAL CHIP	82K 5% 1/16W
R844	1-216-843-11	METAL CHIP	68K 5% 1/16W
R845	1-216-843-11	METAL CHIP	68K 5% 1/16W
R846	1-216-841-11	METAL CHIP	47K 5% 1/16W
R847	1-216-296-91	SHORT	0
R851	1-216-833-11	METAL CHIP	10K 5% 1/16W
R852	1-216-833-11	METAL CHIP	10K 5% 1/16W
R853	1-216-833-11	METAL CHIP	10K 5% 1/16W
R854	1-216-833-11	METAL CHIP	10K 5% 1/16W
R855	1-216-834-11	METAL CHIP	12K 5% 1/16W
R856	1-216-836-11	METAL CHIP	18K 5% 1/16W
R857	1-218-899-11	RES,CHIP	150K 0.50% 1/16W
R858	1-218-899-11	RES,CHIP	150K 0.50% 1/16W
R859	1-218-899-11	RES,CHIP	56K 0.50% 1/16W
R860	1-218-899-11	RES,CHIP	56K 0.50% 1/16W
R861	1-216-296-91	SHORT	0
R862	1-216-864-11	METAL CHIP	0 5% 1/16W
R863	1-216-864-11	METAL CHIP	0 5% 1/16W
R864	1-216-138-00	METAL CHIP	3.3 5% 1/8W
R865	1-216-833-11	METAL CHIP	10K 5% 1/16W
R866	1-216-833-11	METAL CHIP	10K 5% 1/16W
R867	1-216-833-11	METAL CHIP	10K 5% 1/16W
R868	1-216-833-11	METAL CHIP	10K 5% 1/16W
R869	1-216-833-11	METAL CHIP	10K 5% 1/16W
R870	1-216-815-11	METAL CHIP	330 5% 1/16W
R871	1-216-817-11	METAL CHIP	470 5% 1/16W
R872	1-216-815-11	METAL CHIP	330 5% 1/16W
R873	1-216-821-11	METAL CHIP	1K 5% 1/16W
R909	1-216-809-11	METAL CHIP	100 5% 1/16W
			(S530D/S550D/S705D)
R912	1-216-809-11	METAL CHIP	100 5% 1/16W
			(S530D/S550D/S705D)
R915	1-216-809-11	METAL CHIP	100 5% 1/16W
R918	1-216-809-11	METAL CHIP	100 5% 1/16W
			(S530D/S550D/S705D)
< COMPOSITION CIRCUIT BLOCK >			
* RB201	1-233-270-11	NETWORK, RES (8 GANG) 10K	
* RB202	1-233-270-11	NETWORK, RES (8 GANG) 10K	
* RB203	1-233-270-11	NETWORK, RES (8 GANG) 10K	
* RB204	1-233-270-11	NETWORK, RES (8 GANG) 10K	
* RB402	1-233-270-11	NETWORK, RES (8 GANG) 10K	
* RB601	1-233-270-11	NETWORK, RES (8 GANG) 10K	
< VARIABLE RESISTOR >			
RV401	1-223-583-11	RES, ADJ, CARBON 1K	

Ref. No.	Part No.	Description	Remark
< VIBRATOR >			
X001	1-781-188-21	OSCILLATOR, CRYSTAL (27MHz)	
X201	1-781-185-21	VIBRATOR, CERAMIC (12.5MHz)	(S330/S530D/S550D)
X201	1-781-185-11	VIBRATOR, CERAMIC (12.5MHz)	(S705D)
* A-6066-012-A MS-29 BOARD, COMPLETE			

(Ref.No. 3,000 Series)			
< CONNECTOR >			
CN001	1-564-722-11	PIN, CONNECTOR (SMALL TYPE) 6P	
< SWITCH >			
S001	1-771-562-11	SWITCH, LEVER (TRAY SENSOR)	
S002	1-762-386-11	SWITCH, PUSH (CHUCK SENSOR)	
* 1-468-359-21 POWER BLOCK (HS-030SF) (S530D: E)			
* 1-468-359-11 POWER BLOCK (HS-030SH) (S705D)			

(Ref.No. 6,000 Series)			
< CAPACITOR >			
C110	9-884-088-01	ELECT	56uF 400V (HS-030SH)
C110	9-884-093-01	ELECT	220uF 400V (HS-030SF)
C131	1-126-964-11	ELECT	10uF 50V
C132	1-126-960-11	ELECT	1uF 50V
C186	1-107-967-11	ELECT	1uF 400V
C211	1-111-087-11	ELECT	330uF 35V
C213	1-126-947-11	ELECT	47uF 35V
C301	1-126-960-11	ELECT	1uF 50V
C311	1-111-087-11	ELECT	330uF 35V
C313	1-126-947-11	ELECT	47uF 35V
C401	1-126-948-11	ELECT	100uF 35V
C402	1-126-960-11	ELECT	1uF 50V
C511	1-126-942-11	ELECT	1000uF 25V
C512	1-126-947-11	ELECT	47uF 35V
C611	1-111-090-11	ELECT	560uF 35V
C613	1-126-947-11	ELECT	47uF 35V
< DIODE >			
D101	9-884-089-01	DIODE	S1WBA60
D102	8-719-160-68	DIODE	RD18FB2
D104	8-719-109-63	DIODE	RD3.0ESB2 (HS-030SF)
D104	8-719-109-57	DIODE	RD2.4ESB2 (HS-030SH)
D133	8-719-109-60	DIODE	RD2.7ESB2
D182	8-719-109-60	DIODE	RD2.7ESB2
D184	9-880-435-01	DIODE	D1N60
D185	8-719-160-68	DIODE	RD18FB2
D211	8-719-027-43	DIODE	S2L20U
D212	8-719-160-78	DIODE	RD24FB2
D311	8-719-200-59	DIODE	21DQ04
D401	8-719-210-21	DIODE	11EQS04
D402	8-719-110-02	DIODE	RD7.5ESB1
D611	8-719-500-50	DIODE	D3S4M

POWER BLOCK

RY-12

Ref. No.	Part No.	Description	Remark
< FUSE >			
△ F101	1-532-503-31	FUSE (1.6A/250V)	
< IC LINK >			
△ P211	1-533-588-11	IC LINK 500mA	
△ P311	1-533-593-11	IC LINK 2A	
△ P511	1-533-589-11	IC LINK 750mA	
△ P611	9-884-090-01	IC LINK 1.5A	
< PHOTO COUPLER >			
△ PC101	8-749-010-59	PHOTO COUPLER TLP721F	
△ PC102	8-749-010-59	PHOTO COUPLER TLP721F	
△ PC103	8-749-010-59	PHOTO COUPLER TLP721F	
< TRANSISTOR >			
Q101	9-880-450-01	TRANSISTOR 2SK2333	
Q102	8-729-023-98	TRANSISTOR 2SC3377	
Q103	9-880-450-01	TRANSISTOR 2SK2333	
Q131	8-729-023-98	TRANSISTOR 2SC3377	
Q181	8-729-046-40	TRANSISTOR 2SK2663	
Q182	8-729-023-98	TRANSISTOR 2SC3377	
Q183	8-729-046-40	TRANSISTOR 2SK2663	
< RESISTOR >			
R152	1-219-121-21	FUSIBLE 0.22	1/4W F
< TRANSFORMER >			
△ T101	9-884-094-01	TRANSFORMER OM-98023 (HS-030SF)	
△ T101	9-884-091-01	TRANSFORMER OM-98024 (HS-030SH)	
△ T102	9-884-095-01	TRANSFORMER OM-98059 (HS-030SF)	
△ T102	9-884-092-01	TRANSFORMER OM-98060 (HS-030SH)	

*	1-468-358-21	POWER BLOCK (SRV902UC) (S330/S530D: US, Canadian/S550D)	

(Ref.No. 7,000 Series)			
< CAPACITOR >			
C108	9-884-071-01	ELECT 220uF	200V
C111	1-126-963-11	ELECT 4.7uF	50V
C201	1-111-041-11	ELECT 1000uF	16V
C202	1-126-933-11	ELECT 100uF	16V
C203	9-884-075-01	ELECT 1000uF	10V
C204	1-126-933-11	ELECT 100uF	16V
C206	9-884-076-01	ELECT 2200uF	10V
C207	1-126-933-11	ELECT 100uF	16V
C208	9-884-077-01	ELECT 470uF	16V
C209	1-126-933-11	ELECT 100uF	16V
C210	1-126-933-11	ELECT 100uF	16V
C211	1-126-933-11	ELECT 100uF	16V
< DIODE >			
D101	8-719-904-05	DIODE IN4005	
D102	8-719-904-05	DIODE IN4005	
D103	8-719-904-05	DIODE IN4005	
D104	8-719-904-05	DIODE IN4005	
D105	8-719-059-27	DIODE P6KE150	

Ref. No.	Part No.	Description	Remark
D106	8-719-052-58	DIODE AG01A	
D107	8-719-059-27	DIODE 1SS119	
D108	8-719-981-98	DIODE MTZJ3.0	
D109	8-719-904-05	DIODE IN4005	
D110	8-719-904-05	DIODE IN4005	
D121	8-719-981-98	DIODE MTZJ3.0	
D122	8-719-059-27	DIODE 1SS119	
D201	8-719-052-74	DIODE FMX-12S	
D202	8-719-907-30	DIODE ERB84-009	
D203	8-719-052-57	DIODE 31DQ04	
D204	8-719-059-45	DIODE AU02Z	
D205	9-884-074-01	DIODE MA2300	
D206	8-719-043-74	DIODE AK04	
D208	8-719-921-50	DIODE MTZJ6.2	
< FUSE >			
△ F101	1-533-296-11	FUSE (2A/125V)	
< IC >			
IC201	8-759-420-19	IC AN1431	
IC202	8-759-420-19	IC AN1431	
< PHOTO COUPLER >			
△ PC101	8-749-014-24	PHOTO COUPLER ON3131	
△ PC102	8-749-014-24	PHOTO COUPLER ON3131	
△ PC121	8-749-014-24	PHOTO COUPLER ON3131	
< IC LINK >			
△ PS201	1-553-558-11	IC LINK 500mA	
△ PS202	1-553-590-11	IC LINK 1A	
△ PS203	1-553-593-11	IC LINK 2A	
△ PS204	1-553-589-11	IC LINK 750mA	
< TRANSISTOR >			
Q101	8-729-905-71	TRANSISTOR 2SC4056	
Q102	8-729-012-31	TRANSISTOR 2SC4040	
Q121	8-729-047-03	TRANSISTOR 2SK2177	
Q122	8-729-925-16	TRANSISTOR 2SC1740S	
Q201	8-729-422-72	TRANSISTOR UN4211	
< RESISTOR >			
R121	9-884-072-01	CARBON 10	1/4W F
R129	9-884-073-01	CARBON 100	1/4W F
< TRANSFORMER >			
△ T101	9-884-069-01	TRANSFORMER ETS28AE2G5AC	
△ T102	9-884-070-01	TRANSFORMER ETS19AB1B6AG	

*	A-6065-255-A	RY-12 BOARD, COMPLETE (S705D)	

(Ref.No. 3,000 Series)			
< CONNECTOR >			
* CN101	1-580-230-21	PIN, CONNECTOR (PC BOARD) 2P	
* CN201	1-691-960-11	PIN, CONNECTOR (PC BOARD) 3P	
* CN202	1-564-001-11	PIN, CONNECTOR 2P	

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark
		< DIODE >	
D101	8-719-911-19	DIODE 1SS119	
		< RELAY >	
△RY101	1-755-318-11	RELAY, POWER	
*	A-6065-243-A	SW-315 BOARD, COMPLETE (S705D)	
*	A-6065-221-A	SW-317 BOARD, COMPLETE (S530D/S550D)	

		(Ref.No. 4,000 Series)	
		< CONNECTOR >	
CN099	1-785-539-11	CONNECTOR, BOARD TO BOARD 4P	
		< DIODE >	
D098	8-719-056-06	DIODE SLR-342DCT31 (VES) (S530D)	
D098	8-719-056-06	DIODE SLR-342DCT31	
		(VIRTUAL 3D SURROUND) (S550D/S705D)	
		< TRANSISTOR >	
Q098	8-729-421-22	TRANSISTOR UN2211	
		< RESISTOR >	
R098	1-216-041-00	METAL CHIP 470 5% 1/10W	
		< SWITCH >	
S098	1-771-349-21	SWITCH, KEYBOARD (VES) (S530D)	
S098	1-771-349-21	SWITCH, KEYBOARD	
		(VIRTUAL 3D SURROUND) (S550D/S705D)	
*	A-6065-214-A	TK-51 BOARD, COMPLETE	

		(Ref.No. 2,000 Series)	
		< CAPACITOR >	
C004	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C005	1-162-966-11	CERAMIC CHIP 0.0022uF 10% 50V	
C006	1-124-779-00	ELECT CHIP 10uF 20% 16V	
C007	1-162-966-11	CERAMIC CHIP 0.0022uF 10% 50V	
C008	1-162-966-11	CERAMIC CHIP 0.0022uF 10% 50V	
C009	1-162-966-11	CERAMIC CHIP 0.0022uF 10% 50V	
C010	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C011	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C012	1-124-779-00	ELECT CHIP 10uF 20% 16V	
C013	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C014	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C015	1-162-919-11	CERAMIC CHIP 22PF 5% 50V	
C016	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C017	1-164-172-11	CERAMIC CHIP 0.0056uF 10% 25V	
C018	1-164-739-11	CERAMIC CHIP 560PF 5% 50V	
C019	1-164-172-11	CERAMIC CHIP 0.0056uF 10% 25V	
C020	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C021	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C022	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C023	1-165-176-11	CERAMIC CHIP 0.047uF 10% 16V	

Ref. No.	Part No.	Description	Remark
C024	1-164-730-11	CERAMIC CHIP 0.0012uF 10% 50V	
C025	1-165-176-11	CERAMIC CHIP 0.047uF 10% 16V	
C026	1-162-964-11	CERAMIC CHIP 0.001uF 10% 50V	
C027	1-164-217-11	CERAMIC CHIP 150PF 5% 50V	
C028	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	
C029	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C030	1-107-725-11	CERAMIC CHIP 0.1uF 10% 16V	
C031	1-124-779-00	ELECT CHIP 10uF 20% 16V	
C032	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C033	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C034	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C035	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C036	1-165-176-11	CERAMIC CHIP 0.047uF 10% 16V	
C037	1-164-739-11	CERAMIC CHIP 560PF 5% 50V	
C038	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C039	1-107-826-91	CERAMIC CHIP 0.1uF 10% 16V	
C040	1-162-969-11	CERAMIC CHIP 0.0068uF 10% 25V	
C041	1-162-966-11	CERAMIC CHIP 0.0022uF 10% 50V	
		< CONNECTOR >	
CN001	1-785-700-21	CONNECTOR, FFC/FPC (ZIF) 23P	
CN002	1-566-529-11	CONNECTOR, FPC (ZIF) 13P	
CN003	1-785-699-21	CONNECTOR, FFC/FPC 18P	
CN004	1-785-699-21	CONNECTOR, FFC/FPC 18P	
		< DIODE >	
D003	8-719-988-61	DIODE 1SS355TE-17	
		< IC >	
IC001	8-759-567-24	IC SSI33P3722	
		< COIL >	
L001	1-412-031-11	INDUCTOR CHIP 47uH	
		< TRANSISTOR >	
Q001	8-729-903-46	TRANSISTOR 2SB1132-T100-QR	
Q002	8-729-015-76	TRANSISTOR UN5211-TX	
		< RESISTOR >	
R001	1-216-815-11	METAL CHIP 330 5% 1/16W	
R002	1-216-809-11	METAL CHIP 100 5% 1/16W	
R003	1-216-809-11	METAL CHIP 100 5% 1/16W	
R004	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R005	1-216-013-00	METAL CHIP 33 5% 1/10W	
R006	1-216-013-00	METAL CHIP 33 5% 1/10W	
R007	1-216-841-11	METAL CHIP 47K 5% 1/16W	
R008	1-216-797-11	METAL CHIP 10 5% 1/16W	
R009	1-216-834-11	METAL CHIP 12K 5% 1/16W	
R010	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R012	1-216-864-11	METAL CHIP 0 5% 1/16W	
R014	1-216-864-11	METAL CHIP 0 5% 1/16W	
R015	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R016	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R017	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
R018	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R022	1-216-811-11	METAL CHIP 150 5% 1/16W	
R023	1-216-820-11	METAL CHIP 820 5% 1/16W	

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark
R025	1-216-813-11	METAL CHIP 220 5%	1/16W
R026	1-216-864-11	METAL CHIP 0 5%	1/16W

MISCELLANEOUS

115	1-418-097-11	ENCODER, ROTARY (S530D/S550D/S705D)	
117	1-771-564-11	SWITCH, TACTILE (S330)	
127	1-790-167-11	CABLE, FLEXIBLE FLAT (FMF-35)	
153	1-790-166-11	CABLE, FLEXIBLE FLAT (FMT-25)	
154	1-790-163-11	CABLE, FLEXIBLE FLAT (FMA-7)	
155	1-790-164-11	CABLE, FLEXIBLE FLAT (FMA-8) (S530D/S550D/S705D)	
156	1-790-165-11	CABLE, FLEXIBLE FLAT (FMA-9) (S530D/S550D/S705D)	
△ 161	1-769-744-91	CORD, POWER (E, Hong Kong, Singapore)	
△ 161	1-783-531-31	CORD, POWER (US, Canadian)	
△ 220	8-820-081-03	OPTICAL PICK-UP KHM-220AAA/J1RP	
M001	1-541-632-11	MOTOR, DC (LOADING)	
△ T901	1-431-175-21	TRANSFORMER, POWER (S705D)	

HARDWARE LIST

#1	7-685-885-09	SCREW +BVTT 4X16 (S) (S705D)
#2	7-621-775-10	SCREW +B 2.6X4
#3	7-685-536-19	SCREW +BTP 2.6X12 TYPE2 N-S

ACCESSORIES & PACKING MATERIALS

	1-418-320-21	COMMANDER, STANDARD (RMT-D108A) (S530D)
	1-418-320-41	COMMANDER, STANDARD (RMT-D109A) (S330)
	1-418-321-11	COMMANDER, STANDARD (RMT-D111A) (S550D)
	1-418-321-61	COMMANDER, STANDARD (RMT-D111E/N) (S705D: Hong Kong)
	1-418-321-71	COMMANDER, STANDARD (RMT-D111E/H) (S705D: Singapore)
△	1-569-008-21	ADAPTOR, CONVERSION 2P (E)
	1-575-334-41	CORD, CONNECTION (STEREO AV CABLE 1.5m) (S705D)
	1-575-334-11	CORD, CONNECTION (STEREO AV CABLE 1.5m) (S530: E)
	1-575-335-21	CORD, CONNECTION (S-VIDEO CABLE 1.5m) (S330/S530D/S550D)
△	1-770-019-11	ADAPTOR, CONVERSION PLUG 3P (Hong Kong)
	1-776-078-31	CORD, CONNECTION (S-VIDEO CABLE 1.5m) (S705D)
	1-782-997-11	CORD, CONNECTION (STEREO AV S-LINK CABLE 1.5m) (US, Canadian)
	3-053-633-01	COVER, BATTERY (for RMT-D108A/D109A) (S330/S530D)
	3-055-539-01	COVER, BATTERY (for RMT-D111A/D111E/N/D111E/H) (S550D/S705D)

Ref. No.	Part No.	Description	Remark
	3-865-641-11	MANUAL, INSTRUCTION (ENGLISH) (S550D: US, Canadian)	
	3-865-641-21	MANUAL, INSTRUCTION (FRENCH) (S550D: Canadian)	
	3-865-642-11	MANUAL, INSTRUCTION (ENGLISH) (S530D: US, Canadian)	
	3-865-642-21	MANUAL, INSTRUCTION (FRENCH) (S530D: Canadian)	
	3-865-642-31	MANUAL, INSTRUCTION (ENGLISH, SPANISH, PORTUGUESE) (S530D: E)	
	3-866-153-11	MANUAL, INSTRUCTION (ENGLISH, CHINESE) (S705D)	
	3-866-504-11	MANUAL, INSTRUCTION (ENGLISH) (S330)	
	3-866-504-21	MANUAL, INSTRUCTION (FRENCH) (S330: Canadian)	
	3-866-506-11	MANUAL, INSTRUCTION (ENGLISH) (S330: US)	
	3-866-506-21	MANUAL, INSTRUCTION (ENGLISH) (FRENCH) (S330: Canadian)	

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

